

SBC-E Series

ELECTRIC BOILERLESS STEAMER

INSTALLATION - OPERATION - MAINTENANCE



BLODGETT OVEN COMPANY

www.blodgett.com
44 Lakeside Avenue, Burlington, Vermont 05401 USA
Manufacture Service Questions: 866-518-3977

PART NUMBER 170118 REV A (04/11)

THIS MANUAL MUST BE RETAINED FOR FUTURE REFERENCE. READ, UNDERSTAND AND FOLLOW THE INSTRUCTIONS AND WARNINGS CONTAINED IN THIS MANUAL.

FOR YOUR SAFETY

DO NOT STORE OR USE GASOLINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.

WARNING

IMPROPER INSTALLATION, ADJUSTMENT, ALTERATION, SERVICE OR MAINTENANCE CAN CAUSE PROPERTY DAMAGE, INJURY OR DEATH. READ THE INSTALLATION, OPERATING AND MAINTENANCE INSTRUCTIONS THOROUGHLY BEFORE INSTALLING OR SERVICING THIS EQUIPMENT.

NOTIFY CARRIER OF DAMAGE AT ONCE

IT IS THE RESPONSIBILITY OF THE CONSIGNEE TO INSPECT THE CONTAINER UPON RECEIPT OF SAME AND TO DETERMINE THE POSSIBILITY OF ANY DAMAGE, INCLUDING CONCEALED DAMAGE. WE SUGGEST THAT IF YOU ARE SUSPICIOUS OF DAMAGE TO MAKE A NOTATION ON THE DELIVERY RECEIPT. IT WILL BE THE RESPONSIBILITY OF THE CONSIGNEE TO FILE A CLAIM WITH THE CARRIER. WE RECOMMEND THAT YOU DO SO AT ONCE.

IMPORTANT - READ FIRST - IMPORTANT

- WARNING:** THE UNIT MUST BE INSTALLED BY PERSONNEL QUALIFIED TO WORK WITH ELECTRICITY AND PLUMBING. IMPROPER INSTALLATION CAN CAUSE INJURY TO PERSONNEL AND/OR DAMAGE TO THE EQUIPMENT. THE UNIT MUST BE INSTALLED IN ACCORDANCE WITH APPLICABLE CODES.
- CAUTION:** SHIPPING STRAPS ARE UNDER TENSION AND CAN SNAP BACK WHEN CUT.
- CAUTION:** DO NOT INSTALL THE UNIT IN ANY WAY WHICH WILL BLOCK THE REAR VENTS, OR WITHIN 2 INCHES OF A HEAT SOURCE SUCH AS A BRAISING PAN, DEEP FRYER, CHAR BROILER OR KETTLE.
- CAUTION:** LEVEL THE UNIT FRONT TO BACK, AND PITCH IT SLIGHTLY TO THE FRONT, TO AVOID DRAINAGE PROBLEMS.
- WARNING:** FOLLOW THE WIRING DIAGRAM EXACTLY WHEN CONNECTING A UNIT TO AVOID DAMAGE OR INJURY. WIRING DIAGRAM IS LOCATED ON THE INSIDE OF THE RIGHT PANEL.
- CAUTION:** DO NOT USE PLASTIC PIPE. DRAIN MUST BE RATED FOR BOILING WATER.
- WARNING:** DO NOT CONNECT THE DRAIN DIRECTLY TO A BUILDING DRAIN.
- WARNING:** BLOCKING THE DRAIN IS HAZARDOUS.
- IMPORTANT:** IMPROPER DRAIN CONNECTION WILL VOID WARRANTY.
- IMPORTANT:** DO NOT ALLOW ANY WATER TRAPS IN THE DRAIN LINE. A TRAP CAN CAUSE PRESSURE TO BUILD UP INSIDE THE CAVITY DURING STEAMING, WHICH WILL MAKE THE DOOR GASKET LEAK.
- WARNING:** WHEN YOU OPEN THE DOOR, STAY AWAY FROM STEAM COMING OUT OF THE UNIT. STEAM CAN CAUSE BURNS.
- WARNING:** BEFORE CLEANING THE OUTSIDE OF THE STEAMER, DISCONNECT THE ELECTRIC POWER SUPPLY. KEEP WATER AND CLEANING SOLUTIONS OUT OF CONTROLS AND ELECTRICAL COMPONENTS. NEVER HOSE OR STEAM CLEAN ANY PART OF THE UNIT.
- WARNING:** ALLOW COOKING CHAMBER TO COOL COMPLETELY BEFORE CLEANING.
- WARNING:** USE MILD CLEANING AGENTS ONLY. CAREFULLY READ THE WARNINGS AND FOLLOW THE DIRECTIONS ON THE LABEL OF EACH CLEANING AGENT. USE SAFETY GLASSES AND RUBBER GLOVES AS RECOMMENDED BY CLEANING AGENT MANUFACTURER.
- WARNING:** DO NOT PUT HANDS OR TOOLS INTO THE COOKING CHAMBER UNTIL THE FAN HAS STOPPED TURNING.
- WARNING:** DO NOT OPERATE THE UNIT UNLESS THE REMOVABLE RIGHT SIDE PANEL HAS BEEN RETURNED TO ITS PROPER LOCATION.
- NOTICE:** DO NOT USE A CLEANING AGENT THAT CONTAINS ANY SULFAMIC ACID, OR ANY CHLORIDE, INCLUDING HYDROCHLORIC ACID. IF THE CHLORIDE CONTENT OF ANY PRODUCT IS UNCLEAR, CONSULT THE MANUFACTURER. DO NOT USE A CLEANING OR DELIMING AGENT THAT CONTAINS MORE THAN 30% PHOSPHORIC ACID.
- NOTICE:** DO NOT USE ANY DEGREASER THAT CONTAINS POTASSIUM HYDROXIDE OR SODIUM HYDROXIDE OR THAT IS ALKALINE.
- WARNING:** USE OF ANY REPLACEMENT PARTS OTHER THAN THOSE SUPPLIED BY THE MANUFACTURER OR AN AUTHORIZED DISTRIBUTOR VOIDS ALL WARRANTIES AND CAN RESULT IN BODILY INJURY TO THE OPERATOR AND DAMAGE THE EQUIPMENT. SERVICE BY OTHER THAN FACTORY-AUTHORIZED PERSONNEL WILL VOID ALL WARRANTIES.
- WARNING:** HIGH VOLTAGE EXISTS INSIDE CONTROL COMPARTMENTS. DISCONNECT FROM BRANCH CIRCUIT BEFORE SERVICING. FAILURE TO DO SO CAN RESULT IN INJURY OR DEATH.

Table of Contents

Important Operator Warnings	page 1
References.....	page 2
Equipment Description.....	page 3
Inspection and Unpacking	page 4
Installation	page 5-6
Initial Start-Up.....	page 7
Operation	page 8-9
Cleaning.....	page 10-11
Maintenance.....	page 12
Troubleshooting.....	page 13
Schematics/Wiring Diagram	page 20-21
Service Log	page 22

References

UNDERWRITERS LABORATORIES, INC.
333 Pfingsten Road
Northbrook, Illinois 60062

NFPA/70 - The National Electrical Code

NATIONAL FIRE PROTECTION ASSOCIATION
60 Battery March Park
Quincy, Massachusetts 02269

NSF INTERNATIONAL
789 N. Dixboro Road
P.O. Box 130140
Ann Arbor, Michigan 48113-0140

Equipment Description



Your 3-pan, 5-pan or 10-pan boilerless steamer is designed to give years of service. It has a stainless steel cavity (cooking chamber) which is served by an electric heated atmospheric steam generating reservoir. A powerful blower circulates the steam in the cavity to increase heating efficiency.

Each cavity holds up to three, five or ten steam table pans (12" x 20" x 2 1/2" deep) as shown below.

Model	PAN DIMENSIONS					
	12 x 20 x 1	12 x 20 x 2-1/2	12 x 20 x 4	12 x 20 x 6	13 x 18 x 1	26 x 18 x 1
3-Pan	6	3	2	1	-	-
(2) 3-Pan	12	6	4	2	-	-
5-Pan	10	5	3	2	-	-
(2) 5-Pan	20	10	6	4	-	-
10-Pan	20	10	6	4	20	10
(2) 10-Pan	40	20	12	8	40	20

An 18-gauge stainless steel case encloses the cavity, the steam generating reservoir and the control compartment that houses electrical components. Door hinges are field-reversible (the door may be set to open from the left or right). Operating controls are on the front panel.

The boilerless steamers are equipped with fully electronic controls. These units are readily identified by their unique control panels. Steamer function is controlled by touch pad controls and a rotary timer-dial. The drain system on all models includes a spray condenser, which cools drain water.

Inspection & Unpacking

CAUTION
SHIPPING STRAPS ARE UNDER TENSION
AND CAN SNAP BACK WHEN CUT.

Your boilerless steamer will be delivered completely assembled in a heavy shipping carton strapped to a skid. On receipt, inspect carton carefully for exterior damage.

Carefully cut the straps and detach the sides of the carton from the skid. Pull the carton up off the unit. Be careful to avoid personal injury or equipment damage from staples which might be left in the carton walls. Write down the model number, serial number and installation date. Keep this information for reference. Space for these entries is provided at the top of the Service Log in the back of this manual.

Steamer Type	Ship Weight (LBS)	Ship Weight (KGS)
3-Pan Table Top	220	100
3-Pan on stand	310	141
(2) 3-Pan on stand	500	227
5-Pan table top	275	125
5-Pan on stand	350	159
(2) 5-Pan on stand	555	252
10-Pan on stand	469	213
(2) 10-Pan on stand	764	347

When starting installation, check packing materials to make sure loose parts such as the condensate drip tray are not discarded with this material.

Installation

WARNING

THE UNIT MUST BE INSTALLED BY PERSONNEL WHO ARE QUALIFIED TO WORK WITH ELECTRICITY AND PLUMBING. IMPROPER INSTALLATION CAN CAUSE INJURY TO PERSONNEL AND/OR DAMAGE TO THE EQUIPMENT. THE UNIT MUST BE INSTALLED IN ACCORDANCE WITH APPLICABLE CODES.

CAUTION


DO NOT INSTALL THE UNIT WITH THE REAR VENTS BLOCKED OR WITHIN 2 INCHES OF A HEAT SOURCE SUCH AS A BRAISING PAN, DEEP FAT FRYER, CHARBROILER OR KETTLE. TO AVOID DRAINAGE PROBLEMS, LEVEL THE UNIT FRONT TO BACK, AND PITCH SLIGHTLY TO THE FRONT.

CAUTION

EACH UNIT MUST HAVE A SEPARATE GROUND WIRE FOR SAFE OPERATION.

WARNING

TO AVOID DAMAGE OR PERSONAL INJURY, FOLLOW THE WIRING DIAGRAM EXACTLY.



Minimum Clearances: Boilerless steamer requires the following minimum clearances to any surface, combustible or noncombustible.

Right Side	2 inches
Left Side	2 inches
Rear	6 inches

Steam Free Zone: The boilerless steamer can be damaged by steam from external sources. Do not install the steamer over a steam venting drain. Ensure that steam is not present in an area bounded by the footprint of the steamer and a circle 18 inches in radius about the right rear corner of the steamer (see figure at left).

ELECTRICAL SUPPLY CONNECTION

Model	kW Rating	Rated Current Demand Per Cavity (Amperes)				
		208V, 1-Ph	208V, 3-Ph	240V, 1-Ph	240V, 3-Ph	480V, 3-Ph
3-Pan	9	44	25	38	22	11
5-Pan	12	58	34	50	29	15
10-Pan	21	NR	59	NR	51	26

1. Electrical Supply Connection

Current and power demands for each unit are as shown above.

- A. **Panel Removal - Right Side**
Open the wiring and control panel by removing screws from the right side panel. Slide the panel forward and set it aside.
- B. **Supply Voltage**
The unit must be operated at the rated name plate voltage. The name plate can be found on the rear of the unit.
- C. **Phase Selection**
Refer to steamer wiring diagram and element wiring on pages 19 and 20 for wiring information.
- D. **Terminal Block**
The terminal block for incoming power is located at the back of the control compartment. The ground terminal is located in the wiring compartment near the terminal block.
- E. **Supply Wire**
The equipment grounding wire must comply with the National Electrical Code (NEC) requirements. The wiring diagram on the inside of the unit's right side cover gives directions for proper connection of the terminal block jumpers. The wire must be used or the unit will not meet Underwriters Laboratories and NEC requirements. The electric hole is sized for a one-inch conduit fitting.
- F. **Branch Circuit Protection**
Each boilerless steamer, including individual units of stacked models, should have its own branch circuit protection and ground wire.

Installation

WARNING

DO NOT CONNECT THE DRAIN DIRECTLY TO A BUILDING DRAIN. BLOCKING THE DRAIN IS HAZARDOUS.

CAUTION

DO NOT USE PLASTIC PIPE. DRAIN MUST BE RATED FOR BOILING WATER.

IMPORTANT

DO NOT ALLOW WATER TRAPS IN THE LINE. A TRAP CAN CAUSE PRESSURE BUILD-UP IN THE CAVITY, WHICH MAY CAUSE THE DOOR GASKET TO LEAK.

WARNING

DO NOT STACK STEAMERS WHEN LEGS ARE USED.

Steamer Type	NPT Pipe Size Required
3-Pan	1.5"
(2) 3-Pan	2.5"
5-Pan	1.5"
(2) 5-Pan	2.5"
10-Pan	2.0
(2) 10-Pan	2.0"

3. Water Connection(s)

Install a check valve to prevent back flow in the incoming cold water line, as required by local plumbing codes. Water pressure in the line should be between 30 and 60 PSI. If pressure is above 60 PSI, a pressure regulator will be needed. These pressures must provide the 1.5 gallons per minute required for proper steamer function.

A 3/4 inch female NH connector (garden hose type) is used to attach the water supply to the inlet valve. Minimum inside diameter of the water feed line is 1/2 inch. Use a washer in the hose connection. Do not allow the connection to leak, no matter how slowly. Do not over-tighten hose connections.

This equipment is to be installed to comply with the basic plumbing code of the Building Officials and Code Administrators International, Inc. (BOCA) and the Food Service Sanitation Manual of the Food and Drug Administration (FDA).

4. Drain Connection

Level the steamer front to back, and pitch it slightly to the front (maximum 1/4 inch) by adjusting the optional legs or the bullet feet on the optional stand.

There must be a free air gap between the end of the hose and the building drain. The free air gap should be as close as possible to the unit drain. There must also be no other elbows or other restrictions between the unit drain and the free air gap. Install the drain line with a constant downward pitch.

Proper Drain Line Connection: Drain line must have a constant downward pitch of at least 1/4" per foot. Observe local code regarding air gap spacing and drain connections.

5. Factory-Stacked Units

This section is applicable only if you are installing factory-stacked units. Installing stacked steamers is similar to installing a single unit. The steamers are stacked and assembled at the factory and delivered with the water connections and drain hoses required for a single point connection.

A. Water Connection

The same water supply connection is used for both units. At the water inlet valve a 3/4 inch female NH connector (garden hose type) is used for the water supply.

B. Electrical Supply Connection


Separate electrical connections will be required for each steamer to be stacked. Each steamer unit must have it's own branch circuit protection.

C. Drain Connection


Steamers must be leveled front to back, and pitched to the rear (maximum 1/4 inch) by adjusting the bullet feet on the cabinet or stand base. For all factory-stacked steamers, a 2-1/2 inch ID hose is attached to the unit drain. It must be rated for boiling water.

6. Counter-Mounted Units

This section is applicable if the steamer will be mounted to a counter. All four edges of the bottom of the steamer must be sealed with RTV to the counter if the 4 inch legs are not used. Counter must be made of a noncombustible material such as metal or tile.



IMPROPER DRAIN LINE CONNECTION



Initial Start-Up


WARNING
WHEN YOU OPEN THE DOOR, STAY AWAY
FROM STEAM COMING OUT OF THE UNIT.
STEAM CAN CAUSE BURNS.



After the boilerless steamer has been installed, test it to ensure that the unit is operating correctly.

1. Remove all literature and packing materials from the interior and exterior of the unit.
2. Make sure the water supply line is open.
3. Turn on electrical service to the unit. The steamer will not operate without electrical power. Do not attempt to operate the unit during a power failure. NOTE: The door **MUST** be closed for the elements to operate.
4. To turn unit on, press the ON switch on the control panel.
5. When the steam generating reservoir has filled with water, the heaters will begin heating automatically. Within 20 minutes or less the READY light will come on, indicating that the water has reached its standby temperature. When the READY light is displayed, you may take any one of the following steps:
 - a. Push TIMED and set the timer knob to the desired steaming time.
 - b. Push MANUAL for continuous steaming.
 - c. Push STOP to let the unit stay at ready condition.
6. To shut down the unit, press the OFF switch. The steam generating reservoir will then fill with cold water and drain.
7. If the steamer operates as described, the unit is functioning correctly and ready for use.

Operation



A. Controls

Operator controls are on the front right of the unit.

The control panels have the following touch pads and indicator lights:

1. The TIME display shows the remaining cooking time. It displays three dashes in MANUAL mode.
2. The ON/OFF rocker switch gets the unit ready for use or shuts it off.
3. The READY indicator light indicates the unit has achieved the ready temperature.
4. Hour meter records cumulative hours of operation.
5. The FAULT display shows the current fault.

The push button operations:

1. In the STOP mode the steam generator stays at a low boil or ready temperature.
2. When the TIMED button is pushed, the TIMED light will illuminate and time can be set by turning the TIMER knob (cook time can be increased or decreased at any time by turning the timer knob). The unit steams until the timer counts down to zero and the temperature drops to ready. At that time the STOP light illuminates and a beeper sounds.
3. When the MANUAL button is pushed, the unit steams continuously. The MANUAL light will stay illuminated.
4. CANCEL button should be pushed to stop beeping.

Operation

WARNING
WHEN YOU OPEN THE DOOR, STAY AWAY
FROM THE STEAM COMING OUT OF THE
UNIT. THE STEAM CAN CAUSE BURNS.



———— High Float
———— Low Float
———— Empty

B. Operating Procedure

1. Press the ON/OFF rocker to the ON position, (Fi┐) is displayed in the TIME display window. The steam generating reservoir will begin filling, displaying (Fi=) and (Fi≡) as it fills. After initial fill the unit will begin draining displaying (Fi=), refilling displaying (Fi≡), and then begin heating until the READY light comes on (about 15-20 minutes).

2. Load food into pans in uniform layers. Pans should be filled to about the same levels, and should not be mounded.

3. Open the door and slide the pans into the supports. If you will only be steaming one pan, put it in the middle position. Some foods will cause foam. When cooking foods that foam, such as shrimp, put an empty solid 2½" deep pan in the bottom slot of the pan racks.

4. Close the door. When the READY indicator is lit take one of the following steps:

If you want to steam the food for a certain length of time push the TIMED button and set the desired time with the TIMER knob. The timer will automatically run the steamer for the set time and then STOP. A beeper will sound. Push CANCEL to stop beeping.

If you want to steam continuously push the MANUAL button. The unit will continue steaming until stopped.

Push STOP to stop producing steam.

5. To remove pans from cavity open the door. Remove the pans from the steamer using hot pads or oven mitts to protect your hands from the hot pans.

6. To shut off the unit press the ON/OFF rocker switch to OFF, (FL≡) will appear in the timer display. The steam generating reservoir will begin draining, displaying (Fi=) and (Fi≡) as it drains, and refill to the high float twice and finally drain completely and turn off the unit.

NOTE: When filling or draining the steam generating reservoir (≡) will be displayed indicating the water level in the reservoir. (┐) reservoir is empty, (=) low float is satisfied, (≡) high float is satisfied.

NOTE: If a large amount of shrimp is cooked in the unit, foaming will occur because the steam lid actually gets so hot that the shrimp will cook on its surface and the shrimp proteins in the dripping will foam on the surface of the steam lid.

* To avoid this use a catch pan to catch shrimp drippings and proteins to prevent foaming when cooking a large amount of shrimp.

Cleaning

WARNING
DISCONNECT THE POWER SUPPLY
BEFORE CLEANING THE OUTSIDE OF
THE STEAMER.

KEEP WATER AND CLEANING SOLUTIONS
OUT OF CONTROLS AND ELECTRICAL
COMPONENTS. NEVER HOSE OR STEAM
CLEAN ANY PART OF THE UNIT.

AVOID CONTACT WITH ANY CLEANERS,
DELIMING AGENT OR DEGREASER AS
RECOMMENDED BY THE SUPPLIER. MANY
ARE HARMFUL. READ THE WARNINGS AND
FOLLOW THE DIRECTIONS!

EVEN WHEN THE UNIT HAS BEEN SHUT
OFF, DON'T PUT HANDS OR TOOLS
INTO THE COOKING CHAMBER UNTIL
THE FAN HAS STOPPED TURNING.

DON'T OPERATE THE UNIT UNLESS THE
REMOVABLE PARTITION HAS BEEN PUT
BACK IN ITS PROPER LOCATION.

DON'T USE ANY CLEANING AGENT
THAT CONTAINS ANY SULFAMIC
AGENT OR ANY CHLORIDE, INCLUDING
HYDROCHLORIC ACID (HCL). TO
CHECK FOR CHLORIDE CONTENT SEE
ANY MATERIAL SAFETY DATA SHEETS
PROVIDED BY THE CLEANING AGENT
MANUFACTURER.

To keep your boilerless steamer in proper working condition, use the following procedure to clean the unit. This regular cleaning will reduce the effort required to clean the steam generator and cavity.

A. Suggested Supplies

1. Mild detergent
2. Stainless steel exterior cleaner
3. Cloth or sponge
4. Brush with soft bristles
5. Spray bottle
6. Measuring cup
7. Nylon pad
8. Towels
9. Plastic disposable gloves
10. Funnel

B. Procedure

1. Exterior Cleaning
 - a. Prepare a warm solution of the mild detergent as instructed by the supplier. Wet a cloth with this solution and wring it out. Use the moist cloth to clean the outside of the unit. Do not allow freely running liquid to touch the controls, the control panel, any electrical part, or any louver on the rear panels.
 - b. To remove material which may be stuck to the unit, use a fiber brush or a plastic or rubber scraper with a detergent solution.
 - c. Stainless steel surfaces may be polished with a recognized stainless steel cleaner.
2. Interior Cleaning
Daily cleaning must be done in order to enhance the performance and prolong the life of your boilerless steamer.

IMPORTANT
DO NOT USE ANY METAL MATERIAL
(SUCH AS METAL SPONGES) OR METAL
IMPLEMENTS (SUCH AS A SPOON, SCRAPER
OR WIRE BRUSH) THAT MIGHT SCRATCH
ANY STAINLESS STEEL SURFACE.
SCRATCHES MAKE THE SURFACE HARD
TO CLEAN AND PROVIDE PLACES FOR
BACTERIA TO GROW. DO NOT USE STEEL
WOOL, WHICH MAY LEAVE PARTICLES
EMBEDDED IN THE SURFACE,
WHICH COULD EVENTUALLY CAUSE
CORROSION AND PITTING.




Cleaning

WARNING
ALLOW THE STEAMER TO COOL
COMPLETELY BEFORE CLEANING. HOT
SURFACES CAN CAUSE SEVERE BURNS.

WARNING
FAILURE TO CLEAN THE STEAMER AS
SPECIFIED COULD NEGATIVELY IMPACT
THE PERFORMANCE OF THE STEAMER.

FLOAT PROBE ORIENTATION



C. Cleaning Steps

STEP 1 - Press OFF switch to turn steamer OFF and open steamer door.

STEP 2 - CAUTION: allow the steamer to cool completely before cleaning.

STEP 3 - Remove steam lid by grasping the two tabs located on the lid front and sliding pan forward.

STEP 4 - Remove left pan rack by lifting rack up and pulling away from cavity wall.

STEP 5 - Remove right fan shroud and rack assembly by lifting rack up and pulling away from cavity wall.

STEP 6 - Clean steam lid, left pan rack and rack/ shroud assembly to remove food soils. These three parts may be cleaned in a dishwasher.

STEP 7 - Use a mild detergent to wipe down the entire steamer cavity to remove food and scale particles. Carefully clean float probes if food residue or loose scale is present. A thin layer of tightly bound scale is normal and will not affect steamer performance. If scale is excessive, then refer to deliming instructions below.

STEP 8 - Remove drain strainer and clean thoroughly to remove any build-up of debris.

STEP 9 - Replace pan racks and steam lid. Steamer is now cleaned and ready to use.

D. Deliming Instructions

When using a Water Treatment System use vinegar as a deliming agent. Commercial delimer may be used to remove excessive scale build-up.

STEP 1 - After following all cleaning steps 1 through 7 listed above, turn steamer on and allow water to enter steamer cavity.

STEP 2 - Pour 1 cup of vinegar or delimer into steamer cavity and shut door.

STEP 3 - Set steamer timer to 30 minutes and allow steam cleaning to occur.

STEP 4 - After 30 minutes cleaning cycle is complete, turn steamer OFF and allow to cool completely.

STEP 5 - Open steamer door and wipe down the entire steamer cavity to remove loosened scale particles. Carefully clean float probes if loose scale is present.

STEP 6 - Replace pan racks and steam lid. Steamer is now cleaned and ready to use.

Maintenance

The boilerless steamer is designed for minimum maintenance and no user adjustments should be necessary. Certain parts may need replacement after prolonged use. If there is a need for service, only Authorized Service Agents should perform the work.

If steam or condensate is seen leaking from around the door, take the following steps:

1. Check the door gasket. Replace it if it is cracked or split.
2. Inspect the cooking chamber drain to be sure it is not blocked.
3. Adjust the door latch pin to allow for changes that might occur as the gasket ages.
 - a. Loosen the lock nut at the base of the latch pin, then turn the latch pin 1/4 turn clockwise, and tighten the lock nut.
 - b. After adjustment, run the unit to test for further steam leakage.
 - c. If there is still leakage, repeat the adjustment
 - d. Continue adjusting the pin clockwise until the door fits tightly enough to prevent leakage. The hinge may also be adjusted.


Troubleshooting

Your boilerless steamer is designed to operate smoothly and efficiently if properly maintained. However, the following is a list of checks to make in the event of a problem. Wiring diagrams are furnished inside the service panel. If an item on the check list is marked with (*), it means that the work should be done by an Authorized Service Agent.


SYMPTOM	WHO	WHAT TO CHECK
Fault Display 1 or 2.	User	a. Clean floats in unit / Check float probe orientation b. Be sure water supply is adequate to run steamer(s) during normal operation.
No power.	User	a. Check wall circuit breaker. b. Disconnect power, then check fuses inside steamer.* c. Call service technician.
Unit overfills with water at start up.	User	a. Clean floats in unit / Check float probe orientation. b. Clean drain strainer. c. Call service technician.
Steamer does not fill with water.	User	a. Is the ON switch depressed? b. Is the water supply connected? c. Is the water turned on? d. Is the water supply hose kinked or obstructed? e. Check for low water pressure (less than 30 PSI) or low water flow (less than 1.5 gpm). f. Is the screen at the water connection clogged?
"Door" Shown in Time Display Window.	User	a. Is the steamer door securely closed?
No steam.	User	a. Is the ON switch depressed? b. Is the water supply connected? c. Is the water turned on? d. Is steamer door completely closed?
Fault Display 7.	User	a. The component cooling fan may not be operating. The display may come on for several minutes during normal operation. If it stays on for more than 30 minutes, call service technician. Unit may be used for cooking, while waiting for service.
Any unusual operation.	User	a. Press OFF switch to turn steamer off. Momentarily turn circuit breaker off and then turn unit back on.
Door pops open.	User	a. Ensure drain and vent are not plugged. No more than two units should be attached to a single drain line. b. Check door pin adjustment per above. c. Call service technician.
Fault Display 6.	User	a. Wait 30 minutes for unit to cool down. b. Call service technician.

Parts List

Boilerless Steamer




Parts List Boilerless Steamer




Parts List


Boilerless Steamer



Parts List Boilerless Steamer



Parts List Boilerless Steamer



Parts List

Boilerless Steamer


To order parts, contact your Authorized Service Agent. Supply the model designation, serial number, part description, part number, quantity, and when applicable, voltage and phase.

Key	Description	Part #
1	TERMINAL BLOCK	070185
2	CAPACITOR, 3MF	096813
3	TRANSFORMER 208/240V PRIMARY/ 24V SECONDARY, 75VA	121716
4	CONTACTOR	145081
5	FUSEHOLDER	096809
6	FUSE	119823
7	GROUND TERMINAL (3-PAN/5-PAN)	106412
7	GROUND TERMINAL (10-PAN)	129714
8	TERMINAL BLOCK (3-PAN/5-PAN)	003888
8	TERMINAL BLOCK (10-PAN)	002577
9	WATER VALVE	071235
10	MUFFIN FAN	153505
11	DRAIN BOX (3-PAN/5-PAN)	150659
11	DRAIN BOX (10-PAN)	150661
12	HI-LIMIT	144484
13	THERMOSTAT (DRAIN BOX)	145248
14	DRAIN VALVE	071234
15a	CONDENSATE CUP	150628
15b	GASKET, CONDENSATE CUP	142613
16	READY THERMOSTAT	147285
17	FLOAT PROBE	149880
18	DOOR SWITCH	096857
19	POWER SWITCH	160920
20	DOOR ASSEMBLY, COMPLETE (3-PAN)	130858
20	DOOR ASSEMBLY, COMPLETE (5-PAN)	125922
20	DOOR ASSEMBLY, COMPLETE (10-PAN)	143874
21	KNOB	160921
22	CONTROL BOARD	160648
23	TOROID (480V ONLY)	119833
24	MOTOR ASSEMBLY	146880
25	RELAY BOARD	160649
26	ELEMENT 208V 1000W (3-PAN/5-PAN)	148553
26	ELEMENT 240V 1000W (3-PAN/5-PAN)	148554
26	ELEMENT 277V 1000W (3-PAN/5-PAN)	148552
26	ELEMENT 208V 1000W (10-PAN)	148444
26	ELEMENT 240V 1000W (10-PAN)	148551
26	ELEMENT 277V 1000W (10-PAN)	148443
27	TOP PANEL (3-PAN/5-PAN)	150637
27	TOP PANEL (10-PAN)	149444


Key	Description	Part #
28	FRONT PANEL OVERLAY (3-PAN)	170155
28	FRONT PANEL OVERLAY (5-PAN/10-PAN)	170156
29	DOOR LATCH PIN	078914
30	DOOR PIN LOCK NUT	003823
31	STEAM LID (3-PAN/5-PAN)	149299
31	STEAM LID (10-PAN)	149452
32	CAVITY FAN	096790
33	LEFT PAN RACK (3-PAN)	149883
33	LEFT PAN RACK (5-PAN)	149872
33	LEFT PAN RACK (10-PAN)	145642
34	DOOR HANDLE	070123
35	DOOR GASKET (3-PAN)	124849
35	DOOR GASKET (5-PAN)	125907
35	DOOR GASKET (10-PAN)	143879
36	TERMINAL BLOCK 480V ONLY (10E)	003888
X	MOTOR SHAFT SEAL	096868
X	BLOWER COVER (3-PAN)	149387
X	BLOWER COVER (5-PAN)	149313
X	BLOWER COVER (10-PAN)	149451
X	RIGHT PAN RACK (3-PAN)	141571
X	RIGHT PAN RACK (5-PAN)	140157
X	RIGHT PAN RACK (10-PAN)	145721
X	DRIP TRAY (3-PAN/5-PAN)	094151
X	DRIP TRAY (10-PAN)	145520
X	LEFT SIDE PANEL (3-PAN)	149229
X	LEFT SIDE PANEL (5-PAN)	149233
X	LEFT SIDE PANEL (10-PAN)	149446
X	RIGHT SIDE PANEL (3-PAN)	149231
X	RIGHT SIDE PANEL (5-PAN)	149235
X	RIGHT SIDE PANEL (10-PAN)	149448
X	FLOW REDUCER, CONDENSATE	147371
X	FLOW REDUCER, FILL	144481
X	HARNESS, CONTROL TO RELAY BOARD	160884
X	HARNESS, REAR (3-PAN/5-PAN)	160883
X	HARNESS, LOW VOLTAGE (3-PAN/5-PAN)	160880
X	HARNESS, FOWARD (3-PAN/5-PAN)	160882
X	HARNESS, STEAMER HIGH VOLTAGE (3-PAN/5-PAN)	160874
X	HARNESS, HIGH VOLTAGE (3-PAN/5-PAN)	153486
X	JUMPER, VOLTAGE SELECT	123124
X	HARNESS, STEAMER 480V ONLY	153118
X	HARNESS, REAR (10-PAN)	153843
X	HARNESS, LOW VOLTAGE (10-PAN)	153841
X	HARNESS, FORWARD (10-PAN)	153842

x- Item not depicted/called out in drawing or photograph

Wiring Diagram (3-Pan/5-Pan)



Wiring Diagram (10-Pan)



Service Log

Model No:	Purchased From:
Serial No:	Location:
Date Purchased:	Date Installed:
Purchase Order No:	For Service Call:

[illegible]



BLODGETT OVEN COMPANY

www.blodgett.com

**44 Lakeside Avenue, Burlington, Vermont 05401 USA
Telephone: 866-518-3977**