

Operating Instructions

for the MEC-110 with ENHANCED SMS



COMMERCIAL COOKING APPLIANCES ALSO CLASSIFIED BY ETL IN ACCORDANCE WITH NSF STANDARD NO. NSF 169. DESIGN EVALUATED BY ETL IN ACCORDANCE WITH ANSI/ISA 221.23 AND CAN/CSA 1-14.6-M78.

**10-Product Cooking Controller
 Model 231-60210-02**

This document contains confidential information. The dissemination, publication, copying, or duplication of this document or the software described herein without prior written authorization is strictly prohibited.

229-51339 Rev A
 Printed in the USA
 © 2007 FAST

(FAST.)[®]
the time is right.

Toll-Free Technical Support
 24 Hours A Day, 365 Days A Year
 (from the U.S., Canada and the Caribbean)
1-800-243-9271

Notices

(FAST.) is not liable for any use of product not in accordance with (FAST.)'s installation and operating instructions.

Before using this equipment, or for any questions on the operation of the appliance, consult and follow all instructions and safety warnings found in the appliance operator's manual supplied from the manufacturer of the appliance.

Not all features are available on some models.

**Controller
Operating
Environment**

The solid state components in this controller are designed to operate reliably in a temperature range up to 158°F/70°C. Before installing this controller, it should be verified that the ambient temperature at the mounting location does not exceed 158°F/70°C.

**Cleaning the
Controller**

Using a clean damp cloth, wipe down your controller daily using a commercial quality foodservice-approved detergent.

Do not allow oil to build up on any part of the controller.



NEVER use chemical or abrasive cleaners on your controller. The controller's overlay may be damaged.

Installation


Tools Required

- Straight Screwdriver
1. Turn appliance power OFF.
 2. Connect the wire harness to the controller.
 3. Attach the 2 provided tinnerman nuts to the controller. Be sure to line up the holes.
 4. Hold the controller against the front panel.
 5. Secure the controller to the appliance using the 2 provided screws.

Programming Codes

Product Programming 1 7 2 4
 System Programming 3 2 2 8

Controller Features



- 1 **LARGE LED DISPLAY:** 8-character, 14-segment. Displays programming and cook cycle information.
- 2 **SERVICE WINDOW:** Locate the controller's serial number and tech support phone number easily.
- 3 **INDICATOR LIGHTS:** lit when there's an active cook cycle and in programming mode.
- 4 **PRODUCT KEYS:** Press to start a cook cycle. Also used in programming. **REPLACEABLE MENU STRIP:** Make menu changes quickly and easily.
- 5 **PROGRAMMING CENTER:** Easy cell phone-like programming. Access programming mode and change cooking parameters.
- 6 **FEATURE KEYS:** Used to access programming functions and controller features; keys will vary by model.
- 7 **SCK LINK:** Signifies that your control is communications-capable.

Features Explained

Programmable Action Alarms

Up to three action alarms can be programmed for each product key. An action alarm alerts the operator to perform some action at a pre-programmed time.

Programmable Appliance Type

A specific type of appliance; i.e., gas, electric or generic can be programmed into the controller.

Energy Saving Manual Setback

Setback, an **energy-saving feature**, will lower the temperature of the oil after a pre-determined amount of inactive time (1 to 59 minutes). Temperature is programmable from 200-300°F (93.3-148.8°C). Enter setback mode by pressing the SETBACK key. The controller will display *COOL* or *SETBACK* and will control the appliance to the programmed setback temperature.

Fahrenheit or Celsius Temperature Display

The controller can be configured to display the temperature in degrees Fahrenheit or Celsius (accessible through System Programming mode).

Programmable (FAST.Flex)TM Timing Mode

Flex or straight timing can be configured for each stage on each product key. To insure consistent, high-quality food product, **flex time** will adjust the actual cook time taking into consideration the temperature variation due to load size, initial product temperature, product moisture content, and other factors affecting the cook cycle. If cooking by **straight time**, the controller will cook only for the specified time without adjusting for these variances.

Programmable Filter/Polish Mode

To aid in extending the life of your oil, this Meridian Controller will alert the operator at pre-programmed times or number of products cooked when it is time to filter the oil by displaying the *FILTER* prompt. If the prompt is flashing, cooking can still be performed. If the prompt is solid, the filter procedure must be executed. A filter can also manually be forced at any time of the day.

Programmable Filter Lockout Cycle Count

Ensure good-tasting food is always served to your customers by requiring the oil be filtered after "x" amount of times. Any product key with Filter Lockout programmed will cease to operate until the oil is filtered. A filter lockout cycle count (valid range is 0 to 99) can be programmed for each product key. To disable filter lockout, enter 0 for the filter lockout count.

Programmable Global Filter Lockout

A single filter lockout cycle count can be programmed to apply globally to all product keys.

Programmable Hold Time Linking

Each product key can be linked to an independent hold timer, or multiple product keys can be linked to a single hold timer.

Features Explained

CONTINUED

Programmable Hold Times

Product key hold times can be programmed to track product quality through a specified holding period. Hold time countdown begins as soon as the cook cycle is complete. The controller will sound an alarm when the product's hold time has expired alerting the operator to discard the product.

Automatic Least Hold Display

Product with the least amount of cook time remaining will be shown in the display. Pressing and hold the SCAN key allows you to view each active product's remaining cook time.

Melt Cycle

If the vat temperature is below the Melt Limit Temperature and the controller is ON, it will control the melting of the oil.

Programmable Operating Mode

The controller can be programmed to operate as either a controller or timer.

Programmable Pressure Valve

The pressure valve state for each stage on each product key can be programmed. The valve can be open or closed.

Note: The valve is normally open when not cooking.

Programmable Stage Temperatures

Cook temperatures for each stage on each product key can be programmed. The valid temperature range is 200°F to 400°F (93.3°C to 204.4°C).

Programmable Stage Times

Cook times for each stage on each product key can be programmed. The controller is programmable in minutes (up to 99) and seconds (up to 59) and allows up to ten stages per product key.

Note: Multiple cook starts are not allowed if a product key has more than one stage programmed.

Operating the Controller



Start a Cook Cycle

Press any product key to start a cook cycle. If the key is programmed, the correct cooking time will be displayed and will immediately start to count down in minutes and seconds. *DONE* will display when the cook cycle has ended.

The pressure solenoid will also close if programmed to do so, or a basket lift will lower if so equipped.

If *DONE* is displayed immediately and the unit starts to signal, the product key being pressed is not programmed.

Stop a Cook Cycle

Press and hold an active product key for 3 seconds. Timing will stop.

Respond to a DONE Alarm

Cancel the signal by pressing the same product key used to start the cook cycle.

Action Alarms

If the controller is programmed for action alarms, they will signal at a preset time during the cooking cycle. The signal, a dual-rhythm beeping, will last 5 seconds and then self-cancel. The display will flash the action alarm time and the controller will start counting toward 0:00.



Holding Timers

If the controller is programmed with holding times, they will automatically start counting upon expiration of the cooking cycle.

When there are active hold times, the HOLD indicator light will be lit.

To **View All Active Hold Times**, press and hold the HOLD key. Upon expiration, the timer will display *HOLD* and pulse with an audible tone.

To Cancel, press the HOLD key.

The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

229-51339 Rev A
© 2007 FAST

24/7 Tech Support:
1-800-243-9271

Operating the Controller


CONTINUED



Boil Mode

CAUTION: THE USER MUST CONSULT AND FOLLOW THE APPLIANCE MANUFACTURER'S GUIDELINES FOR CLEANING AND BOILING OF THE FRY VATS. If your fryer manufacturer recommends this procedure, the boil function accurately maintains the fryer temperature at 190°F (88°C) to assist in the cleaning of fry vats. To start the boil process, turn the appliance OFF. Empty the fry vat of oil. Once the vat is emptied of oil and refilled with cold water, the controller and fryer may now go into boil mode.

The fry vat must be below a temperature of 255°F (124°C) to enter the boil mode.



NOTE: The fry vat will maintain a temperature of 190°F (88°C) to allow the boil function to be performed.

To Enter Boil Mode: Press and hold the P key for 3 seconds. *PROGRAM* will be displayed.

Press the up or down arrow keys until *BOIL* is displayed, then press the P key. The feature is now activated and *BOIL* will be displayed.

To Exit Boil Mode, press and hold the P key for 3 seconds. *PROGRAM* will be displayed.

Press the up or down arrow keys until *BOIL* is displayed, then press the P key. This will exit you from the boil mode. If the controller has an ON/OFF key, you can also exit by pressing OFF and then ON.

Turn the appliance OFF. The controller will no longer display *BOIL*. Empty the water from the vat and wipe away all remaining water. Once dry, refill the vat with oil.



CAUTION: Refill the vat with oil **ONLY** when it is completely dry.

Fill Mode




If the controller is programmed for filter lockout, *FILTER* will appear in the display after the pre-programmed number of cook cycles allowed. The controller will stop operating until the fryer is filtered. After filtering, the display will read *FILL*. **At this time, the fryer MUST be refilled with oil.** When this step is complete, press ENTER to resume normal operations.

Operating the Controller

CONTINUED

Product Counts



To Check Product Counts: press and hold the P key for 3 seconds. *COUNTS* will be displayed.

Press the P key. *GLOBAL* will be displayed then the total number of cook counts will be shown.

Press the P key. *FILTRCNT* will be displayed then your total filter count will be shown.

Press the P key. *DISPCNT* will be displayed then your total disposal count will be displayed.

Press the P key. *TOTALX10* will be displayed then your total x 10 global count will be shown. Then press the P key.


To Exit Product Counts: *COUNTS* will be displayed. Press the up arrow key. *EXIT* will be displayed. Press the P key. The controller will exit programming mode.

Filter / Polish

When filtering is performed, the oil must be dumped from the vat for 3 minutes. The filter countdown will then begin at 7 minutes, at which time the Polish should be performed. At the end of polishing operation, the display will show *FILL*. Return the oil to the vat.

Press the ENTER/EXIT FILTER key to clear the message and go into an idle state. The oil will be heated to the correct pre-programmed temperature.

Force A Filter



To Force A Filter at any time of the day: press and hold the SCAN and ENTER/EXIT FILTER keys at the same time for 3 seconds. *FILTER* will be displayed and an alarm will be heard.

Press the ENTER/EXIT FILTER key to start the filtering sequence.

The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

229-51339 Rev A
© 2007 FAST

24/7 Tech Support:
1-800-243-9271

Display Descriptions

LO

Controller is in Operating Mode. Actual vat temperature is more than 10 degrees below the programmed vat temperature.

Controller is in Operating Mode. Actual vat temperature is within the proper cooking temperature range. The vat is ready to start a cook cycle.

DROP

READY

HI

Controller is in Operating Mode. The actual vat temperature is more than 40 degrees above the highest programmed vat temperature. A continuous audible alarm will sound.

PROBE

Controller's probe is either open or shorted. Display will be accompanied with an audible alarm if shorted. Check or replace the probe.

2:30

Controller is in Operating Mode and a cook cycle is in progress.

DONE

Controller is in Operating Mode and a cook cycle has been completed.

CODE

Controller is waiting for a pass code to be entered.

PRODUCT

Controller is in Product Key Programming Standby mode.

TIME 1

Stage cooking time (1-10) is displayed.

TEMP 1

Stage cooking temperature (1-10) is displayed.

TIMING 1

Stage timing mode (1-10) (flex or straight) is displayed.

ALTIME1

Action alarm status is displayed.

FILL

After fryer is filtered, this display prompts you to refill the fryer with oil.

SYSTEM

Controller is in System Programming Standby Mode.

TEMPUNIT


Controller is in Fahrenheit or Celsius Programming Mode.

APPLIANC

Controller is in Appliance Type Programming Mode.


Product Key Programming

RECIPE 1724 STORE EMPLOYEE

 18 button controllers have two displays that show a full line of information; for example:
TIME **2:00**

10 button controllers have a single, dual-purpose display that will alternate information; for example:
TIME then **2:00**

ENTER PROGRAMMING MODE.
 Press and hold the P key for 3 seconds.



COUNTS
 Press the down arrow key.



PROGRAM
 Press the P key.




CODE
 Type in 1 7 2 4 using the product keys. Press the P key.




RECIPE
 Press the P key. All product key LEDs will light up.



PRODUCT PROGRAM A PRODUCT KEY. Press the product key you want to program. Press the P key.




 Some controllers may have different options listed.

Depending on model, you can either press the P key to change all programmable settings or you can scroll using the arrow keys to any of the specific options.

ALL
 Press the P key.



NAME
XXXXXXXX
SET PRODUCT DISPLAY NAME. NAME will be displayed then the actual product name. Use the up and down arrow keys to scroll through the library. Press the P key to lock in your choice.




The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

Product Key Programming

CONTINUED


TIME 1
XX:XX

SET COOK TIME. Actual set time will be displayed. To change, press toggle clear to change the time to zero. Type in a new time using the product keys. Press the P key.



TEMP 1
XXXX

SET COOK TEMPERATURE. Actual set temperature will be displayed. To change, press toggle clear to change the temperature to zero. Type in a new temperature using the product keys. Press the P key.



TIMING 1
STRAIGHT
FLEX

SET TIMING MODE. Use the left and/or right arrow keys to choose Straight or Flex. Press the P key.



*NOTE: On some models, each product key can be programmed with up to 10 stages. If no additional stages are required at this point, set the time to zero. Press the P key to continue to Action Alarm.

TIME 2
XX:XX


SET COOK TIME #2. Actual cook time will be displayed. To change, press toggle clear to change the time to zero. Type in a new time using the product keys. Press the P key. Repeat previous steps.*



Some models have up to 3 action alarms.


ALM TIME 1
XX:XX

SET ACTION ALARM. Actual alarm time 1 will be displayed. To change, press toggle clear to change the time to zero. Type in a new time using the product keys. Press the P key.



ALM NAME 1
XXXXXXXX

SET ACTION ALARM NAME. ALMNAME1 will be displayed, then the actual action alarm name. Use the up and down arrow keys to scroll through the library. Press the P key to either go to next action alarm name, or continue through programming.



ALM CNCL 1
AUTO
MANUAL

SET ACTION ALARM CANCEL MODE. ALMCNCL1 will be displayed, then the action alarm mode. Use the left and right arrow keys to choose AUTO or MANUAL. Press the P key to save and continue.



ALM TONE 1
XXXXXXXX

SET ACTION ALARM TONE. ALMTONE1 will be displayed, then the action alarm tone: *DOUBLE, SHORT, MEDIUM, LONG, LONG SHT, NONE*. Use the left and right arrow keys to choose an alarm tone. Press the P key to save and continue.



Product Key Programming

CONTINUED


HOLD
YES
NO

SET HOLD. Hold time mode will be displayed. To change, use the left and right arrow keys to choose YES or NO. Press the P key to save and continue.



WEIGHT
X

SET WEIGHT. WEIGHT will be displayed, then a number. To change, press toggle clear to change the number to zero. Type in a new weight (1-99) using the product keys. Press the P key to continue.



ALL

EXIT PROGRAMMING MODE. Press the up arrow key.




EXIT

Press the P key.



PRODUCT

Either press another product key to program and repeat the programming instructions, or exit by pressing the up arrow key.



EXIT

Press the P key.



RECIPE

Press the up arrow key.



EXIT

Press the P key.



READY

You have now EXITED Product Key Programming Mode and can operate the controller.

The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

System Programming

SYSTEM 3228 STORE MANAGER

ENTER SYSTEM PROGRAMMING MODE.
Press and hold the P key for 3 seconds.



COUNTS
Press the down arrow key.



PROGRAM
Press the P key.



CODE
Type in 3 2 2 8 using the product keys. Press the P key.



SYSTEM
Press the P key.



APPLIANCE
GAS
ELEC
SPC

SET APPLIANCE MODE.
Use the left and/or right arrow keys to choose GAS, ELECTRIC or SPECIAL. Press the P key.



LANGUAGE
ENGLISH
OTHER
SET LANGUAGE.
LANGUAGE will be displayed. To change, use the left and right arrow keys to choose ENGLISH or OTHER. Press the P key to save and continue.



CTRLTYPE
TEMPCTRL
TIMECTRL
SET CONTROL TYPE. Use the left and/or right arrow keys to choose TEMPERATURE or TIME Control. Press the P key.




TONEVOL
SET TONE VOLUME. Use the left and/or right arrow keys to choose 1, 2, 3, 4 or NONE. Press the P key.




TEMPUNIT
F
C
SET TEMPERATURE SCALE. Use the left and/or right arrow keys to choose Fahrenheit (F) or Celsius (C). Press the P key.



PREHEAT
HIGH
LOW
SET PREHEAT MODE. Use the left and/or right arrow keys to choose HIGH or LOW. Press the P key.



SETBTIME
XX:XX
PROGRAM SET BACK TIME. Actual set time will be displayed. To change, press toggle clear to change the time to zero. Type in a new time using the product keys. Press the P key.




System Programming

CONTINUED

SETBTEMP

XXXX

PROGRAM SETBACK TEMPERATURE. Actual set temperature will be displayed. To change, press toggle clear to change the temperature to zero. Type in a new temperature using the product keys. Press the P key.




CNTTYPE

PCS

LBS


SET COUNT TYPE. Use the left and/or right arrow keys to choose PCS (PIECES) or LBS (POUNDS). Press the P key.



FILTRCNT

X


SET GLOBAL FILTER COUNT. Actual filter count will be shown (0-999), based on pieces or pounds. To change, press toggle clear to change the count to zero. Type in a new filter count using the product keys. Press the P key.



DISPCNT

X


SET DISPOSAL COUNT. (Enter maximum number of pieces or pounds prior to prompt for disposal.) To change, press toggle clear to change the count to zero. Type in a new disposal count using the product keys. Press the P key.



FLTRTIME

XX:XX

SET POLISH OIL TIME. Previously set time will be displayed. To change, press toggle clear to change the time to zero. Type in a new time using the product keys. Press the P key.



FILTER

X

FILTERING MODE. Previously set filter mode will be displayed. Use the left and/or right arrow keys to toggle choices. Press the P key.



FORCE

When **FORCE** is displayed, the controller will not allow you to start any timing cycles.


PROMPT

When **PROMPT** is displayed, the controller will allow normal operation of fryer until the ENTER function key is pressed.

FC/DRY

X


SET NUMBER OF FILTERS PER DAY. Use the left and/or right arrow keys to choose 0, 1, 2 or NONE. Press the P key.



FC/TIME

XX:XX


SET FILTER COUNT TIME PROMPT. Use the left and/or right arrow keys to set time elapsed since last filter prompt (1-12 hours in 1 hour increments). Press the P key.



FLTDELAY

XX:XX

FILTER DELAY. Use the left and right arrow keys to set :00-4:00 hours. Press the P key.



The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

System Programming

CONTINUED

COOKUNIT

MM:SS
HH:MM

SET COOK UNIT. Use the left and/or right arrow keys to choose Minutes/Seconds or Hours/Minutes. Press the P key.



HOLDUNIT

MM:SS
HH:MM


SET HOLD UNIT. Use the left and/or right arrow keys to choose Minutes/Seconds or Hours/Minutes. Press the P key.



INST ON

XX:XX

SET INSTANT ON TIME. To change, press toggle clear to change the time to zero. Type in a new time using the product keys (0-99:99). Press the P key.



SYSTEM

EXIT SYSTEM PROGRAMMING MODE. Press the up arrow key.



EXIT

Press the P key.



READY

You have now EXITED System Programming Mode and can operate the controller.

Offset Programming

SYSTEM 3228 STORE MANAGER



Offset Temperature can be set from 20 to -20F (-6.6 to -28.8C).

ENTER OFFSET PROGRAMMING MODE.

Press and hold the P key for 3 seconds.



COUNTS

Press the down arrow key.



PROGRAM

Press the P key.



CODE

Type in 3 2 2 8 using the product keys. Press the P key.



SYSTEM

Press the down arrow key UNTIL Offset is displayed.



OFFSET

Press the P key.




Offset Programming

CONTINUED

XXF

Use the product keys to enter a new offset temperature. to change from negative to positive, use the left and right arrow keys. Press the P key.



OFFSET

EXIT OFFSET PROGRAMMING MODE. Press the down arrow key until EXIT appears.



EXIT

Press the P key.



READY


You have now EXITED System Programming Mode and can operate the controller.

Programming Custom Product and Action Alarm Names to the Library

SYSTEM 3228 STORE MANAGER

ENTER LIBRARY PROGRAMMING MODE.

Press and hold the P key for 3 seconds.



COUNTS

Press the down arrow key.




PROGRAM

Press the P key.



CODE

Type in 3 2 2 8 using the product keys. Press the P key.



SYSTEM

Press the down arrow key to select either PRODLIBR OR ALRMLIBR.



PRODLIBR


ALRMLIBR

Choose either PRODLIBR (Product Library) or ALRMLIBR (Action Alarm Library) by pressing the P key.



-

A flashing dash will be displayed. Press the SCAN key and use the product keys to spell a new word. Press the right arrow key to advance to the next character position.



AB

Continue spelling the word. When done, press the P key.



ADD

TO SAVE WORD, press P again. Skip to Exit Library Programming.



TO CANCEL OR MODIFY, see next step.

The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

229-51339 Rev A
© 2007 FAST

24/7 Tech Support:
1-800-243-9271

Programming Custom Product and Action Alarm Names to the Library

CONTINUED

ADD

CANCEL

MODIFY

TO CANCEL OR MODIFY WORD, press the left or right arrow keys to select CANCEL or MODIFY.



IF YOU CHOOSE CANCEL:

CANCEL

Press the P key to EXIT and cancel the word.



IF YOU CHOOSE MODIFY:

MODIFY

Press the SCAN key to go back and modify the word.



PRODLIBR

ALRMLIBR

EXIT LIBRARY PROGRAMMING. Press the up or down arrow keys until display reads EXIT.



EXIT

Press the P key.



READY

You have now EXITED System Programming Mode and can operate the controller.

Troubleshooting

PROBLEM	CAUSE	SOLUTION
No Power	Circuit breaker OFF	Check and reset.
	Appliance not plugged in	Plug in cord.
	Defective 24VAC transformer	Replace transformer. Replace controller.
No Sound	Inoperable speaker	Replace controller.
Button Problem	Frozen key	Unplug controller. Hold down the TOGGLE/CLEAR key as you plug controller back in.
	Inoperable key	Replace controller.
PROBE is Displayed	Defective temperature probe	Replace temperature probe
	Probe not plugged in	Plug in probe.
Reading Wrong Temperature	Defective temperature probe	Replace temperature probe.
Not Heating	Defective element, relay, contactor or gas valve	Replace defective part.
	Defective controller	Replace controller.

Parts & Accessories

DESCRIPTION	(FAST.) PART NUMBER
Sheet Metal Bezel	214-50291
Slotted Round Head Screw, Black, 1/4-20 x 3/4"	150-10202
Tinnerman Spring Nut 1/4-20	150-11025

The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

229-51339 Rev A
© 2007 FAST

24/7 Tech Support:
1-800-243-9271

Index

- Cleaning the Controller 2
- Controller Operating Environment 2
- Display Descriptions 9
- Features 3
- Features Explained 4-5
- Installation 3
- Notices 2
- Operating the Controller
 - Action Alarms 6
 - Boil Mode 7
 - Done Alarm 6
 - Fill Mode 8
 - Holding Timers 7
 - Product Counts 8
 - Start a Cook Cycle 6
 - Stop a Cook Cycle 6
 - View All Active Hold Times 7
- Programming Codes 3
- Programming: (LIBRARY) Store Manager
 - Enter Library Programming 16
 - Exit Library Programming 17
- Programming: (PRODUCT) Store Employee
 - Action Alarm 11
 - Action Alarm Name 11
 - Action Alarm Cancel Mode 11
 - Action Alarm Tone 11
 - Cook Temperature 11
 - Cook Time 11
 - Enter Programming Mode 10
 - Exit Programming Mode 11
 - Filter Count 12
 - Hold Time 11
 - Hold Time Mode 12
 - Product Display Name 10
 - Product Key 10
 - Sensitivity 12
 - Timing Mode 11
 - Weight 12
- Programming: (SYSTEM) Store Manager
 - Appliance Mode 13
 - Control Type 13
 - Cook Unit 15
 - Count Type 14
 - Disposal Count 14
 - Enter System Programming 13
 - Exit System Programming 15
 - Filter Count Time 14
 - Filter Delay 14
 - Filtering Mode 14
 - Global Filter Count 14
 - Hold Unit 15
 - Instant On Time 15
 - Language 13
 - Number of Filters Per Day 14
 - Polish Oil Time 14
 - Preheat Mode 13
 - Set Back Temperature 14
 - Set Back Time 13
 - Temperature Scale 13
 - Tone Volume 13
- Programming: OFFSET
 - Enter Offset Programming 15
 - Exit Offset Programming 16
- Support
 - Customer Service and Technical Assistance 20
 - Service Exchange Program 20
 - Parts & Accessories 18
 - Troubleshooting 18
 - Warranty 20

(FAST.)[®]

Food Automation - Service Techniques, Inc.
905 Honeyspot Road
Stratford, Connecticut 06615-7147 USA

Phone: +1-203-377-4414

Sales: 1-800-FASTRON

Fax: +1-203-377-8187

International Callers: +1-203-378-6860

www.fastinc.com

Toll-free technical support 24/7 from the U.S., Canada,
and Caribbean:
1-800-243-9271

International offices are located in:

United Kingdom

31 Saffron Court
Southfields Business Park
Basildon Essex SS15 6SS
England
Phone: +44-0 1268-544000
Fax: +44-0 1268-544500

Asia/Pacific


1803, 18F, No 922 Hengshan Rd
Shanghai 200030,
China
Phone: +86 13916854613

#11-359, BLK 217, Bukit Batok ST 21
Singapore 650217
Phone: +65 98315927
Fax: +65 66658462

The unauthorized use or duplication of the software described herein, or this material, is strictly prohibited.

229-51339 Rev A
© 2007 FAST

24/7 Tech Support:
1-800-243-9271



229-51339

Customer Service and Technical Assistance

Our customer service department is available for orders and questions Monday through Friday between the hours of 8 AM and 5 PM EST. Call us toll-free at **1-800-FASTRON** (800-327-8766) if you're in the US, Canada or the Caribbean, or at 203-378-6860 if you're outside of these areas.

Toll-free technical assistance is available 24 hours a day, 365 days a year by calling **1-800-243-9271** (from the U.S., Canada and the Caribbean) when help is needed immediately.

You can also send an instant email message to a FAST technician, Monday through Friday, 8am-5pm EST, by going to www.fastinc.com, selecting the 'Support' link at the top of the page, and clicking on 'Email Us.'

Free Program for Service Exchanges

FAST provides an Exchange Program, at no extra cost, if a unit should fail. In the event of failure, you have the option of (1) receiving a replacement product from our factory, freight prepaid; (2) exchanging the failed product for a replacement product at one of our authorized local service centers; or (3) selecting on-site repair or replacement of the failed unit by one of our authorized local service centers.

To take advantage of this program, simply call our toll-free customer service number, 1-800-243-9271. If you elect to receive an exchange unit from the factory, a replacement unit will be sent immediately. Upon receipt of the replacement unit, simply return the failed unit to the factory, freight prepaid, using the same carton and packing material in which the replacement unit was shipped. The unit will be replaced free of charge, if still under warranty, and if the product shows no evidence of abuse or alteration. If the unit is not under warranty, you will pay repair charges and shipping costs to and from the factory. If you should elect on-site repair and the unit is under warranty, you will not be required to pay the costs of reasonable on-site labor, but will be required to pay the service agency's travel charges to and from the on-site location.

Any minor adjustment or calibration and any labor costs for the replacement of probes will be made at your expense.

The FAST Exchange Program is available to any FAST Domestic Customer whose account is current, and applies to all FAST Timers, Computers and Controllers.

Warranty

FAST provides a limited one-year warranty (optional two-year and lifetime) for its products. Warranty replacement units are available. A copy of the exact provisions of this warranty and the other terms and conditions of sale are available upon request.

Patents

The products manufactured by FAST are protected under one or more of the following U.S. Patents:

4,782,445	4,812,625	4,812,963	4,864,498	4,911,068
4,920,948	5,043,860	5,171,974	5,331,575	5,539,671
5,711,606	5,723,846	5,726,424	5,875,430	6,142,666
6,339,930	6,401,467	6,505,546	6,581,391	7,015,433

Plus foreign patents and patents pending. Plus licensed patent 5,973,297

Specifications subject to change without notice.