

POWERMITE® GAS BOOSTER HEATER INSTALLATION, OPERATING, SERVICE AND PARTS MANUAL

MODEL: PMG-60 58,000 BTU

I&W #07.05.053.00







WATER HEATERS FOR OTHER THAN RECREATIONAL VEHICLE INSTALLATION ONLY

CHAUFFE-EAU POUR INSTALLATION AUTRE QUE DANS DES VÉHICULES DE LOISIR UNIQUEMENT

WARNING: If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- WHAT TO DO IF YOU SMELL GAS:
 - Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any phone in your building.
 - Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
- Installation and service must be performed by a qualified installer, service agency or the gas supplier.

AVERTISSEMENT: Assurez-vous de bien suivre les instructions données dans cette notice pour réduire au minimum le risque d'incendie ou d'explosion ou pour éviter out dommage matériel, toute blessure ou la mort.

- Ne pas entreposer ni utiliser d'essence ou ni d'autres vapeurs ou liquides inflammables à proximité de cet appareil ou de tout autre appareil.
- QUE FAIRE SI VOUS SENTEZ UNE ODEUR DE GAZ:
 - •Ne pas tenter d'allumer d'appareil.
 - Ne touchez à aucun interrupteur; ne pas vous servir des téléphones se trouvant dans le bâtiment.
 - Appelez immédiatement votre fournisseur de gaz depuis un voisin.
 Suivez les instructions du fournisseur.
 - Si vous ne pouvez rejoindre le fournisseur, appelez le service des incendies.
- L'installation et l'entretien doivent être assurés par un installateur ou un service d'entretien qualifié ou par le fournisseur de gaz.

CONTENTS

Important Safety InstructionsFront Co	over	Gas	13
Important Owner Information			
Introduction			
Model Description			
System Overview	1	Maintenance	19
Specifications			23
Dimensions		Replacement Parts List	
Booster Heater Sizing Chart	4		
Installation		Hatco Limited Warranty	
General			
Plumbing	8		

i

IMPORTANT OWNER INFORMATION

Record the model number, serial number (identification plate located on the lower right hand side, front corner of the unit), voltage and purchase date of your Powermite® Gas Booster Heater in the spaces below. Please have this information available when calling Hatco for service assistance.

/lodel No
Serial No
oltage
Date of Purchase

Business 8:00 a.m. to 5:00 p.m. Hours: Central Standard Time

(Summer Hours: June to September – 8:00 a.m. to 5:00 p.m. C.D.T. Monday through Thursday

8:00 a.m. to 2:30 p.m. C.D.T. Friday)

Telephone: (800) 558-0607; (414) 671-6350

Fax: (800) 690-2966 (Parts & Service) (414) 671-3976 (International)

24-Hour 7-Day Parts & Service
Assistance available in the
United States and Canada
by calling (800) 558-0607.

Additional information can be found by visiting our web site at www.hatcocorp.com.

INTRODUCTION

Hatco Powermite Gas Booster Heaters are instantaneous fin tube type heaters designed to boost the temperature of regularly available hot water, usually 110°F to 150°F (43°C to 66°C) to a minimum of 180°F (82°C). Water at 180°F (82°C) can be used as sanitizing rinse water in commercial dishwashers in accordance with Health Codes and National Sanitation Foundation Standard #5.

The Hatco Gas Booster Heater is design certified by CSA International and tested under the requirements of the American National Standard, ANS Z21.10.3*CSA 4.3, Current Edition.

All Hatco Gas Booster Heaters are factory preplumbed and pre-wired to allow for easy installation. The control compartment area is accessible from the front, which permits easy installation, even when near other equipment.

Hatco Gas Booster Heaters are quality built for long life and rugged dependability. Dependability of the booster heater is preserved through proper, safe installation and operation.

This manual provides the installation, safety and operating instructions for the Powermite Gas Booster Heater. We recommend all installation, operating and safety instructions appearing in this manual be read prior to installation or operation of your Hatco PMG-60 Gas Booster Heater. Safety instructions that appear in this manual after a warning symbol A and the words WARNING or CAUTION printed in bold face are very important. A WARNING means there is the possibility of serious injury or death to yourself or others. CAUTION means there is the possibility of minor or moderate injury. CAUTION without the symbol signifies the possibility of equipment or property damage only.

Hatco Gas Booster Heaters are a product of extensive research and field testing. The materials used were selected for maximum durability, attractive appearance and optimum performance. Every unit is thoroughly inspected and tested prior to shipment.

ALL MODELS

Water enters the booster heater at the inlet water connection and flows into the stainless steel tank. It then is pumped through the finned tube heat exchanger where it is heated to the proper temperature. The heated water then returns back to the top half of the stainless steel tank for supply to the dishwashing machine. Water that is not immediately used by the dishwashing machine is recirculated through the heat exchanger.

This system is designed to assure the availability of the proper temperature water at the heater outlet.

All Hatco booster heaters are warranted to be free of defects in material and workmanship under normal use and service, and when installed in accordance with factory recommendations.

NOTE: Hatco Booster Water Heaters are approved for use with commercial dishwashers only.

SYSTEM OVERVIEW

The Hatco Powermite Gas Booster Heater is designed to maintain a minimum temperature of 180°F (82°C) water required for the rinse cycle of a commercial dishwasher. An inlet water temperature of at least 110°F (43°C) will produce optimum results (See Capacity Chart and Booster Heater Sizing Chart in *SPECIFICATIONS*).

After the necessary power, water and gas connections are completed, start the unit by turning on the toggle switch located on the lower front base. The water circulating pump will start at this time. After 20 seconds, providing the operating and safety controls are satisfied, the ignition module will energize the spark igniter and turn on the gas for the pilot. The igniter will spark for about 90 seconds or until proof of fire. If there is a confirmed pilot fire, and the water temperature is below the setpoint, the unit will go into full burn. The unit will stay in full burn until the desired setpoint temperature is met, then the burner will shut off. During standby periods of limited use, the burner will cycle on only to replace standby water temperature loss. If for some reason the unit did not ignite there is an automatic 5 minute delay before the unit attempts to ignite again.

1

If the unit overheats above the setpoint temperature, the safety high limit will open, shutting down the burner, locking out the controller, and turning on the alarm pilot light. In order to reset the unit, turn the unit off and depress the reset button on the appropriate high limit switch. The heat exchange high limit is located on the left hand side of the heat exchanger or the tank high limit on the lower front of the control box. This switch will not reset until the temperature has dropped to a safe level. This unit must remain off for at least 10 seconds before it can be restarted.

NOTE: The operating thermostat control is factory preset at 190°F (88°C).

NOTE: The circulator pump will stay on as long as the toggle switch is in the ON position.

SPECIFICATIONS

Type: Gas-fired, instantaneous recirculating booster heater with accumulator for use with

door type dishwashers. Unit is unvented and floor mounted.

Capacity: Input 58,000 BTUs/Hour. Output 46,000 BTUs/Hour = 13.4 kW

Fuel: Natural gas @ 5 iwc or Propane @ 11 iwc – minimum inlet gas pressure.

Operating

Water Pressure: 150 PSI max. Relief valve set at 150 PSI, 210°F (99°C).

Power: Supply 120 VAC, 15 amp service (unit uses 1.75 amps @ 120 volts).

Ignition: Electronic spark pilot with flame proofing by rectification.

Temperature Control: Electronic, temperature control probe/microprocessor based. Factory preset at

190°F (88°C).

Safety Systems: Energy cut off devices include manual reset flame rollout and heat exchanger high

limits, and manually reset tank high limit. Redundant gas solenoid valve with

integral regulator. Temperature/Pressure relief valve on tank.

Fluing: Direct – combustion air enters bottom, flue gases exit sides at top of unit.

Pump: Recirculating with bronze housing.

Connections: Gas – 1/2" NPT, Water – 3/4" NPT, Electric – 120 VAC, 15 Amp.

Weight: 108 pounds (49 kg), dry.

WATER TEMPERATURE RECOVERY TABLE – FAHRENHEIT						
	INPUT MBH	Gallons per Hour (GPH) at Indicated Temperature Rise (F°)				
MODEL	(1,000 BTU/HR)	30°	40°	50°	60°	70°
PMG-60	58	181	135	108	90	77

NOTE: Capacity is reduced @ altitudes above 2000 feet (610 m). See HIGH ALTITUDE INSTALLATION & OPERATION section for sizing considerations.

DIMENSIONS




Figure 1. Dimensional Drawings

3

SPECIFICATIONS

BOOSTER HEATER SIZING CHART

Dishwasher	Model Number	POWERMIT	GAS E® BOOSTER† ature Rise
		40°F (22°C)	70°F (39°C)
Blakeslee	UC-21, D-8	PMG-60	PMG-60
Champion	U-H1, UH-200, UH-200B, U-HB, UL-150 UH-150, UH-150B, UH-100B, DHB-VS D-H1, D-HB, D-H1T, D-HBT PP-28 D-H1C, D-H1TC 66 WSPW, 44-WS, 66WS	PMG-60 PMG-60 PMG-60	PMG-60 PMG-60 PMG-60
Hobart	LXiC, LXiGC, LX-18C, LX-30C, LX-40C LX-30, SR24, SR24H LX-18 AM-14T, AM-14F, AM-14TC AM-12, AM-12C*, AM-14, AM-14C AM-15, AM-15F, AM-15T Opti-RinSe C44AW, CRS-66AW, CCS-66AW, CPW-80AW	PMG-60 PMG-60 PMG-60 PMG-60	PMG-60 PMG-60 PMG-60
Insinger	Commander 18-5, 18-5H, Ensign 40-2	PMG-60	
Jackson	JP-24, JP-24B, JP-24F, JP-24BF 24B Series 10AB, 10APRB 200 200B	 PMG-60	PMG-60 PMG-60 PMG-60
Knight Equipme	nt KLE-112 HL	PMG-60	PMG-60
Metalwash/ Intedge	FW4	PMG-60	
Stero	SCT-44-10-LW, SCT-44-LW, SCT-66S-LW, SCT-76S-LW, SCT-76SC-LW, SCT-90S-LW	PMG-60	

^{*} Hobart Model AM-12 with serial no. 12-067-357 or below and model AM-12C with serial no. 12-067-537 or below require slightly larger booster than listed. Or C Models with serial no. 85-1041605 or greater use Opti-RinSe.

This selector chart is based on 40°F (22°C) and 70°F (39°C) temperature rises, 20 psi flow pressure, and minimum rinse cycle timer setting in NSF listing.

All booster heaters are rated at 100% of the capacity of the dishwashers as recommended by the National Sanitation Foundation. Where make-up water for wash tank is provided from final rinse supply, chart recommendations are based upon this additional demand (not over 2 GPM) as required by NSF.

All sizings shown are that of the dishwasher manufacturers. Hatco Corporation is not responsible for incorrect sizing applications.

[†] Powermite installations above 2,000 ft. (610 m) will reduce the above capacities and may require change of pressure and/or orifices in certain models at time of install to meet IAS safety compliance. These modifications are the responsibility of the installer. Consult "Installation and Operating Manual" for sizing adjustments and orifice changes.

GENERAL

Code Requirements

Installation must be in accordance with local codes. or in the absence of local codes, with the latest edition of the National Fuel Gas Code, ANSI Z223.1, the National Electrical Code, ANSI/NFPA 70. Canadian installations should conform with CSA-B149.1 Natural Gas and Propane Installation Code. and CSA-C22.1 Electrical Code, and/or local installation codes. {Les installations canadiennes doivent se conformer CODES aux D'INSTALLATION CSA-B149.1. Natural Gas and Propane Installation Code, et CSA-C22.1 Electrical Code, et/ou aux codes locaux d'installation.}

NOTE: In the Commonwealth of Massachusetts, Hatco Booster Heaters shall be installed by a licensed plumber and gasfitter.

NOTE: The Commonwealth of Massachusetts requires that if a water treatment system is installed in line with the Hatco Booster Heaters, a water backflow protector shall also be installed.

NOTE: If a check valve or water backflow protector is installed and cannot be removed install a back pressure relief valve, Hatco part number 03.02.039.00, set at 125 psi (862 kPa) on the incoming line between the pressure reducing valve and the inlet to the booster heater. Discharge must be to open site drain.

For the most effective operation, install the Hatco Gas Booster Heater as close as possible to the dishwashing machine.

NOTE: Employ external recirculation if distance between booster and dishwasher exceeds the National Sanitation Foundation specifications of five (5) feet (1.5 m).

⚠ CAUTION

Unit is not weatherproof. For safe and proper operation the unit must be located <u>indoors</u> where the ambient air temperature is constant and is a minimum of 70°F (21°C).

⚠ WARNING

To assure proper operation and avoid a possible unsafe condition, the booster heater must be installed in a horizontal position with the base parallel to the floor and the inlet connection at the lowest point.

The Booster Heater must not be installed directly on carpeting, but on top of a metal, wood (or equivalent) panel extending beyond the full width and depth of the booster heater by at least 3" (76 mm) in any direction or, if the heater is installed in an alcove or closet, the entire floor must be covered by the panel. The panel must be strong enough to carry the weight of the heater when full of water.

Adequate front clearance is required to allow for accessibility to the control compartment.

The booster heater should be located in an area where leakage of the tank or connections will not result in damage to the area adjacent to the heater or to lower floors of the structure. When such locations cannot be avoided, it is recommended that a suitable drain pan, adequately drained, be installed under the booster heater. The pan must not restrict combustion air flow.

INSTALLATION

Combustion/Ventilation Air

The booster heater must be located in an area which allows for an adequate supply of air for proper combustion and ventilation in accordance with Section 5.3 and 7.2.2 of the National Fuel Gas Code NFPA54/ANSI Z223.1 (a portion of the 1996 code is excerpted below) or applicable provisions of the local building codes. Only a single booster appliance may be installed in this manner. Installations under the jurisdiction of Canadian CSA-B149.1. Natural Gas and Propane Installation Code require a gas interlock tied into the ventilation hood system. {Les installations sous la juridiction des CODES D'INSTALLATION canadiens CSA-B149.1, Natural Gas and Propane Installation code nécessitent un verrouillage réciproque de gaz raccordé au système de capot de ventilation.}

EXCERPT FROM ANSIZ223.1/NFPA #54

7.2.1 Connection To Venting Systems. Excerpt as permitted in 7.2.2 through 7.2.6, all gas utilization equipment shall be connected to venting systems.

7.2.2 Equipment Not Required To Be Vented. A single booster-type [automatic instantaneous] water heater, when designed and used solely for the sanitizing rinse requirements of a dishwashing machine, provided that the equipment is installed, with the draft hood in place and unaltered, if a draft hood is required in a commercial kitchen having a mechanical exhaust system. Where installed in this manner, the draft hood shall not be less than 36 inches (91 cm) vertically and 6 inches (15 cm) horizontally from any surface other than the equipment.

Where any or all of this equipment is installed so the aggregate input rating exceeds 20 Btu per hour per cubic foot (207 watts per m³) of room space in which it is installed, one or more shall be provided with venting systems or other approved means for removing the vent gases to the outside atmosphere so the aggregate input rating of the remaining unvented equipment does not exceed the 20 Btu per hour per cubic foot (207 watts per m³) figure. Where the room or space in which the equipment is installed is directly connected to another room or space by a doorway, archway or other opening of comparable size that cannot be closed, the volume of adjacent room or space shall be permitted to be included in the calculation.

Minimum Clearance Requirements: {Exigences quant au dégagement minimum:}

Floor	Top	Left Side	Right Side	Front	Back
{Sol}	{Dessus}	{Côté gauche}	{Côté droit}	{Devant}	{Derrierè}
6"* (152 mm)	5" (127 mm)	6" (152 mm)	6" (152 mm)	20" (508 mm)	2" (51 mm)

^{*}Includes legs supplied with booster heater {Comrend pieds fournis avec appareil de chauffage auxiliare}.

↑ WARNING/CAUTION

The flow of air to the heater for combustion and ventilation <u>must not</u> be obstructed. Air vents on the bottom and side of the unit should never be blocked.

⚠ WARNING/CAUTION

This unit is designed to vent directly into the room and is intended for commercial food service water heating only. <u>IT IS NOT FOR RESIDENTIAL USE.</u>

⚠ WARNING/CAUTION

Flue gases exit top sides of this unit and must not be obstructed, specified clearances must be maintained for safe operation.

While the gas booster heater is designed and approved to vent directly into the room, an alternative venting method is available through our accessory diverter hood. See the *ACCESSORIES* section of this manual.

High Altitude Installation and Operation

Atmospheric conditions at elevations above 2000 ft. (610 m) have an effect on the performance of most gas fired products. For this reason, historical models for altitude de-rating were developed for gas appliances with atmospheric burners. The National Fuel Gas Code, ANSI Z223.1 is an accepted model which requires a de-rating of 4% per 1000 ft. (305 m) elevation when no testing to the contrary exists for that product. This could require modifying the equipment and adjusting settings in the field to achieve de-rating. Testing has shown this to be a very conservative approach.

Manufacturers discourage unnecessary field adjustments in order to maintain a level of performance and quality designed into the product. For these and other reasons, testing was underwritten through CSA International to verify an improved satisfactory performance with little or no modification to effect input rate or control. The following text and charts are a result of this testing and should be used during application sizing and installation.

• The PMG-60 can operate with less de-rating than ANSI Z223.1 with sea level manifold pressure settings and orifices. A natural gas unit will require an orifice change over 5000 ft. (1525 m). No change is needed for a liquid propane gas unit. This is true up to 8500 ft. (2593 m) elevation where a slight decrease in manifold pressure may be needed to meet the approved BTU rate. Also note that the GPH capacity will be reduced and a guideline is given as to the percent of sea level capacity expected.

Orifice Kits for altitude installations may be ordered through Hatco Customer Service. For PMG-60 order P/N ORIF60.

For Canadian installations between 2000-4500 feet (610-1370 m) de-rate unit by 10% to 52,000.

{Pour les installations au Canada entre 610 et 1370 m (2000 et 4500 pi) reclassifier l'appareil de 10% à 52,000 BTU.}

Altitude Summary Publication Data for PMG Boosters

NATURAL GAS

Altitude: Ft. Above Sea Level (Meters)	0-2000 (0-610)	2001-3000 (610-915)	3001-4000 (915-1220)	4001-5000 (1220-1525)	5001-6000 (1525-1830)	6001-7000 (1830-2135)	7001-8000 (2135-2440)	8001-8500 (2440-2593)	8501-9500 (2593-2898)	9501-10500 (2898-3203)
PMG-60 Approved Input Rate*	58000	56154	54308	52462	50615	48769	46923	46000	44160	42320
Suggested Orifice Size† GPH Capacity Derate•	# 55 DMS	0.97	0.94	0.90	# 56 DMS 0.87	0.84	0.81	0.79	0.76	0.73

LIQUID PROPANE GAS

Altitude: Ft. Above Sea Level (Meters)	0-2000 (0-610)	2001-3000 (610-915)	3001-4000 (915-1220)	4001-5000 (1220-1525)	5001-6000 (1525-1830)	6001-7000 (1830-2135)	7001-8000 (2135-2440)	8001-8500 (2440-2593)	8501-9500 (2593-2898)	9501-10500 (2898-3203)
PMG-60 LPG Approved Input Rate*	58000	57154	56308	55461	54615	53769	52923	52500	50400	48300
Suggested Orifice Size† GPH Capacity Derate•	# 68 DMS	0.99	0.97	0.96	0.94	0.93	0.91	0.91	0.87	0.83

Notes:

- * This is the maximum allowable btu rate certified by CSA. These are to be verified by the qualified gas installer on site. Check Heat Value with local Gas Utility
- † The first orifice size is the factory built unit.
 - The next sizes are shown at the altitudes where a change is required to allow pressure adjustments to the approved input rates.
- This is a de-rate multiplier to use when sizing a gas booster for a given application.
 - Take this value and multiply it by the GPH found on the Hatco sizing chart to ensure it will provide the capacity you need.
 - You can also use this value by dividing it into your capacity needs and take the resulting *adjusted GPH* to the sizing chart to select a gas booster.

PLUMBING

Components

SUPPLIED WITH UNIT	OPTIONAL WITH UNIT	SUPPLIED BY INSTALLER
Temperature/Pressure Relief Valve Blended Phosphate Water Treatment System Temperature/Pressure Gauges (2) Shock Absorber 3/4" Plug (installed) 3/4" Inlet Tee	Back Pressure Relief Valve	 3/4" Gate or Ball Valve Drain Valve 3/4" Unions 3/4" Piping

Pressure And Temperature Relief Valves

For protection against excessive pressures and temperatures in the booster heater, install temperature and pressure protective equipment by local codes. Hatco supplies valves constructed with brass working parts and heat resistant silicone seat discs for all booster heater models.

⚠ WARNING

Valves supplied by Hatco are designed for high temperature commercial operation. Do not substitute Hatco valves with valves designed for domestic water heaters.

Temperature/pressure protective equipment should not be less than a combination temperature/pressure relief valve certified by a nationally recognized testing laboratory that maintains periodic inspection of the production of this equipment and meets the requirements for Relief Valves and Automatic Shutoff Devices for Hot Water Supply Systems, ANSI Z21.22*CSA 4.4. The temperature/pressure relief valve must be marked with a minimum set pressure not to exceed the marked maximum working pressure of the booster heater.

⚠ CAUTION

Do not use an anti-siphon or check valve on the incoming water line.

⚠ CAUTION

FOR **PRESSURE** INSTALLING AND TEMPERATURE RELIEF **VALVES** IN ACCORDANCE WITH ANSI Z21.22*CSA 4.4. Combination pressure and temperature relief valves with extension thermostats must be installed so that the temperature-sensing element is immersed in the water within the top 6" (152 mm) of the tank. They must be installed either in the hot outlet service line or directly in a tank tapping. Combination pressure and temperature relief valves that do not have extension elements must be mounted directly in a tank tapping located within the top 6" (152 mm) of the tank, and shall be adequately insulated and located so as to assure isolation from flue gas heat or other ambient conditions that are not indicative of stored water temperature. TO AVOID WATER DAMAGE OR SCALDING DUE TO VALVE OPERATION. DRAIN PIPE MUST CONNECTED TO VALVE OUTLET AND RUN TO A SAFE PLACE OF DISPOSAL. Drain pipe must be as short as possible and be the same size as the valve discharge connection throughout its entire length. Drain line must pitch downward from the valve and terminate at least 6" (152 mm) above the floor drain where any discharge will be clearly visible. The drain line shall terminate plain, not threaded, with a material serviceable for temperatures up to 250°F (121°C) or greater. Excessive length, over 15' (4.57 m), or use of more than two elbows can cause a restriction and reduce the discharge capacity of the valve. No shut-off valve shall be installed between the relief valve and tank, or in the drain line. Valve lever must be tripped periodically to ensure that waterways are clear. This device is designated for emergency safety relief and shall not be used as an operating control. The valves are set to relieve at 150 pounds pressure or when water temperature reaches 210°F (99°C). Read tag on valve for additional information.

INSTALLATION

Temperature/Pressure Gauges

Hatco requires a temperature/pressure gauge be installed in both the inlet and outlet lines to the booster heater. These gauges provide an instant visual check of the water temperature and pressure entering and leaving the booster heater. The visual check is helpful in eliminating unnecessary service calls.

Install the temperature sensing bulb in the water system. See **Figures 2 and 3** for methods of installation.

Pressure Reducing Valve

Proper operation of most dishwasher rinse nozzles require available water flow pressure at the nozzle to be 20 PSI.

If water pressure available to the booster heater inlet is over 20 PSI, a pressure reducing valve with bypass must be installed in the hot water supply line to the booster heater.

The valve supplied by Hatco has a built-in high pressure bypass which prevents excessive pressure build-up as the booster heats up.

⚠ CAUTION

Pressure regulating valve must have a built-in high pressure bypass.

Blended Phosphate Water Treatment System

Hatco requires that the Blended Phosphate Water Treatment System supplied be installed with unions on the incoming 3/4" water supply line after the pressure reducing valve and before the booster heater.

Cartridges supplied have a usage rating of 100,000 gallons of water. To ensure proper operation the cartridges must be replaced when expired.

NOTE: The Commonwealth of Massachusetts requires that if a water treatment system is installed in line with the Hatco Booster Heaters, a water backflow protector shall also be installed.

NOTE: If a check valve or water backflow protector is installed and cannot be removed install a back pressure relief valve, Hatco part number 03.02.039.00, set at 125 psi (862 kPa) on the incoming line between the pressure reducing valve and the inlet to the booster heater. Discharge must be to open site drain.




Figure 2. Installation Temperature/Pressure Gauge




Figure 3. Installation Temperature/Pressure Gauge

NOTE: Product failure caused by liming or sediment buildup is not covered under warranty.

PLUMBING CONNECTIONS (See Figure 4) Inlet

Hatco Booster Heaters are designed to be connected with 3/4" pipe at the inlet pipe from the primary water heater. Water temperature from the primary water heater must be at least 110°F (43°C) and should not exceed 160°F (71°C). Minimum temperature differential between the inlet and outlet temperature must never be less than 20°F (11°C).

Note: Refer to BOOSTER HEATER SIZING CHART for application information.

Inlet line <u>must</u> be installed with a shut-off valve, a full open gate or ball type valve, a 3/4" union, together with the blended phosphate water treatment system pressure reducing valve set at 20 PSI (1.4 kg/cm²) flow pressure and a temperature/pressure gauge supplied by Hatco.

NOTE: Do not run a cold ground water line to the Booster Heater.

CAUTION

Incoming water supply in excess of 3 grains of hardness per gallon ([GPG] .75 grains of hardness per liter [GPL]) must be treated/softened before being supplied to booster heater(s). Water that contains over 3 GPG or .75 GPL will cause loss of efficiency, increase fuel consumption and reduce the life of the unit. NOTE: Product failure caused by liming or sediment buildup is not covered under warranty.

CAUTION

Incoming water supply to booster heater must be a minimum of 20 psi (1.4 kg/cm²), water pressure less than 20 psi (1.4 kg/cm²) will decrease the operating life of the recirculating pump and the unit.

NOTE: Product failure caused by incoming water pressure less than 20 psi (1.4 kg/cm²) is not covered under warranty.

⚠ CAUTION

To avoid development of a leak, do not back up or loosen any water pipe fittings.

⚠ WARNING

Do not connect the heater directly to a boiler or furnace coil or any other uncontrolled temperature source. Such hook-up could cause the thermostat to lose control and the unit could overheat.

Form No. PMG-60M-0705

11

INSTALLATION

NOTE: Be sure water flows through the pressure reducing valve in the proper direction. Check the directional arrow. Valve will reduce pressure only during flow conditions.

A 3/4" union fitting and a drain valve must also be installed to allow for easy servicing.

The temperature/pressure relief valve must be installed into one of two locations on the heater: either the right side or the back of the unit. See Figure 4 for exact locations.

To prevent water leakage and damage to the unit, the location for the temperature/pressure relief valve that is **not used** <u>must</u> be plugged. (One plug is supplied by Hatco with the heater.) <u>Both</u> temperature/pressure fittings <u>MUST NOT</u> be plugged.




Figure 4. Plumbing Connections – PMG-60 Gas Booster Heater




Figure 5. PMG-60 Gas Booster Heaters Connected in Series

Outlet

Using a 3/4" union and piping, connect the booster heater water outlet to the dishwasher sanitizing rinse pipe connection.

NOTE: Be certain the connection is made to the final rinse and not to the wash tank.

Install a temperature/pressure gauge in outlet line. Water temperature at outlet should be 180°F (82°C).

NOTE: The temperature sensing element must be in water stream. (See Figures 2 and 3.)

Shock Absorber

In areas of high water pressure, Hatco recommends a shock absorber be installed in the outlet line as close as possible to the dishwasher. The shock absorber softens the water hammer caused by automatic dishwasher valves. (See Figure 4.)

NOTE: Fill booster heater with water to test for installation leaks. Leave the water in booster to prevent pump damage in the event the electrician should apply power.

<u>GAS</u>

Components

SUPPLIED WITH UNIT	OPTIONAL WITH UNIT	SUPPLIED BY INSTALLER
Internal Gas Valve (installed)	None	Gas Supply Line
External Gas Valve (loose)		Sediment Trap
		• Union

INSTALLATION

Gas Piping

The gas inlet pipe size is 1/2" NPT pipe thread fitting to the gas valve. Provide an adequate size gas supply line. The line should never be smaller than 3/8" NPT and should follow according to the gas piping diagram below. The fitting is accessed through the bottom of the case. (See Figure 6.)

NOTE: Gas line should be of the approved type for use with natural gas or propane.

⚠ WARNING/CAUTION

Provide support to the internal gas train while tightening the gas supply connection to the booster.

Gas line should be kept as short as possible, sized to furnish the rated BTU, and installed in a way to protect it from damage. Gas piping must be installed in accordance with local plumbing codes including a sediment trap, ahead of the heater gas controls and a manual shut-off valve located outside the jacket.

NOTE: The internal gas valve is supplied with the heater, the external manual gas valve supplied with unit must be plumbed in by the installer. See **Figure** 6 for gas piping diagram.

A CAUTION

<u>Do not</u> use Teflon tape on gas line pipe threads. A flexible sealant suitable for use with applied gas is recommended.




Figure 6. Gas Hook-up and Pressure Tap Location and Piping Diagram.

⚠ WARNING/CAUTION

The gas used with this unit <u>must</u> be the type specified on the spec plate on this unit. To avoid personal injury or damage to the unit, never use any other than the specified gas.

The heater and its gas connection must be leak tested before placing the booster heater in operation.

The booster heater and its individual shut-off valve must be disconnected and isolated from the gas supply piping system during any pressure testing of the system at test pressures in excess of 1/2 PSI (3.5 kPa.).

This appliance must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig (3.5 kPa).

Dissipate test pressure from the gas supply line before re-connecting the heater and its manual shut-off cock to the gas supply line. FAILURE TO FOLLOW THIS PROCEDURE MAY DAMAGE THE GAS VALVE. OVER PRESSURED GAS VALVES ARE NOT COVERED BY THE WARRANTY.

The heater and its gas connections shall be leak tested before placing the appliance in operation. Use soapy water or commercially available fluid for leak test. DO NOT use open flame to test for leaks.

Incoming Gas Pressure Specifications

	Inches Water Column				
Gas Type	Minimum	Maximum			
Natural	5.0	10.5			
Propane/LP	11.0	13.0			

The maximum inlet gas pressure must not exceed the values shown above. The minimum gas pressure listed is for the purposes of input adjustment.

The manifold inside the heater is provided with a pressure tap to measure the gas pressure. The chart below lists the proper pressure amounts at the manifold pressure tap when testing.

Operating Pressure Specifications at Manifold

	Inches Water Column At Pressure Tap
Gas Type	High Burn
Natural	3.5
Propane/LP	10.0

See Figure 6 for hook-up location and pressure tap location.

INSTALLATION

ELECTRICAL

Components

SUPPLIED WITH UNIT	OPTIONAL WITH UNIT	SUPPLIED BY INSTALLER
• 7/8" Hole Plugs	None	• 120 VAC, 60 Hz, 15 Amp Single Phase Service
		Electrical Ground Wire

The Hatco Gas Booster Heater operates on 120 VAC, 60 Hz, 15 amp, single phase service. All internal electrical connections have been made at the factory.

Electrical Connections

To connect the field wiring to the booster heater:


- Remove the front cover from the unit by lifting up on the front cover and pulling lower edge away from unit. Then let top of cover drop down until it clears the upper edge.
- 2. Open electrical enclosure by removing two screws and sliding the cover out the front.
- Bring power leads from a properly sized fused disconnect switch or circuit breaker through 7/8" hole provided on lower left hand side or bottom of base. Connect supply lines to terminal block provided. (See Figure 7.) <u>Use copper wire only</u>.
- 4. A green grounding terminal is provided internally. An equipment grounding conductor must be properly connected to the green terminal block. (See Figure 7.)

CAUTION

To avoid damage to both the pump and heater assembly, do not turn on the power switch to the heater until the installation is complete and the booster water tank is filled with water and all air in the system has been vented through the dishwasher rinse nozzles.

⚠ WARNING

If an external electrical source is utilized, the appliance, when installed, must be electrically grounded in accordance with local codes, or, in the absence of local codes, with the National Electrical Code, ANSI/NFPA 70, and CSA C22.1, Electrical Code.



- 1. Rotate Screwdriver into top opening.
- 2. Insert 3/8" Stripped Wire Lead.
- 3. Remove Screwdriver.

Figure 7. Terminal Block Wiring Instructions.

START UP PROCEDURES

NOTE: Remove the front cover during start up.

Filling The System With Water

1. With the external gas supply and electric supply turned off, close the drain pipe valve.

NOTE: Water temperature at the inlet should be between 110°F (43°C) and 150°F (66°C) and should never exceed 160°F (71°C) for the unit to operate properly and meet the demands of the dishwashing machine. Minimum temperature differential between inlet and outlet temperatures should never be less than 20°F (11°C).

NOTE: Do not run a cold ground water line to the Booster Heater.

CAUTION

Incoming water supply in excess of 3 grains of hardness per gallon ([GPG] .75 grains of hardness per liter [GPL]) must be treated/softened before being supplied to booster heater(s). Water that contains over 3 GPG or .75 GPL will cause loss of efficiency, increase fuel consumption and reduce the life of the unit. NOTE: Product failure caused by liming or sediment buildup is not covered under warranty.

When the water tank is full, turn on the electric supply and the power switch to allow the circulator pump to purge air from it. The circulator pump should start immediately. Additional air in the tank can be vented through the dishwasher rinse nozzle.

NOTE: Dishwasher should be cycled a minimum of three times before the gas supply to booster is turned on.

After all the air has been vented out of the system, turn off the power to the booster heater.

CAUTION

Product failure caused by dry firing is not covered under warranty.

Lighting The Heater

FOR YOUR SAFETY, READ BEFORE OPERATING:

⚠ WARNING

If you do not follow these instructions exactly, a fire or explosion may result, causing property damage, personal injury or loss of life.

AVERTISSEMENT: Assurez-vous de bien suivre les instructions données dans cette notice pour réduire au minimum le risque d'incendie ou d'explosion ou pour éviter tout dommage matériel, toute blessure ou la mort.

- This appliance is equipped with an ignition device which automatically lights the pilot. <u>DO</u> <u>NOT</u> TRY TO LIGHT THE PILOT BY HAND.
- BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

What To Do If You Smell Gas:

- · Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.
- 3. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it - call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- 4. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

Operating Instructions:

Les Instructions quant a la nise en service de ce chauffe-eau se trouvent sur la surface interieure du ponneau avant. Pour retirer le panneau, saisar les cotes avont interieurs du panneau avant et soulever vers le haut, tirer le bord inferieur vers l'exterieur et laisser le bord superieur tomber.

↑ WARNING/CAUTION

Should overheating occur or the gas supply fail to shut off, turn off the manual gas control valve to the appliance.

En cas de surchauffe ou si l'alimentation en gaz ne s'arrête pas, fermez manuellement le robinet d'arrêt de l'admission de gaz.

OPERATION

- 1. **STOP!** Read the safety information on the appliance label or in this manual.
- 2. Turn off all electric power to the appliance.
- This booster heater is equipped with an ignition device which automatically lights the pilot. <u>DO</u> <u>NOT</u> try to light the pilot by hand.
- 4. To gain access to controls remove front panel by sliding it up and pulling lower edge out and down away from the appliance.
- For units with gas valves like that shown in Figure 8a, turn gas control knob clockwise to OFF.

For units with gas valves like that shown in **Figure 8b**, depress and slide the lever toward the rear to OFF.

- Wait five (5) minutes to clear out any gas. If you then smell gas STOP! Follow "B" in the safety information on the appliance label or in this manual. If you don't smell gas, go to the next step.
- 7. For units with gas valves like that shown in **Figure 8a**, turn gas control knob counterclockwise to ON.

For units with gas valves like that shown in Figure 8b, slide the lever toward the front to ON.

- 8. Replace front access panel.
- 9. Turn on all electric power to the appliance.
- 10. Turn on power switch and:
 - a. After approximately twenty (20) seconds the ignition sequence should begin and light the pilot. If the water temperature is below the setpoint the heating process will start.
 - Allow the booster heater to run until the burner shuts down. The booster heater is now at its setpoint, stabilized working temperature.
 - c. Run the dishwashing machine through at least two rinse cycles. After the first rinse cycle the burner should re-light and remain lit until the water maintains 180°-185°F (82°-85°C) output @ 20 psi through the second cycle.




Figure 8a. Gas Valves - Top View




Figure 8b. Gas Valves - Top View

NOTE: If this test does not proceed as described, contact the Hatco Corporation or your authorized service agent for technical assistance.

11.If the appliance will not operate, follow the instructions "To Turn Off Gas To Appliance" and call your service technician or gas supplier.

To Turn Off Gas To Appliance:

- 1. Turn off power switch on heater.
- 2. Turn off all electric power to the appliance if service is to be performed.
- 3. Shut off external manual gas valve.
- Remove front cover of heater for access to the control compartment.
- Turn gas control knob clockwise to OFF. Do not force.
- 6. Replace front access panel.

CAUTION


Using or storing chlorine based products on or near the booster heater may shorten the life of the unit and void the product warranty.

NOTE: Refer to the exploded views and parts list for part identification and location.

NOTE: Refer to the wiring diagram for specific electrical information.

GENERAL

- Keep the area around the heater free and clear of debris and flammable materials. Do not block air intakes or vents.
- The recirculating water pump motor is permanently lubricated and requires no other maintenance.
- 3. Visually observe and inspect the burner and pilot flame every six months. When the burner is operating properly a clean blue flame will be visible. (See Figures 9 and 10.) Depending on the condition of the kitchen environment, the burner and heat exchanger fins may need to be cleaned of lint or grease-laden dust. If any problems are apparent, discontinue use of the heater and contact the Hatco Corporation or your authorized service agent.
- 4. Once a month check and clean (if necessary) all air inlet holes on the bottom of the unit and the vent on the top of the unit.
- 5. The front cover should be removed and all components visually inspected at least twice a year. Check for evidence of chafing or heat damage to any wiring or components. Check also for any signs of water leakage at any of the plumbing connections. If there are signs of any damage or leakage contact the Hatco Corporation or your authorized service agent.



- The flame during full burn is a broad blue color. An inner cone slightly lighter in color will also be visible.
- The flame should not be rising off of the face of the burner element.
- Yellow tipped flames suggest a need for adjustment or cleaning of the burner assembly.

Figure 9. Gas Flame.

6. The relief valve should be manually operated at least once a year to ensure proper operation.

⚠ WARNING

Before performing this operation, care should be taken that any of the discharged water does not come into contact with the operator or surrounding surfaces. The water can be extremely hot and can cause severe scalding and damage to the property.

If the relief valve discharges periodically, this may be due to thermal expansion in a closed water supply system. Contact the water supplier or local plumbing inspector on how to correct this situation. Do not plug the relief valve.

7. Visually observe and inspect the Blended Phosphate Water Treatment System <u>weekly</u>: To ensure proper operation replace depleted cartridges immediately.

BURNER REMOVAL/INSPECTION (TO BE PERFORMED BY YOUR AUTHORIZED SERVICE AGENCY)

- 1. Shut-off the electrical power and gas supply to the heater.
- 2. Disconnect pilot line at gas regulator valve.
- 3. Disconnect gas supply line at the internal union which is located after the regulator valve.
- 4. Remove upper two (2) screws holding manifold to combustion chamber.
- 5. Slide burner assembly out.
- 6. Disconnect spark electrode wire from pilot igniter.
- 7. Remove above procedure to re-install, checking burner assembly and seal to prevent leakage.




Figure 10. Pilot Flame.

MAINTENANCE

DRAINING THE HEAT EXCHANGER

- 1. Shut-off the electrical power, gas and water supply to the heater.
- 2. Allow unit to cool down to room temperature.
- 3. Open the drain valve under the booster heater to remove water from the tank and pump assembly.
- 4. Remove the drain plug located on the front of the heat exchanger and allow the water to drain from the heat exchanger into a pan or pail. Approximately 1 cup of water will drain from the unit.
- 5. Reverse above procedure using a food grade thread sealant to seal the plug threads and prevent leakage.

CAUTION

Failure to drain the heat exchanger prior to exposing it to freezing conditions will damage the heat exchanger and void the warranty.

NOTE: Freeze damage to the heat exchanger and unit can be avoided by doing the following:

- After draining heat exchanger, blow 30 psi of air into the heat exchanger drain opening which will purge the exchanger of any residual water.
- Leaving drain valves open until performing startup procedures.

<u>COMPONENT -</u> <u>ADJUSTMENTS/REPLACEMENTS</u>

⚠ WARNING/CAUTION

Always disconnect the power and shut off gas supply prior to performing any maintenance on the booster heater to avoid possible personal injury or damage to the booster heater.

⚠ WARNING

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

ATTENTION

Au moment de l'entretien des commandes, étiquetez tous les fils avant de les débrancher. Des erreurs de câblage peuvent entrâiner un fonctionnement inadéquat et dangereux.

S'assurer que l'appareil fonctionne adéquatement une fois l'entretien terminé.

1. Gas Valve Replacement

- a. Shut off electrical power and gas supply to the heater.
- b. Remove front panel.
- c. Remove gas piping to gas valve inlet.
- d. Remove burner assembly as outlined in Burner Removal/Inspection.
- e. Disconnect wiring connections to gas valve.
- f. Remove valve.
- g. Reverse above procedure to re-install.

2. Ignition Module Replacement

- a. Shut off electrical power to the booster.
- b. Remove screws for electrical box cover and slide out front.
- c. Disconnect spark cable from module.
- d. Remove mounting screws holding module.
- e. Remove module.
- f. Reverse above procedure to re-install.

3. Transformer Replacement

- a. Shut off electrical power to the heater.
- b. Disconnect wire leads from transformer at the power supply.
- c. Remove mounting screws that hold transformer in place.
- d. Remove transformer from unit.
- e. Reverse above procedure to re-install.
- 4. Temperature Control Probe Replacement.
 - a. Shut off electrical power to the heater.
 - b. Shut off water supply to the heater and open drain valve to remove water below the temperature control probe level.
 - c. Remove the front panel cover.
 - d. Remove two (2) screws from electrical box cover and remove out the front.
 - e. Disconnect temperature control probe wire leads from thermostat body.
 - f. Remove temperature control probe from tank.
 - g. Reverse above procedure to re-install.

5. Recirculating Pump Replacement

- a. Shut off gas supply.
- b. Shut off electrical supply.
- c. Shut off water supply and allow unit to cool sufficiently.
- d. Open the drain valve under the booster heater to remove water from the tank and pump assembly.
- e. Remove front cover and left side panel for access to pump.
- Remove two (2) screws from the electrical box cover and lift off.

- g. Remove pump motor cover and disconnect wiring connections to the pump motor.
- h. Remove bolts and nuts holding pump assembly to flanges (save bolts and nuts).
- Install new pump assembly using new O-rings (supplied with pump assembly) starting with lower bolts first (FLOW ARROW MUST POINT UPWARD).
- j. Close the drain valve under the booster heater and turn the water supply ON checking for leaks at all fittings.
- k. Connect wiring to new pump motor and install wiring compartment cover.
- Purge the air from the system. Turn on the electrical supply and allow pump to displace air out of the heat exchanger and holding tank by running several rinse cycles on the dishwashing machine. Test all connections for tightness.
- m. Turn on gas supply (CHECK ALL FITTINGS FOR LEAKS) and follow start-up procedures.
- 6. Temperature/Pressure Gauge Replacement
 - a. Shut off electrical power to the heater.
 - b. Shut off water supply and open drain valve to remove water in the piping.
 - c. Remove temperature/pressure gauge from pipe fitting connection.
 - d. Reverse above procedure to re-install.
- 7. Temperature/Pressure Relief Valve Replacement
 - a. Shut off electrical power to the heater.
 - Shut off water supply and open drain valve to remove water in the tank below the relief valve level.
 - c. Disconnect drain pipe from valve.
 - d. Remove temperature/pressure relief valve.
 - e. Reverse above procedure to re-install.
- 8. Low Water Cut Off Replacement
 - a. Shut off electrical power to the heater.
 - b. Remove screws for electronics cover and slide out front.
 - c. Mark wires and disconnect from old module.
 - d. Reverse above procedure to re-install.
- 9. Tank High Limit Replacement
 - a. Shut off electrical power to the heater.
 - b. Shut off water supply and open drain valve to remove water in the piping and pump.
 - c. Remove screws for electronics cover and slide out front.
 - d. Remove limit from enclosure, disconnecting leads.
 - e. Loosen 3/8" (10 mm) tank fitting packing nut then remove fitting.
 - f. Reverse above procedure to re-install.

- 10. <u>Orifice Replacement</u> (for High Altitude Orifice Size Change or Orifice Repair)
 - a. Shut off electrical power and gas supply to the heater.
 - b. Remove front panel.
 - c. Disconnect gas supply line at the internal union located after the regulator valve.
 - d. Remove four (4) screws holding manifold to combustion chamber.
 - e. Slide manifold assembly out.
 - Unscrew brass orifices from the black distribution manifold.
 - g. Install new orifices as required.

NOTE: If this is a high altitude change, refer to the tables in the HIGH ALTITUDE INSTALLATION & OPERATION section for the appropriate diameter to drill the orifice blanks for your elevation.

 Reverse the procedure above to re-install, checking burners and seals to prevent gas leaks.

11. Heat Exchanger Replacement

- a. Shut off gas supply.
- b. Shut off electrical supply.
- c. Shut off water supply.
- d. ALLOW UNIT TO COOL DOWN TO ROOM TEMPERATURE.
- e. Open the drain valve under the booster heater to remove water from the tank and pump assembly.
- f. Remove front cover and shut off internal gas valve.
- g. Drain water from the heat exchanger drain plug into pan or tray (less than 16 oz. [498 g]).
- h. Unwrap insulation from front of the heat exchanger.
- Mark and disconnect water lines from the heat exchanger. Use a second backup wrench on the fittings, discard used washers (new ones are provided).
- i. Disconnect gas manifold union.
- k. Disconnect pilot line from gas valve.
- Disconnect wire leads to high limit on side of the heat exchanger.
- m. Remove top three (3) screws of inner flue access cover.
- n. There are four (4) screws holding the manifold to the burner assembly remove the top two (2) screws.
- o. Slide the burner out of the heat exchanger.
- p. Slide the heat exchanger assembly out of the booster.

MAINTENANCE

- q. Remove the two (2) side screws from the burner and lift the heat exchanger out of the bracket.
- r. Remove the heat exchanger high limit switch from old heat exchanger and place onto new.
- s. Reverse steps (h) (r) to reassemble unit.
- t. Seal threads of drain plug with a food grade sealant to prevent leakage and install in new exchanger.
- u. Reconnect water and gas lines and relief valve plumbing.
- v. Close drain valve under booster heater and turn on water supply to booster, then turn on electrical supply and allow pump to displace trapped air out of the new heat exchanger, then purge this air out of the booster by running several rinse cycles on the dishmachine. CHECK ALL FITTINGS FOR LEAKS.
- w. Turn on gas supply (CHECK ALL FITTINGS FOR LEAKS) and follow start-up procedures.
- 12.<u>Blended Phosphate Water Treatment Cartridge</u>
 Replacement
 - a. Shut off electrical power to the heater.
 - b. Shut off water supply and open drain valve to remove water in piping.
 - c. Loosen canister using wrench attached.
 - d. Remove canister and discard depleted cartridge.
 - e. Use a clean damp cloth, wipe interior of canister clean.

NOTE: Make sure O-ring seal is properly placed in canister.

f. Reverse above procedure to reinstall.

⚠ WARNING

Genuine Hatco Replacement Parts are specified to operate safely in the environments in which they are used. Some aftermarket or generic replacement parts do not have the characteristics that will allow them to operate safely in Hatco equipment. It is essential to use Hatco Replacement Parts when repairing Hatco equipment. Failure to use Hatco Replacement Parts may subject operators of the equipment to hazardous electrical voltage, resulting in electrical shock or burn.

⚠ WARNING

This product has no "user" serviceable parts. To avoid damage to the unit or injury to personnel, use only Authorized Hatco Service Agents and Genuine Hatco Parts when service is required.

⚠ WARNING

If service is required on this unit, contact your Authorized Hatco Service Agent, or contact the Hatco Service Department at 800-558-0607 or 414-671-6350; fax 800-690-2966 or International fax 414-671-3976.


ACCESSORIES

An accessory flue gas diverter hood model PMGH-60 is available from Hatco that can be placed directly on top of the PMG-60 Booster Heater. This hood will re-direct flue products exiting the heater a distance of up to 20' (6.1 m) within the same room to be exhausted under a ventilation hood.

NOTE: The PMGH-60 diverter is not a substitute for a kitchen ventilation hood system.

NOTE: Model PMGH-60 requires a separate electrical connection.

REPLACEMENT PARTS LIST



REPLACEMENT PARTS LIST

PARTS COMMON TO ALL PMG-60 MODELS

ITEM	DESCRIPTION	PART NO.	QTY.	ITEM	DESCRIPTION	PART NO.	QTY.
1	Low Water Cut Off Board 120V	R02.01.210.00	1	25	NAT Gas Orifice #55	03.12.002.00	8
2	Relay 24VAC Relay DPDT	02.01.116.00	1	26	LP Gas Orifice #68*	03.12.003.00	8
3	Socket for Mini Relay	02.01.125.00	1	27	Burner Blade Assembly	R03.12.007.00	1
4	Sectional T-Block Complete	02.15.027.00	1	28	Heat Exchanger	R03.12.008.00	1
5	Tank High Limit, Manual Reset	02.16.116.00	1	29	Gas Manifold	03.12.009.00	1
6	Control Thermostat with Probe	R02.16.068.00	1	30	NAT Gas Pilot Assembly		
7	Temperature Control Probe	R02.16.069.00	1		with Orifice	03.12.010.00	1
8	Flame Rollout High Limit/			31	LP Gas Pilot Conversion -		
	Heat Exchanger High Limit	02.16.106.00	2		Orifice Only*	03.12.011.00	1
9	Transformer 120/24V (40VA)	02.17.034.00	1	32	6" (152 mm) Plastic Legs★	05.30.069.00	4
10	Toggle Switch, On/Off	R02.19.008A.00	1	33	6" (152 mm) Stainless Legs*	★ 05.30.070.00	4
11	Indicator Light, Green 120 Volt	02.19.070G.00	1	34	Water Manifold		
12	Indicator Light, Red 120 Volt	02.19.070R.00	1		3/4" Assembly	R03.04.004.00	1
13	Boot Cover, Toggle Switch	02.20.040.00	1	35	Tempering Tank	01.05.003.00	1
14	Pilot Spark Cable, High Voltage	02.21.019.00	1	36A	Pressure Reducing Valve,		
15	Back Pressure Relief Valve				Iron	03.02.004.00	1
	(Optional)	03.02.039.00	1	36B	Pressure Reducing Valve,		
16	Ignition Module	R02.21.022.00	1		Brass* (Optional)	03.02.015.00	1
17	Natural Gas Combination Valve	02.21.023.00	1	37	Temperature Pressure		
18	LP Gas Combination Valve -				Gauge	03.01.003.00	2
	Conversion Kit*	02.21.024.00	1	38	LP Gas Conversion Kit,		
19	Low Water Cut Off Probe	02.40.001.00	1		(Includes LP Gas Valve,		
20	T/P Relief Valve	03.02.020.00	1		Orifices and Pilot)*	R00.02.0004.00	1
21	Manual Shut Off Valve	03.02.025.00	1	39	Water Treatment Canister		
22	Pump Flange Kit with Bolts	03.05.026.00	1		and Cartridge	03.05.061.00	1
23	Recirculating Pump	R03.05.027.00	1	40	Cartridge Only	03.05.061A.00	1
24A	Flexible Water Lines†	03.05.049.00	2	41	O-Ring Gasket	03.05.061B.00	1
24B	Water Line Gasket*	05.06.066.00	4				

^{*} Not Shown

NOTE: Consult factory if replacing Orifices or Burner Assembly to ensure proper sizing.

NOTE: When calling for parts/service, please supply altitude of installation location and fuel type.

NOTE: The last four digits in a ten digit numerical serial number is the manufacturing date code.

Example: Serial number 1021059907 has a date code of 9907 which indicates the following: 9907

Year 1999

Please also note, effective January 2001 the serial number date code was changed to reflect the year and week of manufacture.

Example: xxxxxx 0124

Year 2001

Week twenty-four


PARTS COMMON TO ALL PMGH-60 MODELS

ITE	M DESCRIPTION	PART NO.	QTY.	ITEM	DESCRIPTION	PART NO.	QTY.
А	Blower Motor - 120 Volt	02.12.001.00	1	В	On/Off Rocker Switch	02.19.080.00	1

[★]Units manufactured in October 1999 or before use part number 04.01.013.00 for the replacement leg.

[†] Gasket should be replaced at each joint being serviced using Item #24B.

WIRING DIAGRAM



HATCO LIMITED WARRANTY

1. PRODUCT WARRANTY

Hatco warrants the products that it manufactures (the "Products") to be free from defects in materials and workmanship, under normal use and service, for a period of one (1) year from the date of purchase when installed and maintained in accordance with Hatco's written instructions or 18 months from the date of shipment from Hatco. Buyer must establish the product's purchase date by returning Hatco's Warranty Registration Card or by other means satisfactory to Hatco in its sole discretion.

Hatco warrants the following Product components to be free from defects in materials and workmanship from the date of purchase (subject to the foregoing conditions) for the period(s) of time and on the conditions listed below:

a) One (1) Year Parts and Labor PLUS One(1) Additional Year Parts-Only Warranty:

Toaster Elements (metal sheathed)
Drawer Warmer Elements (metal sheathed)
Drawer Warmer Drawer Rollers and Slides
Food Warmer Elements (metal sheathed)
Display Warmer Elements (metal sheathed
air heating)

Holding Cabinet Elements (metal sheathed air heating)

- b) One (1) Year Parts and Labor PLUS Four (4) Years Parts-Only Warranty on pro-rated terms that Hatco will explain at Buyer's request: 3CS and FR Tanks
- c) One (1) Year Parts and Labor PLUS Nine
 (9) Years Parts-Only Warranty on:
 Electric Booster Heater Tanks
 Gas Booster Heater Tanks

THE FOREGOING **WARRANTIES ARE** EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR PATENT OR OTHER INTELLECTUAL PROPERTY RIGHT INFRINGEMENT. Without limiting the generality of the foregoing, SUCH WARRANTIES DO NOT COVER: Coated incandescent light bulbs, fluorescent lights, lamp warmer heat bulbs, glass components, Product failure in booster tank, fin tube heat exchanger, or other water heating equipment, by liming, sediment buildup, chemical attack or freezing, Product misuse. tampering misapplication, improper installation or application of improper voltage.

2. LIMITATION OF REMEDIES AND DAMAGES

Hatco's liability and Buyer's exclusive remedy hereunder will be limited solely, at Hatco's option, to repair or replacement by a Hatco-authorized service agency (other than where Buyer is located outside of the United States, Canada, United Kingdom or Australia in which case Hatco's liability and Buyer's exclusive remedy hereunder will be limited solely to replacement of part under warranty) with respect to any claim made within the applicable warranty period referred to above. Hatco reserves the right to accept or reject any such claim in whole or in part. Hatco will not accept the return of any Product without prior written approval from Hatco, and all such approved returns shall be made at Buyer's sole expense. HATCO WILL NOT BE LIABLE, **UNDER** ANY CIRCUMSTANCES, FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, INCLUDING BUT NOT LIMITED TO LABOR COSTS OR LOST **PROFITS** RESULTING FROM THE USE OF OR INABILITY TO USE THE PRODUCTS OR FROM THE PRODUCTS BEING INCORPORATED IN OR BECOMING A COMPONENT OF ANY OTHER PRODUCT OR GOODS.

HATCO AUTHORIZED PARTS DISTRIBUTORS

NEW YORK TENNESSEE ALABAMA INDIANA Jones McLeod Appl. Svc. Acme American Repairs, Inc. Camp Electric GCS Service Memphis 901-527-7543 Birmingham 205-251-0159 Indianapolis 317-545-9655 Brooklyn 718-456-6544 **ARIZONA** IOWA Alpro Service Co. **TEXAS** 718-386-2515 Brooklyn Stove Parts Supply Flectric Motor Service Co. Auth. Comm. Food Equip. 817-831-0381 Fort Worth Phoenix 602-234-2443 Davenport 319-323-1823 Appliance Installation Buffalo 716-884-7425 Armstrong Repair Service Byassee Equipment Co. Goodwin Tucker Group 713-666-7100 602-252-0402 Des Moines 515-262-9308 Northern Parts Dist. Houston Phoenix Plattsburgh 518-563-3200 Commercial Kitchen Repair Co. **KENTUCKY CALIFORNIA** 210-735-2811 San Antonio J.B. Brady, Inc. GCS Service Industrial Electric 315-422-9271 Syracuse Louisville 502-367-1788 <u>UTAH</u> 714-379-7100 **Huntington Beach NORTH CAROLINA** La Monica's Rest Equip Service Chapman Appl. Service **LOUISIANA** 619-298-7106 Authorized Appliance Murray 801-263-3221 San Diego Chandlers Parts & Service Charlotte 704-377-4501 **VIRGINIA** 225-272-6620 P & D Appliance Baton Rouge S. San Francisco 650-635-1900 <u>OHIO</u> Daubers **MARYLAND** Norfolk 757-855-4097 Akron/Canton Comm. Svc. Inc. Electric Motor Service 330-753-6635 Akron Daubers Hawkins Commercial Appliance Baltimore 410-467-8080 Springfield 703-866-3600 303-781-5548 Certified Service Center Englewood GCS Service 513-772-6600 Cincinnati WASHINGTON Silver Spring 301-585-7550 **DELAWARE** Commercial Parts and Service Restaurant Appl. Service Food Equipment Service **MASSACHUSETTS** 614-221-0057 Columbus 206-524-8200 Seattle Wilmington 302-996-9363 Ace Service Co., Inc. Electrical Appl. Repair Service **WISCONSIN** 781-449-4220 Needham **FLORIDA** 216-459-8700 Independence A.S.C., Inc. Whaley Foodservice Repair **MICHIGAN** E. A. Wichman Co. 608-246-3160 Madison Jacksonville 904-725-7800 Commercial Kitchen Service Toledo 419-385-9121 A.S.C., Inc. Universal Restaurant Services Bay City 517-893-4561 **OKLAHOMA** 414-543-6460 Milwaukee 305-593-5488 Miami Bildons Appliance Service Hagar Rest, Service, Inc. Nass Service Co., Inc. 248-478-3320 Detroit Oklahoma City 405-235-2184 Orlando 407-425-2681 Midwest Food Equip. Service **CANADA** Krueger, Inc. BGSI Grandville 616-261-2000 Oklahoma City 405-528-8883 Pompano Beach 954-971-0456 **MINNESOTA OREGON** Comm. Appliance Service **BRITISH COLUMBIA** GCS Service 813-663-0313 Bressie Electric Co. Tampa Key Food Equipment Service 612-546-4221 Minneapolis 503-231-7171 Portland 604-433-4484 **GEORGIA** Vancouver **MISSOURI** Ron's Service, Inc. **MANITOBA** TWC Services General Parts 503-624-0890 Portland 770-438-9797 Smyrna Denko Mechanical Ltd. Kansas City 816-421-5400 **PENNSYLVANIA** 204-233-8003 Heritage Service Group Winnipea Commercial Kitchen Services Elmer Schultz Services 866-388-9837 Norcross **ONTARIO** St. Louis 314-890-0700 Philadelphia 215-627-5401 Southeastern Rest. Svc. R.G. Henderson Ltd. Kaemmerlen Parts & Service FAST Comm. Appl. Service 770-446-6177 Norcross 416-422-5580 Toronto St. Louis 314-535-2222 215-288-4800 Philadelphia <u>HAWAII</u> Choquette CKS **NEBRASK**A GCS Service 613-739-8458 Ottawa Burney's Comm. Service, Inc. 412-787-1970 Anderson Electric Pittsburgh Honolulu 808-848-1466 **QUÉBEC** Omaha 402-341-1414 K & D Service Co. Food Equip Parts & Service Choquette CKS 717-236-9039 Harrisburg **NEVADA** 808-847-4871 Honolulu Montreal 514-722-2000 Electric Repair Co. Burney's Commercial **ILLINOIS** Choquette CKS 610-376-5444 Reading 702-736-0006 Las Vegas 418-681-3944 Québec City Parts Town **RHODE ISLAND** Hi. Tech Commercial Service 708-865-7278 Lombard N. Las Vegas 702-649-4616 Marshall Electric Co. Eichenauer Elec. Service 401-331-1163 **NEW JERSEY** Providence 217-429-4229 Decatur **SOUTH CAROLINA** Jay Hill Repair Midwest Elec. Appl. Service 973-575-9145 Fairfield Whaley Foodservice Repair **Elmhurst** 630-279-8000 W. Columbia 803-791-4420 Service Plus Cone's Repair Service

HATCO CORPORATION

973-691-6300

P.O. Box 340500, Milwaukee, WI 53234-0500 U.S.A. (800) 558-0607 (414) 671-6350

Parts & Service Fax (800) 690-2966 Int'l. Fax (414) 671-3976 www.hatcocorp.com

Moline

Flanders

309-797-5323