

Star Manufacturing International Inc.

10 Sunnen Drive St. Louis, MO 63143

Phone: (314) 781-2777 Fax: (314) 781-3636 Installation and Operating Instructions

2M-Z1436 Rev. B 6/25/02

STAR-MAX ELECTRIC HOT PLATE MODELS 502A AND 502FA



Model 502A



Model 502FA







SAFETY SYMBOL



This symbol is intended to alert the user to the presence of important operating and maintenance instructions in the manual accompanying the appliance.

RETAIN THIS MANUAL FOR FUTURE REFERENCE

NOTICE

Using any part other than genuine Star factory supplied parts relieves the manufacturer of all liability.

NOTICE

Star reserves the right to change specifications and product design without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions or replacements for previously purchased equipment.

MAINTENANCE AND REPAIRS

Contact your local authorized service agent for service or required maintenance. Refer to the authorized service center listing provided with the unit. The Star Service Help Desk (1-800-807-9054) is available during normal business hours to answer any questions that may arise. Please have your model number and serial number for faster service.

GENERAL OPERATING INSTRUCTIONS



CAUTION

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations. For equipment to be used by the general public, please contact the factory.

The Star-Max models 502A and 502FA Electric Hot Plates are equipped for the voltage indicated on the nameplate mounted on the front panel. This unit is designed to operate on alternating current (A.C.), two wire single phase service only. **DO NOT CONNECT TO DIRECT CURRENT (D.C.).**

Total Connected Load

502FA - at 240 Volts, Wattage is 5200. at 208 Volts, Wattage is 3900.

502A - at 240 Volts, Wattage is 4200. at 208 Volts, Wattage is 3150.

INSTALLATION

For your protection, we recommend that a qualified electrician install this appliance. The electrician should be familiar with electrical installations and your local electrical requirements. The external wiring should be in conduit or an approved type of flexible cable and of suitable size to carry the load. The supply circuit should be properly fused and equipped with a means of disconnecting as required by local electrical code. The body of the hot plate should be grounded (Do not ground to a gas supply pipe). The connections are made in this unit at the pigtail leads located in the junction box on the back of the unit. To gain access to the pigtail leads remove cover on junction box.

LOCATE THE UNIT

Do not install the unit closer than 1 inch from a side wall and/or closer than 1 inch from a rear wall.

LEVELING UNIT

Level unit by adjusting the (4) feet for accurate and perfect line up with other Star-Max series units.



CAUTION

OPERATING PROCEDURE

DO NOT INSTALL WITHOUT FEET.



CAUTION

USE ONLY FLAT BOTTOM PANS AND POTS! DO NOT USE RAISED BOTTOM UTENSILS OR BUCKETS! GOOD HEAT TRANSFER DEPENDS UPON GOOD CONTACT BETWEEN THE ELEMENT AND POT.

Two (2) heating elements are used. For the 502FA each element draws 2600 watts on 240 Volts and 1950 watts on 208 Volts. For the 502A each element draws 2100 watts on 240 Volts and 1575 watts on 208 Volts. Each element is controlled by an infinite position switch. The right control knob controls the rear cooking element and the left control knob controls the front cooking element. On "HI" the element delivers uninterrupted full heat. Between "LO" and "5" any desired amount of heat can be obtained between 6% and 60% of full heat.

Signal lights are provided above the control knobs to give a visual check if either one or both heating units are turned on.

CLEANING

The exterior surfaces can be kept clean and attractive by regularly wiping with a clean soft cloth. Any discoloration can be removed with a non-abrasive cleaner.

For model 502A, the heating elements may be raised for access to the drip pans, which may be removed for cleaning and the bottom pan may be removed by sliding pan forward.

REPLACEMENT OF INFINITE CONTROL

BE SURE POWER IS DISCONNECTED BEFORE ATTEMPTING TO SERVICE UNIT.

- Pull control knobs on front panel forward to remove.
- 2. Remove 4 screws from front panel and tilt front panel forwards.
- 3. Remove the nut that mounts the inoperative control and pull the control to the side.
- 4. Remove one wire at a time from the inoperative control and connect at the same terminal on the new control. Carefully check to see that proper wires have been connected to the terminals of the control. See attached wiring diagram.
- 5. Assemble new control to the front panel.

MAINTENANCE AND REPAIRS

Contact the factory or one of its representatives or a local service company for service or maintenance if required.

Visit our Website at: www.star-mfg.com Email: service@star-mfg.com For Fax-On-Demand Literature: (800) 807-9814 THOROUGHLY INSPECT YOUR UNIT ON ARRIVAL

This unit has been tested for proper operation before leaving our plant to insure delivery of your unit in perfect condition. However, there are instances in which the unit may be damaged in transit. In the event you discover any type of damage to your product upon receipt, you must immediately contact the transportation company who delivered the item to you and initiate your claim with same. If this procedure is not followed, it may affect the warranty status of the unit.

LIMITED EQUIPMENT WARRANTY

All workmanship and material in Star products have a one (1) year limited warranty on parts & labor in the United States and Canada. Such warranty is limited to the original purchaser only and shall be effective from the date the equipment is placed in service. Star's obligation under this warranty is limited to the repair of defects without charge, by the factory authorized service agency or one of its sub-agencies. Models that are considered portable (see below) should be taken to the closest Star service agency, transportation prepaid.

- > Star will not assume any responsibility for loss of revenue.
- > On all shipments outside the United States and Canada, see International Warranty.
- * The warranty period for the JetStar series six (6) ounce popcorn machines is two (2) years.
- * The warranty period for the Chrome-Max Griddles is five (5) years on the griddle surface. See detailed warranty provided with unit.
- * The warranty period for Teflon/Dura-Tec coatings is one year under normal use and reasonable care. This warranty does not apply if damage occurs to Teflon/Dura-Tec coatings from improper cleaning, maintenance, use of metallic utensils, or abrasive cleaners. This warranty does not apply to the "non-stick" properties of such materials.
- > This warranty does not apply to "Special Products" but to regular catalog items only. Star's warranty on "Special Products" is six (6) months on parts and ninety (90) days on labor.
- > This warranty does not apply to any item that is disassembled or tampered with for any purpose other than repair by a Star Authorized Service Center or the Service Center's sub-agency.
- > This warranty does not apply if damage occurs from improper installation, misuse, wrong voltage, wrong gas or operated contrary to the Installation and Operating instructions.

PARTS WARRANTY

Parts that are sold to repair out of warranty equipment are warranted for ninety (90) days. The part only is warranted. Labor to replace the part is chargeable to the customer.

SERVICES NOT COVERED BY WARRANTY

- 1. Travel time and mileage rendered beyond the 50 mile radius limit
- 2. Mileage and travel time on portable equipment (see below)
- 3. Labor to replace such items that can be replaced easily during a daily cleaning routine, ie; removable kettles on fryers, knobs, grease drawers on griddles, etc.
- Installation of equipment
- Damages due to improper installation
- 6. Damages from abuse or misuse
- 7. Operated contrary to the Operating and Installation Instructions
- Cleaning of equipment 8.
- Seasoning of griddle plates

- 10. Voltage conversions
- 11. Gas conversions
- 12. Pilot light adjustment
- 13. Miscellaneous adjustments
- 14. Thermostat calibration and by-pass adjustment
- 15. Resetting of circuit breakers or safety controls
- 16. Replacement of bulbs
- 17. Replacement of fuses
- 18. Repair of damage created during transit, delivery, & installation OR created by acts of God

PORTABLE EQUIPMENT

Star will not honor service bills that include travel time and mileage charges for servicing any products considered "Portable" including items listed below. These products should be taken to the Service Agency for repair:

* The Model 510F Fryer.

- * The Model CFS Series Food Steamer. * The Model 526WO Warming Oven.
- * The Model 526TO Toaster Oven.
- * The Model J4R, 4 oz. Popcorn Machine.
- * The Model 518CM & 526CM Cheese Melter.
- * The Model 12NCPW & 15NCPW Nacho Chip/Popcorn Warmer.
- * All Hot Dog Equipment except Roller Grills & Drawer Bun Warmers.
- * All Nacho Cheese Warmers except Model 11WLA Series Nacho Cheese Warmers.
- * All Condiment Dispensers except the Model CSD Series Chili/Cheese Dispenser.
- * All Specialty Food Warmers except Model 130R, 500, 11RW Series, and 11WSA Series.
- **ALL:**
- * Pop-Up Toasters
- * Butter Dispensers
- * Pretzel Merchandisers
 - * Pizza Ovens


* Sneeze Guards


- * Pastry Display Cabinets
- * Heat Lamps * Hot Cups
- * Nacho Chip Merchandisers * Accessories of any kind
- * Pumps

The foregoing warranty is in lieu of any and all other warranties expressed or implied and constitutes the entire warranty.

FOR ASSISTANCE

Should you need any assistance regarding the Operation or Maintenance of any Star equipment; write, phone, fax or email our Service Department. In all correspondence mention the Model number and the Serial number of your unit, and the voltage or type of gas you are using.





MODEL 502 STAR-MAX ELECTRIC HOT PLATE


KEY NUMBER	PART NUMBER	NUMBER PER UNIT	DESCRIPTION
		22 1 1 1 2 2 2 4 1 1 1 1 4 2 2 2 2 4 1	SHIELD-KNOB KNOB-THERMOSTAT EMBLEM-STAR PANEL, VINYL FRONT PANEL PILOT LIGHT CONTROL-INFINITE 240V ADAPTER-TERMINAL LEG SLIDE, DRAWER DRAWER BACK WELD ASSEMBLY COVER, HANDY BOX TERMINAL-GROUND BUSHING COVER-TERMINAL BLOCK ELEMENT W/Ceramic Block PAN-REFLECTOR RING-ELEMENT ADAPTER CHAIN STRAIN RELIEF TOP WELD ASSEMBLY

*SUGGESTED PARTS STOCKING-

IMPORTANT: WHEN ORDERING SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER-(1) MINIMUM PARTS ORDER-\$5.00

PAGE 1





MODEL 502F

PARIS LISI

MODEL 502F STAR-MAX ELECTRIC FRENCH HOT PLATE

KEY NUMBER	PART NUMBER	NUMBER PER UNIT	DESCRIPTION	
1 2 3 4 5 6 7 8 9 10 11 12 13	2R-8229 2R-9781 2M-Y7134 I3-Y7454 I3-Y7602 2J-Y7114 2J-6403 2C-9938 2R-Y5092 I3-502010 G3-Y7788 2C-Y2344 2K-8043 I1-162117 I3-502002 2N-Y3301	221112224 1114 212	SHIELD-KNOB KNOB-THERMOSTAT EMBLEM-STAR PANEL, VINYL FRONT PANEL PILOT LIGHT CONTROL-INFINITE 240V ADAPTER-TERMINAL LEG BACK WELD ASSEMBLY COVER, HANDY BOX TERMINAL-GROUND BUSHING CLAMP ASSEMBLY TOP WELD ASSEMBLY ELEMENT	

*SUGGESTED PARTS STOCKING-

IMPORTANT: WHEN ORDERING SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER-(1) MINIMUM PARTS ORDER-\$5.00

PAGE 1

