HENNY PENNY Model HC-941

SECTION 5. PARTS INFORMATION

5-1. INTRODUCTION

This section identifies and lists the replaceable parts of the Henny Penny Multipurpose Holding Cabinets.

5-2. GENUINE PARTS

Use only genuine Henny Penny parts in your cabinet. Using a part of lesser quality or substitute design may result

5-3. HOW TO FIND PARTS

To find parts you want to order from the Parts List proceed as follows:

- 1. Refer to the exploded drawing in this section to identify
- 2. Use the item number from the exploded drawing to locate the corresponding part in the Parts List in this section. In this list will be the Henny Penny part number and a description of the part.

5-4. HOW TO ORDER

Once the part you want to order has been found in the Parts List, write down the following information:

1. From the Parts List:

(Sample)

Item Number 16
Part Number 27534
Description Slide Vent

2. From the data plate:

(Sample)

 Product Number
 05126

 Serial Number
 0001

 Voltage
 120V

5-5. PRICES

5-6. DELIVERY

Your independent Henny Penny distributor has a price parts list and will be glad to inform you of the cost of your parts order.

Commonly replaced items are stocked by your independent Henny Penny distributor and will be sent out when your order is received. Other parts will be ordered by the distributor from Henny Penny Corporation. Normally, these will be sent to your distributor within three working days.

5-7. WARRANTY


All replacement parts (except lamps and fuses) are covered under warranty for 90 days against manufacturing defects and workmanship. If damage occurs during shipping, notify the carrier at once so that a claim may be properly filed. Refer to warranty on the front of this section for other rights and limitations.

5-8. RECOMMENDED

SPARE PARTS FOR
DISTRIBUTORS

Recommended replacement parts, stocked by your distributor, are indicated with $\sqrt{}$ in the parts lists. Please use care when ordering recommended parts, because all voltages and variations are marked. Distributors should order parts based upon common voltages and equipment sold in their territory.

306 5-1



Model 05524 (No Vents)

Part No.	Description	Qty.
44319 44315 44311 44324 44305 44031 49112 PL01-001 EF02-049 44323 44341 05031 41539	Shell Stud Weld Assy. Drawer Frame Assy. Drawer Front Drawer Assy. Decal Heater Power Cord Chrome Plug - 1/2" Strain Relief Thermometer Bulb Cover Pan Insert Pan Bracket - Thermometer	1 1 1 1 2 1 1 1 1 1

1 276		
1 1	Shell Stud Weld Assembly	1
2 275	,	1
3 2762	l l	1
√ 4 141	· · · · · · · · · · · · · · · · · · ·	1
8 2884		1 1
9 SC0		4
10 SC0	, "	2
1 1	Lockwasher #10 Internal	2
$\sqrt{12}$ 275	"	1 1
13 NSC		6
14 275		2
15 2750	_	2
16 2753		2
17 3139		1
18 2883	· · · · · · · · · · · · · · · · · · ·	1
19 SC0		2
20 2754		1
$\sqrt{21}$ 1662		1
22 276		1
22 446		1
23 2760		1
24 276	,	1
25 SC0	1	6
26 2760	1 "	1
27 NS0		*
28 2762		1
$\sqrt{29}$ 2219	1	1
30 SC0		2
31 2590	· · · · · · · · · · · · · · · · · · ·	1
$\sqrt{32}$ 1413		1
33 NS0	005 Nut Hex Keps #6-32 C	2
34 NS0		*
35 SC0	014 Screw #8 - AB x 3/8 PH THD S	5
36 2752	Brace - Heater	2
37 2752		2
√38 2758	Heater - HHC 120 V, 480 W	2
39 2643	Foot Leveler	4
40 2251	Clip Thermostat Bulb Mtg.	1
41 276	Plate - Side Access	2
42 1506	Cord, Electric	1
43 EFC	O17 Strain Relief 11/32	1
44 MS0	Receptacle NEMA 5-15 R	1
45 2764	1	2
46 SC0		2
47 NS0	1 "	3
48 2882		1
49 EF0		1
50 NS0	* "	2
51 4153	<u> </u>	1
$\sqrt{52}$ 2882		1
52 3304	Cover - Glass - Thermometer	1