


HHS-983 (983 stand) PARTS LIST



<u>Item No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Qty. P/U</u>
1	24389	Assy – Leg & Support Weldment - Tall - Caster	1
1	24956	Assy – Leg & Support Weldment - Caster	1
1	27410	Assy – Leg & Support Weldment - Tall - Leg	1
1	24886	Assy – Leg & Support Weldment - Leg	1
2	23791	Caster – 5” Expan. Stem w/Lock	2
3	23790	Caster – 5” Expan. Stem w/o Lock	2
4	24852	Cover – Enclosure (before Jan. '04)	1
5	36627	Counter Weight Bar (before Jan. '04)	6
6	27400	Assy – Enclosure – Table – Tall (before Jan. '04)	1
7	26120	Foot – Adjustable	4
8	43100	Plate – Counter Weight (Jan. '04 & after)	9-std/13-tall
9*	NS02-002	Nut – Keps ¼-20 C	15

FM06-034
09-07-05