

SECTION 4. PARTS INFORMATION

4-1. INTRODUCTION This section lists the replaceable parts of the Henny Penny

MPC-554 units.

4-2. GENUINE PARTS Use only genuine Henny Penny parts in your cabinet. Using

a part of lesser quality or substitute design may result in

damage to the unit, or personal injury.

4-3. WHEN ORDERING PARTS Once the parts that you want to order have been found in the

parts list, write down the following information:

Example: Item Number 8

Part Number <u>63464</u>

Description Switch - Power

From data plate, list the following information:

Example: Product Number MPC554

Serial Number <u>AW001IE</u> Voltage <u>120 Volt</u>

4-4. PRICES Your distributor has a price list and will be glad to inform

you of the cost of your parts order.

4-5. DELIVERY Commonly replaced items are stocked by your local

distributor and will be sent out when your order is received. Other parts will be ordered, by your distributor, from Henny

Penny Corporation.

4-6. WARRANTY All replacement parts (except lamps and fuses) are warranted

for 90 days against manufacturing defects and workmanship. If damage occurs during shipping, notify the carrier at once so that a claim may be properly filed. Refer to warranty in the front of the manual for other rights and limitations.

the front of the mandar for other rights and miniations.


4-7. RECOMMENDED
SPARE PARTS FOR


DISTRIBUTORS

Recommended replacement parts, stocked by your distributor, are indicated with $\sqrt{}$ in the parts lists. Please use care when ordering recommended parts, because all voltages and variations are marked. Distributors should order parts based upon common voltages and equipment sold in their territory.

607 4-1







Item No.		Part No.	Description	Quantity
1	1	30978	Transformer Assembly - 120VP-12VS-20VP	1
\checkmark	2	40645	Relay - 25A - Solid State	3
\checkmark	3	73602	Control - MPC554	1
\checkmark	4	71851	Drawer - Small MPC	10
1	5	71850	Drawer - Large MPC	4
	6	53656	Cord - Power	1
	7	74129	Decal - Power Switch - Left	1
	7	72774	Decal - Power Switch - Right	1
\checkmark	8	63464	Switch - Power	1
1	9	LS72-000	Indicator - Bi-Color Panel Mount	1
	10	69608	Decal - MPC554 Control	1
	11	14910	Kit - MPC554 Liner/Heater - Long - Top	1
	12	14911	Kit - MPC554 Liner/Heater - Long - Bottom	1
	13	14912	Kit - MPC554 Liner/Heater - Short	1
	14	ME50-021	Terminal Block (not shown)	2

4-2 607