

Cheesemelter Mounting Instructions

Models: 124CM
136CM
148CM

NOTE

The back panel is packaged separately from the cheesemelter. The screws used to attach the back panel are screwed into the rear edge of the cheesemelter.


Wall Mounting

1. Remove the four (4) screws from the back and wall mounting bracket of the cheesemelter.
2. Separate the wall mounting bracket from the back of the cheesemelter.
3. Remove the insulation from the back.

NOTE

The mounting screws are not supplied. Ensure the mounting screws are a suitable size to mount the cheesemelter to the wall.

4. Position the wall mounting bracket on the wall with the offset at the top.
5. Using a screwdriver, install the four (4) screws into the wall mounting bracket and wall.
6. Remove the six (6) screws from the rear of the cheesemelter.
7. Place the back onto the cheesemelter with the offset at the top.
8. Using a screwdriver, install the six (6) screws into the back of the cheesemelter.
9. Install the insulation into the back of the cheesemelter.
10. Using an assistant, position the cheesemelter into the wall mounting bracket.
11. While the assistant holds the cheesemelter, install the four (4) screws into the sides of the cheesemelter.
12. Using a screwdriver, tighten the four (4) screws.



Counter Mounting

1. Remove the six (6) screws from the back and wall mounting bracket of the cheesemelter.
2. Separate the wall mounting bracket from the back of the cheesemelter.
3. Remove the insulation from the back.
4. Install the back onto the cheesemelter using the six (6) screws. Tighten the screws with a screwdriver.
5. Install the insulation into the back.
6. Place the wall mounting bracket onto the cheesemelter back.
7. Install the four (4) screws into the sides of the cheesemelter.
8. Tighten the four (4) screws with a screwdriver.
9. Set the cheesemelter on the counter.