

MODEL 5124CD & 5136CD

Installation and Operation Instructions

2M-Z6127 Rev. C 12/27/05



5124CD







These symbols are intended to alert the user to the presence of important operating and maintenance instructions in the manual accompanying the appliance.

RETAIN THIS MANUAL FOR FUTURE REFERENCE

NOTICE

Using any part other than genuine Star factory supplied parts relieves the manufacturer of all liability.

Star reserves the right to change specifications and product design without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions or replacements for previously purchased equipment.

Due to periodic changes in designs, methods, procedures, policies and regulations, the specifications contained in this sheet are subject to change without notice. While Star Manufacturing exercises good faith efforts to provide information that is accurate, we are not responsible for errors or omissions in information provided or conclusions reached as a result of using the specifications. By using the information provided, the user assumes all risks in connection with such use.

MAINTENANCE AND REPAIRS

Contact your local authorized service agent for service or required maintenance. Please record the model number, serial number, voltage and purchase date in the area below and have it ready when you call to ensure faster service.

Reference the listing provided with the unit		
81-2777		
tandard Time		
81-2777		
81-2714		
al Inc.		
78		

Type:Infinite Control, 2 Controls, 6.6 KW, 396 sq. in. (2555 sq. cm) Grid AreaWeight:Installed - 98 lb. (45 kg); Shipping - 145 lb. (66 kg)Dimensions:24" W x 25 5/8" D x 14 1/4" H (61cm W x 65cm D x 36cm H)Volts:240V, 3 PH 240V, 3 PH 240V, 1 PH 240V, 1 PH Amps:x - 18.8 y - 18.8 z - 11.9 240V, 3 PH 240V, 3 PH 208V, 3 PH Amps:S136CDType:Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid AreaWeight:Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg)Dimensions:36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H)Volts:240V, 3 PH 240V, 3 PH 240V, 3 PH 240V, 3 PH 25 /8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H)Volts:240V, 3 PH 240V, 4 PH 24	5124CD							
Dimensions: $24" W \times 25 5/8" D \times 14 1/4" H$ (61cm W x 65cm D x 36cm H)Volts: $240V, 3 PH$ Amps: x - 18.8 y - 18.8 z - 11.9 $240V, 1 PH$ Amps: 27.5 $208V, 3 PH$ Amps: x - 21.8 y - 21.8 z - 13.8 $208V, 1 PH$ Amps: 31.8 5136CD Type:Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid Area Weight:Unstalled - 175 lb (80 kg); Shipping - 215 lb. (98 kg)Dimensions: $36" W \times 25 5/8" D \times 14 1/4"H$ (91 cm W x 65 cm D x 36 cm H)Volts: $240V, 3 PH$ Amps: x - 23.9 y - 23.9 z - 23.9 $240V, 1 PH$ Amps: 41.3	Туре:	Infinite Control, 2 Controls, 6.6 KW, 396 sq. in. (2555 sq. cm) Grid Area						
Volts: $(61 \text{cm W} \times 65 \text{cm D} \times 36 \text{cm H})$ Volts: $240\text{V}, 3 \text{ PH}$ Amps: $x - 18.8 \text{ y} - 18.8 \text{ z} - 11.9$ $240\text{V}, 1 \text{ PH}$ Amps: 27.5 $208\text{V}, 3 \text{ PH}$ Amps: $x - 21.8 \text{ y} - 21.8 \text{ z} - 13.8$ $208\text{V}, 1 \text{ PH}$ Amps: 31.8 5136CD Type:Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid AreaWeight:Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg)Dimensions: $36^{"} \text{ W} \times 25 5/8" \text{ D} \times 14 1/4"\text{ H}$ (91 cm W $\times 65 \text{ cm D} \times 36 \text{ cm H})$ Volts: $240\text{V}, 3 \text{ PH}$ Amps: $x - 23.9 \text{ y} - 23.9 \text{ z} - 23.9$ $240\text{V}, 1 \text{ PH}$ Amps: 41.3	Weight:	Installed - 98 lb. (45 kg); Shipping - 145 lb. (66 kg)						
Volts: 240V, 3 PH Amps: x - 18.8 y - 18.8 z - 11.9 240V, 1 PH Amps: 27.5 208V, 3 PH Amps: x - 21.8 y - 21.8 z - 13.8 208V, 3 PH Amps: x - 21.8 y - 21.8 z - 13.8 208V, 1 PH Amps: 31.8 5136CD Type: Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid Area Weight: Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg) Dimensions: 36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H) Y - 23.9 z - 23.9 Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: x - 23.9 y - 23.9 z - 23.9	Dimensions:	24" W x 25 5/8" D x 14 1/4" H						
$\begin{array}{rrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrrr$		(61cm W x 65cm D x 36cm H)						
$\begin{array}{rllllllllllllllllllllllllllllllllllll$	Volts:	240V, 3 PH Amps: x - 18.8 y - 18.8 z - 11.9						
208V, 1 PH Amps: 31.8 5136CD Type: Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid Area Weight: Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg) Dimensions: 36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H) Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3		240V, 1 PH Amps: 27.5						
5136CD Type: Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid Area Weight: Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg) Dimensions: 36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H) Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3		208V, 3 PH Amps: x - 21.8 y - 21.8 z - 13.8						
Type: Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid Area Weight: Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg) Dimensions: 36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H) Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3		208V, 1 PH Amps: 31.8						
Weight: Installed - 175 lb (80 kg); Shipping - 215 lb. (98 kg) Dimensions: 36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H) Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3	5136CD							
Dimensions: 36" W x 25 5/8" D x 14 1/4"H (91 cm W x 65 cm D x 36 cm H) Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3	Туре:	Infinite Control, 3 Controls, 9.9 KW, 594 sq. in (3832 sq. cm) Grid Area						
(91 cm W x 65 cm D x 36 cm H) 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3	Weight:							
Volts: 240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9 240V, 1 PH Amps: 41.3	Dimensions:							
240V, 1 PH Amps: 41.3		(91 cm W x 65 cm D x 36 cm H)						
	Volts:	240V, 3 PH Amps: x - 23.9 y - 23.9 z - 23.9						
		240V, 1 PH Amps: 41.3						
208V, 3 PH Amps: x - 27.6 y - 27.6 z - 27.6		208V, 3 PH Amps: x - 27.6 y - 27.6 z - 27.6						
208V, 1 PH Amps: 47.6								

GENERAL INSTALLATION INSTRUCTIONS



CAUTION

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations.

Before using your new equipment, read and understand all the instructions & labels associated with the unit prior to putting it into operation. Make sure all people associated with its use understand the units operation & safety before they use the unit.

All shipping containers should be checked for freight damage both visible and concealed. This unit has been tested and carefully packaged to insure delivery of your unit in perfect condition. If equipment is received in damaged condition, either apparent or concealed, a claim must be made with the delivering carrier.

Concealed damage or loss - if damage or loss is not apparent until after equipment is unpacked, a request for inspection of concealed damage must be made with carrier within 15 days. Be certain to retain all contents plus external and internal packaging materials for inspection. The carrier will make an inspection and will supply necessary claim forms.

These Electric Char-broilers are equipped for the voltage and wattage indicated on the nameplate mounted on the front panel. These units are designed to operate on alternating current (AC) only. **DO NOT CONNECT TO DIRECT CURRENT (DC).**

INSTALLATION

The installation of this appliance should conform to the national electric code and local electric codes and ordinances and the local electric company rules and regulations.

For your protection, we recommend that a qualified electrician install this appliance. The electrician should be familiar with electrical installations and local electrical requirements. The external wiring should be in conduit or an approved type of flexible cable suitable for operation at 90° C and sized to carry the load. Use copper wire only. The supply circuit should be properly fused and equipped with a means of disconnecting as required by local electrical code. The body of the appliance should be grounded **(Do not ground to a gas supply pipe).**

- 1. Locate the unit: Do not install the unit closer than 12 inches from a side wall and/or closer than 9 inches from a rear wall.
- Level the char-broiler by adjusting the feet, which have provision for 1 inch of adjustment. This adjustment also allows a perfect alignment to be achieved with other Star-Max[™] units.
- 3. The pigtail leads can be accessed by removing the cover plate from the back of the broiler.
- 4. Fill the water pan on the broiler prior to use. Water should be flush with the bottom of the splash baffles. Make sure water is present in the pan at all times. Note: The pan is easily removable for cleaning.



CAUTION

CARE MUST BE TAKEN WHEN OPENING PAN TO PREVENT SPILLING.

- 5. The charbroiler is equipped with modular grates that are readily removable for cleaning. Each heated section is controlled by a separate heat control switch.
- 6. Seasoning Set the heat control switch to the low position and preheat for about 15 to 20 minutes. Using a cloth, spread a thin film of cooking oil over the top of the grate surface. Allow the film to remain on the grate for about 5 minutes. Wipe the surface clean and apply another film of cooking oil. Wipe the surface clean again. The broiler is now ready for use. The oil may tend to smoke this is normal.
- 7. Approximate grilling temperatures range from 350° F (with no product on the grill) on low setting to 570° F on high.

CLEANING

- 1. Clean with a clean soft cloth daily. Any discoloration can be removed with a non-abrasive cleaner.
- 2. Remove the water pan and cooking grates. Wash them in a sink.
- 3. To clean heating element, first remove the grates. Swing the element housing to a vertical position and lock it in place with the support located in the center. Clean the elements with a stiff wire brush or equivalent.
- 4. Heat baffles are located directly below the heating elements and are removable for cleaning in a sink.

Visit our Website at: www.star-mfg.com

Email: service@star-mfg.com

THOROUGHLY INSPECT YOUR UNIT ON ARRIVAL

This unit has been tested for proper operation before leaving our plant to insure delivery of your unit in perfect condition. However, there are instances in which the unit may be damaged in transit. In the event you discover any type of damage to your product upon receipt, you must immediately contact the transportation company who delivered the item to you and initiate your claim with same. If this procedure is not followed, it may affect the warranty status of the unit.

LIMITED EQUIPMENT WARRANTY

All workmanship and material in Star products have a one (1) year limited warranty on parts & labor in the United States and Canada. Such warranty is limited to the original purchaser only and shall be effective from the date the equipment is placed in service. Star's obligation under this warranty is limited to the repair of defects without charge, by the factory authorized service agency or one of its sub-agencies. Models that are considered portable (see below) should be taken to the closest Star service agency, transportation prepaid.

> Star will not assume any responsibility for loss of revenue.

- > On all shipments outside the United States and Canada, see International Warranty.
- * The warranty period for the JetStar six (6) ounce & Super JetStar eight (8) ounce series popcorn machines is two (2) years.
- * The warranty period for the Chrome-Max Griddles is five (5) years on the griddle surface. See detailed warranty provided with unit.
- * The warranty period for Teflon/Dura-Tec coatings is one year under normal use and reasonable care. This warranty does not apply if damage occurs to Teflon/Dura-Tec coatings from improper cleaning, maintenance, use of metallic utensils, or abrasive cleaners. This warranty does not apply to the "non-stick" properties of such materials.
- > This warranty does not apply to "Special Products" but to regular catalog items only. Star's warranty on "Special Products" is six (6) months on parts and ninety (90) days on labor.
- > This warranty does not apply to any item that is disassembled or tampered with for any purpose other than repair by a Star Authorized Service Center or the Service Center's sub-agency.
- > This warranty does not apply if damage occurs from improper installation, misuse, wrong voltage, wrong gas or operated contrary to the Installation and Operating instructions.
- > This warranty is not valid on Conveyor Ovens unless a "start-up/check-out" has been performed by a Factory Authorized Technician.

PARTS WARRANTY

Parts that are sold to repair out of warranty equipment are warranted for ninety (90) days. The part only is warranted. Labor to replace the part is chargeable to the customer.

SERVICES NOT COVERED BY WARRANTY

- 1. Travel time and mileage rendered beyond the 50 mile radius limit
- 2. Mileage and travel time on portable equipment (see below)
- Labor to replace such items that can be replaced easily during a daily cleaning 3. routine, ie; removable kettles on fryers, knobs, grease drawers on griddles, etc. 4. Installation of equipment
- Damages due to improper installation 5.
- Damages from abuse or misuse 6.
- Operated contrary to the Operating and Installation Instructions 7.
- Cleaning of equipment 8.
- 9 Seasoning of griddle plates

- 10. Voltage conversions
- 11. Gas conversions
- 12. Pilot light adjustment
- 13. Miscellaneous adjustments
- Thermostat calibration and by-pass adjustment 14.
- 15. Resetting of circuit breakers or safety controls or reset buttons
- 16. Replacement of bulbs
- 17. Replacement of fuses
- Repair of damage created during transit, delivery, & 18. installation OR created by acts of God

PORTABLE EQUIPMENT

Star will not honor service bills that include travel time and mileage charges for servicing any products considered "Portable" including items listed below. These products should be taken to the Service Agency for repair:


* The Model 510FD Fryer. * Pop-Up Toasters * The Model J4R, 4 oz. Popcorn Machine. * Butter Dispensers * The Model 518CMA & 526CMA Cheese Melter. * Pretzel Merchandisers * The Model 12MC & 15MC & 18MCP Hot Food Merchandisers. * Pastry Display Cabinets * Nacho Chip Merchandisers * The Model 12NCPW & 15NCPW Nacho Chip/Popcorn Warmer. * All Hot Dog Equipment except Roller Grills & Drawer Bun Warmers. * Accessories of any kind * All Nacho Cheese Warmers except Model 11WLA Series Nacho Cheese Warmer. * Sneeze Guards * All Condiment Dispensers except the Model HPDE, & SPDE Series Dispenser. * Pizza Ovens * All Specialty Food Warmers except Model 130R, 11RW Series, and 11WSA Series. * Heat Lamps * All QCS/RCS Series Toasters except Model QCS3 & RCS3 Series. * Pumps


The foregoing warranty is in lieu of any and all other warranties expressed or implied and constitutes the entire warranty.


FOR ASSISTANCE

Should you need any assistance regarding the Operation or Maintenance of any Star equipment; write, phone, fax or email our Service Department. In all correspondence mention the Model number and the Serial number of your unit, and the voltage or type of gas you are using.

- ALL:







MODELS	5124CD and 5136CD Electric Counter Char-Broilers
--------	--

Key	Part	Number Per			
Number	Number	Unit	Description and Model Designation		
1	H1-Z6117	1	ELEMENT HOUSING COVER	5124CD	
	H1-Z6118	1	ELEMENT HOUSING COVER	5136CD	
2	H1-Y3115	2	ELEMENT STRAP	5124CD	
	H1-Y3266	2	ELEMENT STRAP	5136CD	
3	2F-Z6858	2	SUPPORT WITH BUSHING		
4	21-7370	2	GASKET		
5	H1-Z6115	1	ELEMENT HOUSING	5124CD	
	H1-Z6116	1	ELEMENT HOUSING	5136CD	
6	2F-Y3107	4	TOP GRATE	5124CD	
	2F-Y3107	6	TOP GRATE	5136CD	
7	2A-5401	2	COTTER PIN		
8	2C-1811	2	WASHER		
9	H1-Z6122		PROP ROD BRACKET		
10	2P-7969	1	SPRING		
11	2N-Y3083	2/3	HEATING ELEMENT BENT 240V	5124CD / 5136CD	
	2N-Y3084	2/3	HEATING ELEMENT BENT 208V	5124CD / 5136CD	
12	2N-Y3085	2/3	HEATING ELEMENT 240V	5124CD / 5136CD	
	2N-Y3086	2/3	HEATING ELEMENT 208V	5124CD / 5136CD	
13	2A-Z6121	1	PROP ROD		
14	H1-Z6119	2	ELEMENT CLAMP	5124CD	
14	H1-Z6120	2	ELEMENT CLAMP	5136CD	
15	512400		TOP ASSEMBLY	5124CD	
10	513600		TOP ASSEMBLY	5136CD	
16	H1-Z6086	9	BAFFLE	5124CD	
10	H1-Z6086	15	BAFFLE	5136CD	
17	G3-Y7788	1	BOX COVER	3130CD	
18	2K-Z6183	3	BUSHING	5124CD	
10	2K-Z6183	5	BUSHING	5136CD	
19	2C-Y2344		GROUND LUG	3130CD	
20	2E-Y7327		ELECTRICAL BOX		
20	H1-Z6059		REAR ENCLOSURE	5124CD	
21	H1-Z6060		REAR ENCLOSURE	5124CD 5136CD	
22	G3-624303		SIDE LINER ASSEMBLY RIGHT	3130CD	
22	G3-Z5945	2			
23	H1-Z6173		SIDE PANEL BAFFLE FRAME REAR	5124CD	
24		1	BAFFLE FRAME REAR BAFFLE FRAME REAR	5124CD 5136CD	
25	H1-Z6085 H1-Z6084		BAFFLE FRAME REAR BAFFLE FRAME FRONT	5136CD 5124CD	
20	H1-Z6084 H1-Z6533	1			
26	G3-624302		BAFFLE FRAME FRONT SIDE LINER ASSEMBLY LEFT	5136CD	
26				5134CD	
27	H3-612400		LINER ASSEMBLY	5124CD	
20	H3-613600		LINER ASSEMBLY	5136CD	
28	2A-Z5942	4	FOOT		
29	G3-Z6036	2	DRAWER SLIDE	510400	
30	G3-Z5911		FRONT PANEL	5124CD	
	G3-Z5921		FRONT PANEL	5136CD	
31	VARIOUS		NAMEPLATE		
32	H1-Z6123	2	FOOT SUPPORT		
33	H3-Z6482	1	GREASE DRAWER	5124CD	
	H3-Z6483	1	GREASE DRAWER	5136CD	
34	2J-6403	2/3	INFINITE CONTROL	5124CD / 5136CD	
35	2M-Z6038	1	GRAPHIC PANEL	5124CD	
	2M-Z6040	1	GRAPHIC PANEL	5136CD	

IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER

PAGE	1
OF	2

Some items are included for illustrative purposes only and in certain instances may not be available.



R Star Manufacturing International, Inc.

Key Number	Part Number	Number Per Unit	Desc	ription and Model Designation		
36 37 38	2R-Z3436 2J-Y6690 H1-Z6082 H1-Z6083	2/3 2/3 1 1	KNOB PILOT LIGHT LINER COVER LINER COVER	5124CD / 5136CD 5124CD / 5136CD 5124CD / 5136CD 5124CD 5136CD		
39 40	H1-Z6054 H1-Z6056 H1-Z6059 H1-Z6060	1 1 1 1	REAR PANEL REAR PANEL FRONT ENCLOSURE FRONT ENCLOSURE	5124CD 5136CD 5124CD 5136CD		
NA	2E-Z6113 2E-Z6114	1	WIRE SET WIRE SET	5124CD 5136CD		
IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER						2 2
Some items are included for illustrative purposes only and in certain instances may not be available.						



Star Manufacturing International, Inc.

STAR MANUFACTURING

10 Sunnen Drive, St. Louis, MO 63143 U.S.A. (800) 807-9054 (314) 781-2777 Parts & Service (800) 807-9054 www.star-mfg.com