

MODEL HFD-1

Installation and Operation Instructions

2M-Z0662 Rev. K 6/10/2010



HFD-1





These symbols are intended to alert the user to the presence of important operating and maintenance instructions in the manual accompanying the appliance.

RETAIN THIS MANUAL FOR FUTURE REFERENCE NOTICE

Using any part other than genuine Star factory supplied parts relieves the manufacturer of all liability.

Star reserves the right to change specifications and product design without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions or replacements for previously purchased equipment.

Due to periodic changes in designs, methods, procedures, policies and regulations, the specifications contained in this sheet are subject to change without notice. While Star Manufacturing exercises good faith efforts to provide information that is accurate, we are not responsible for errors or omissions in information provided or conclusions reached as a result of using the specifications. By using the information provided, the user assumes all risks in connection with such use.

MAINTENANCE AND REPAIRS

Contact your local authorized service agent for service or required maintenance. Please record the model number, serial number, voltage and purchase date in the area below and have it ready when you call to ensure a faster service.

. .

.

Model No.	Authorized Service Agent ———— Reference the listing provided with the unit			
Serial No.	or	_ or		
Voltage	for an updated listing go to:			
Purchase Date	Website: www.star-mfg.com E-mail Service@star-mfg.com Telephone: (800) 807-9054 Local (314) 7			
	Service He	lp Desk		
	Business Hours:	8:00 am to 4:30 p.m. Central Standard Time		
	Telephone:	(800) 807-9054 Local (314) 781-2777		
	Fax:	(800) 396-2677 Local (314) 781-2714		
	E-mail	Parts@star-mfg.com Service@star-mfg.com Warranty@star-mfg.com		
	Website:	www.star-mfg.com		
	Mailing Address	 Star International Holdings Inc., Company 10 Sunnen Drive St. Louis, MO 63143 U.S.A 		

PRODUCT IDENTIFICATION

Star Manufacturing International, Inc. Humidified Cabinet

Models: HFD-1 120V, HFD-1-P 120V, HFD-1-CR 120V, HFD-1 240V*, HFD-1-P 240V, HFD-1-CR 240V * These models are equipped with European cord set and 240V elements. Note: -1 = Multipurpose Shelving; -1-P = Pretzel Rack; -1-CR = Pizza Rack


All models were designed and tested to the guidelines set forth by the National Sanitation Foundation (NSF), Standard Number 4.

SPECIFICATIONS


Capacity:	48 large pretzels/bagels (P models), three 12" (30 cm) pizzas (CR models) 3 multi-purpose shelves
Electrical:	120 volt, 50/60 hertz, single phase, 1280 watts, 10.6 amps
Dimensions:	240 volt, 50/60 hertz, single phase, 1280 watts, 5.3 amps 15"W x 15"D x 28-1/4"H
Waight	(38.1 cm W x 38.1 cm D x 71.7 cm H)
Weight:	Approximately 60 lbs. (27.2 Kg)

OPERATING CONTROLS

The temperature controls are located at the top of the unit above the door and the humidity controls are located on the bottom of the unit below the door (see Figures 1 and 2).



Temperature Dial - Adjusts cabinet temperature



ON/OFF Switch	-	Activates cabinet light, and air circulation system.
Humidity Dial	-	Adjusts cabinet humidity.
Low Water Indicator	-	Illuminates when water needs to be added.
Drain Tube	-	Allows the water reservoir to be emptied during cleaning.
Door Switch	-	Allows the rotisserie motor to rotate when the door is closed.



CAUTION

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations.

All shipping containers should be checked for freight damage both visible and concealed. This unit has been tested and carefully packaged to insure delivery of your unit in perfect condition. If equipment is received in damaged condition, either apparent or concealed, a claim must be made with the delivering carrier.

Concealed damage or loss - if damage or loss is not apparent until after equipment is unpacked, a request for inspection of concealed damage must be made with carrier within 15 days. Be certain to retain all contents plus external and internal packaging materials for inspection. The carrier will make an inspection and will supply necessary claim forms..

INSTALLATION

Each machine has been properly wired and inspected at the factory for operation on the voltage and type of current specified on the nameplate. Machines with a nameplate stamped 120V, are equipped for operation on 120 volt 50/60 hertz AC single phase service. Machines with a nameplate stamped 240V, are equipped for operation on 240 volt 50/60 hertz AC single phase service. Each condition must be connected to a separate 15 amp circuit with a 3 wire grounded, polarized receptacle.

WARNING

DO NOT CONNECT TO ANY OTHER TYPE OF CURRENT OR THE MACHINE WILL BE SERIOUSLY DAMAGED.

The guarantee of this machine as covered by the warranty card does not apply if an improper installation has been made.

GENERAL OPERATING INSTRUCTIONS



CAUTION

DO NOT BLOCK VENT HOLES ON TOP OF THE CABINET

- 1. Ensure cabinet is plugged into the proper voltage receptacle prior to turning on.
- 2. Fill reservoir with water (distilled preferred) such that the water is approximately level with the top of the water reservoir (low water indicator should extinguish). Capacity is 3/4 gallon (2.8 L).

CAUTION: DO NOT OVERFILL !

- 3. Follow preheat instructions on the following page. Allow approximately 15 minutes for the machine to reach the proper temperature.
- 4. Monitor product temperature via the thermometer (see Figure 3).
- 5. Load product into the racking system. For maximum product freshness, adjust the settings as specified. Pizza and pretzel racks are adjustable for different applications using the screws provided.
- 6. Periodically monitor the water level by the red indicator light on the lower control panel. If the light is illuminated, add water (distilled preferred) until the indicator light is no longer illuminated or to the maximum recommended water level (see Figure 4).



CAUTION: DO NOT OVERFILL !

7. See attached sketch for instructions on reversing the door.



Figure 3

CLEANING INSTRUCTIONS

- 1. Disconnect the electrical cord before cleaning the cabinet.
- 2. To maintain the finish and shine of the unit, wipe it daily with a damp cloth and mild soap. Do not use harsh detergents or scouring pads.
- 3. Daily cleaning of the inside glass, bottom pan and racking system with a damp cloth is recommended.
- Unscrew the drain cap to drain the water reservoir. After the water reservoir is empty, recap the drain tube and fill to the recommended water level (see Figure 4).

CAUTION: DO NOT OVERFILL! RECOMMENDED DIAL SETTINGS

- Preheat: Temp = 6 Humidity = 2
- Pizza:

Temp = High Humidity = 4

Pretzels/Bagels: Temp = 4 Humidity = 4

DIAL SETTING FOR DESIRED TEMPERATURE (APPROX.)

Low	1	110°F (43°C)
	2	120°F (49°C)
	3	130°F (55°C)
	4	150°F (66°C)
	5	165°F (74°C)
High		175°F (80°C)

DIAL SETTINGS FOR DESIRED HUMIDITY

Low,	1, 2	Low Humidity
	3, 4	Medium Humidity
High,	5, 6	High Humidity

All settings are recommendations only and could vary depending on product preparation, cooking time, and internal food temperature.

MAINTENANCE AND REPAIRS

Contact the factory, a service representative or a local service company for service or required maintenance.



Figure 4

Visit our Website at: www.star-mfg.com

Email: service@star-mfg.com

THOROUGHLY INSPECT YOUR UNIT ON ARRIVAL

This unit has been tested for proper operation before leaving our plant to insure delivery of your unit in perfect condition. However, there are instances in which the unit may be damaged in transit. In the event you discover any type of damage to your product upon receipt, you must immediately contact the transportation company who delivered the item to you and initiate your claim with same. If this procedure is not followed, it may affect the warranty status of the unit

LIMITED EQUIPMENT WARRANTY

All workmanship and material in Star products have a one (1) year limited warranty on parts & labor in the United States and Canada. Such warranty is limited to the original purchaser only and shall be effective from the date the equipment is placed in service. Star's obligation under this warranty is limited to the repair of defects without charge, by the factory authorized service agency or one of its sub-agencies. Models that are considered portable (see below) should be taken to the closest Star service agency, transportation prepaid.

- > Star will not assume any responsibility for loss of revenue.
- > On all shipments outside the United States and Canada, see International Warranty.
- * The warranty period for the JetStar six (6) ounce & Super JetStar eight (8) ounce series popcorn machines is two (2) years.
- * The warranty period for the Chrome-Max Griddles is five (5) years on the griddle surface. See detailed warranty provided with unit.
- The warranty period for Teflon/Dura-Tec coatings is one year under normal use and reasonable care. This warranty does not apply if damage occurs to Teflon/Dura-Tec coatings from improper cleaning, maintenance, use of metallic utensils, or abrasive cleaners, abrasive pads, product identifiers and point-of-sale attachments, or any other non-food object tha comes in continuous contact with the roller coating. This warranty does not apply to the 'non-stick" properties of such materials.
- > This warranty does not apply to "Special Products" but to regular catalog items only. Star's warranty on "Special Products" is six (6) months on parts and ninety (90) days on labor.
- > This warranty does not apply to any item that is disassembled or tampered with for any purpose other than repair by a Star Authorized Service Center or the Service Center's sub-agency.
- > This warranty does not apply if damage occurs from improper installation, misuse, wrong voltage, wrong gas or operated contrary to the Installation and Operating instructions.
- > This warranty is not valid on Conveyor Ovens unless a "start-up/check-out" has been performed by a Factory Authorized Technician.

PARTS WARRANTY

Parts that are sold to repair out of warranty equipment are warranted for ninety (90) days. The part only is warranted. Labor to replace the part is chargeable to the customer.

SERVICES NOT COVERED BY WARRANTY

10. Voltage conversions

Gas conversions

16. Replacement of bulbs

17. Replacement of fuses

Pilot light adjustment

13. Miscellaneous adjustments

14. Thermostat calibration and by-pass adjustment

installation OR created by acts of God

11.

12.

15.

18.

- Travel time and mileage rendered beyond the 50 mile radius limit 1. Mileage and travel time on portable equipment (see below)
- 3. Labor to replace such items that can be replaced easily during a daily cleaning routine, ie; removable kettles on fryers, knobs, grease drawers on griddles, etc.
- 4 Installation of equipment
- Damages due to improper installation 5.
- Damages from abuse or misuse 6
- Operated contrary to the Operating and Installation Instructions 7.
- Cleaning of equipment 8.
- Seasoning of griddle plates 9.

PORTABLE EQUIPMENT

Star will not honor service bills that include travel time and mileage charges for servicing any products considered "Portable" including items listed below. These products should be taken to the Service Agency for repair:

- * The Model 510FD Fryer.
- * The Model 526TOA Toaster Oven.
- * The Model J4R, 4 oz. Popcorn Machine.
- * The Model 518CMA & 526CMA Cheese Melter.
- * The Model 12MC & 15MC & 18MCP Hot Food Merchandisers.
- * The Model 12NCPW & 15NCPW Nacho Chip/Popcorn Warmer.
- * All Hot Dog Equipment except Roller Grills & Drawer Bun Warmers.
- * All Nacho Cheese Warmers except Model 11WLA Series Nacho Cheese Warmer.
- * All Condiment Dispensers except the Model HPD & SPD Series Dispenser.
- * All Specialty Food Warmers except Model 130R, 11RW Series, and 11WSA Series.
- * All QCS/RCS Series Toasters except Model QCS3 & RCS3 Series.

ALL: * Pop-Up Toasters

Resetting of circuit breakers or safety controls or reset buttons


Repair of damage created during transit, delivery, &

- * Butter Dispensers
- * Pretzel Merchandisers (Model 16PD-A Only)
- * Pastry Display Cabinets
- * Nacho Chip Merchandisers
- * Accessories of any kind
- * Sneeze Guards
- * Pizza Ovens
- (Model PO12 Only)
- * Heat Lamps
- * Pumps-Manual

The foregoing warranty is in lieu of any and all other warranties expressed or implied and constitutes the entire warranty.


FOR ASSISTANCE


Should you need any assistance regarding the Operation or Maintenance of any Star equipment; write, phone, fax or email our Service Department. In all correspondence mention the Model number and the Serial number of your unit, and the voltage or type of gas you are using.



INSTRUCTIONS FOR REVERSING THE DOOR ON UNIT

- 1. REMOVE THE TOP HINGE BRACKET ON THE LEFT POST AND INSTALL ON THE LOWER RIGHT POST.
- 2. REMOVE THE LOWER HINGE BRACKET ON THE LEFT POST.
- 3. ROTATE THE DOOR 360 DEGREES AND INSERT PIN ON THE BOTTOM OF THE DOOR INTO LOWER HINGE.
- 4. PLACE THE PREVIOUS LOWER BRACKET OVER THE PIN ON TOP OF THE DOOR AND RE-INSTALL THE HINGE BRACKET.






THIS DRAWING CONTAINS INFORMATION CONFIDENTIAL TO STAR MFG. INT'L. INC. NO REPRODUCTION OR DISCLOSURE OF ITS CONTENTS IS PERMITTED.

MODEL: HFD-1 120V/240V

STAR MANUFACTURING INTERNATIONAL INC.SK1450Rev E06/10/2010



MODEL HFD-1 HUMIDIFIED CABINETS

Key	Part	Number Per		
Number	Number	Unit	Description	
1	C3-G8021	1	CORD ASSEMBLY 120V	
	C3-39221	1	CORD ASSEMBLY 240V	
2	2K-Y2968	1	BUSHING - STRAIN RELIEF	
3	2I-Z0057	4	FOOT	
4	D5-Z0345	6	GLASS CHANNEL VERTICAL	
5	D5-Z0346	6	GLASS CHANNEL HORIZONTAL	
6	2Q-Z0581	3	GLASS - SIDE	
7	2K-1139	1	BUSHING - HEYCO	
8	D5-Z0321	1	BOTTOM	
9	2E-Y9148	1	RELAY 120V	
Ũ	2E-Z0625	1	RELAY 240V	
10	2E-Z0802	1	WIRE HARNESS - BOTTOM	
11	2N-Z3435	1	ELEMENT - ASSEMBLY 120V	
.,	2N-Z4149	1	ELEMENT - ASSEMBLY 240V	
12	2T-Z4250	1	THERMOSTAT - BOTTOM	
13	2R-Y8261	2	KNOB	
14	D5-Z0896	1	BODY - RESERVOIR	
15	D5-220093	1	FLOAT-SWITCH ASSEMBLY	
16	D5-220000	1	TRAY - ASSEMBLY	
17	D5-220072	1	PAN - ASSEMBLY	
18	D5-Z3679	2	DOOR - LATCH	
19	D5-220087	1	DOOR ASSEMBLY	
20	2I-Z0877	2	GLASS CHANNEL - HORIZONTAL DOOR	
20	2I-Z0876	1	GLASS CHANNEL - VERTICAL DOOR	
22	2Q-Z0759	1	GLASS DOOR	
22	20-20758 2I-Z0758	1	HINGE - DOOR	
23	2A-Y8068	2	PIN - DOWEL	
24	A3-35219	1	CAP AND CHAIN	
26	21-9772	1	GASKET	
20	2E-Y9700	1	SWITCH - INTERRUPT	
28	2J-Y6689	1	PILOT LIGHT 120V	
20	2J-Z2329	1	PILOT LIGHT 240V	
29	PS-220117	1	SWITCH KIT SERVICE KIT	(manufactured before 4/2010)
29	2E-Z0091	1	SWITCH	(manufactured after 4/2010)
30	2E-20091 2I-Z0878	1	DOOR - GASKET	(manulaciuleu aller 4/2010)
	21-20878 2M-Z0880			
31		1	BOTTOM - LABEL	
32	D5-Z0543		HINGE - BRACKET (TOP)	
33	D5-Z0542	1	HINGE - BRACKET (BOTTOM)	
34 35	D5-Z0320			
	D5-Z0319	3 2	ANGLE - BOTTOM	
36	D5-Z0324			
37	D5-Z0323	1	CORNER - POST RIGHT DOOR	
38	D5-Z0322	1	CORNER - POST LEFT DOOR	
39	2T-Z0613	1	THERMOMETER	
40	D5-Z0318	2	FILLER - POST RACK ANGLE - LEFT DOOR	
41	D5-Z0341	1	RACK ANGLE - LEFT DOOR RACK ANGLE - RIGHT DOOR	
42	D5-Z0342			
43 44	D5-Z0344 D5-Z0343	1	RACK ANGLE - RIGHT RACK ANGLE - LEFT	
44 45		1	TOP COVER	
45 46	D5-Z0605 2M-Z0879	1	TOP COVER TOP LABEL	
	2M-20879 2B-Z6899	3	HOLDER ASSEMBLY	
48				

IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER

PAGE 1 OF 2

Some items are included for illustrative purposes only and in certain instances may not be available.



Star Manufacturing International, Inc.

MODEL HFD-1 HUMIDIFIED CABINETS

Key Number	Part Number	Number Per Unit	Description	
50 51 52 53 54 55 56 57 58 59 60 61 62 63 NI 64 65 66 67 68 69 70 71 72	2B-Z9143 2B-Z4174 2B-Z0340 2N-Z0337 2N-Z0793 D5-Z0590 D5-Z0592 D5-Z0591 2U-Z5583 2E-Z0406 D5-220081 2E-Y9184 D5-Z0177 2S-Y9118 2S-Z0630 2U-Z3641 2U-Z3642 2U-Z9811 D5-Z4170 2T-Z0449 2C-Z1156 2M-Z0894 2I-Z1013 D5-220094 2C-Z0546 2M-Z0894	1 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	ASSEMBLY - PIZZA SHAFT SHELF - PIZZA RACK SHELF ELEMENT - AIR 240V COVER - DUCT BACK - DUCT BLOWER - ASSEMBLY HARNESS - TOP REFLECTOR - ASSEMBLY SOCKET TOP LINER LAMP 100W 120V LAMP 100W 240V MOTOR - ROTISSERIE 120V, Fan Not Included MOTOR - ROTISSERIE 240V, Fan Not Included FAN, MOTOR THERMOSTAT BRACKET THERMOSTAT BRACKET THERMOSTAT BRACKET THERMOSTAT - TOP SOCKET HEAD CAP SCREW (SUPPLIED WITH ITEM 48) COTTER - PIN DOOR DECAL GASKET - PAN DOOR ASSEMBLY HFD-1 SCREW 3/16" ALLEN HEAD DOOR DECAL, "FRESH & FAST"	
	IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED PAGE 2 INCLUDE MODEL AND SERIAL NUMBER OF 2 Some items are included for illustrative purposes only and in certain instances may not be available. PAGE 2			



Star Manufacturing International, Inc.

STAR INTERNATIONAL HOLDINGS INC. COMPANY

Star - Holman - Lang - Wells - Bloomfield - Toastmaster 10 Sunnen Drive, St. Louis, MO 63143 U.S.A. (800) 807-9054 (314) 781-2777 Parts & Service (800) 807-9054 www.star-mfg.com