



MODEL 1-9N 1-12

# Installation and Operation Instructions

2M-H8599 Rev.F 4/28/10



1-9N







#### SAFETY SYMBOL





These symbols are intended to alert the user to the presence of important operating and maintenance instructions in the manual accompanying the appliance.

## RETAIN THIS MANUAL FOR FUTURE REFERENCE NOTICE

Using any part other than genuine Star factory supplied parts relieves the manufacturer of all liability.

Star reserves the right to change specifications and product design without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions or replacements for previously purchased equipment.

Due to periodic changes in designs, methods, procedures, policies and regulations, the specifications contained in this sheet are subject to change without notice. While Star International Holdings Inc., Company exercises good faith efforts to provide information that is accurate, we are not responsible for errors or omissions in information provided or conclusions reached as a result of using the specifications. By using the information provided, the user assumes all risks in connection with such use.

#### **MAINTENANCE AND REPAIRS**

Contact your local authorized service agent for service or required maintenance.

Please record the model number, serial number, voltage and purchase date in the area below and have it ready when you call to ensure a faster service.

Authorized Service Agent Listing

Model No.	Reference the listing provided with the unit	
Serial No.	or	
Voltage	for an updated listing go to:	
Purchase Date	Website: E-mail	www.star-mfg.com Service@star-mfg.com
Pulchase Date —	Service Hel	p Desk
	Business Hours:	8:00 am to 4:30 p.m. Central Standard Time
	Telephone:	(314) 678-6303
	Fax:	(314) 781-2714
	E-mail	Parts@star-mfg.com Service@star-mfg.com Warranty@star-mfg.com
	Website:	www.star-mfg.com
	Mailing Address:	Star International Holdings Inc., Company 10 Sunnen Drive St. Louis, MO 63143 U.S.A



#### **CAUTION**

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations. For equipment to be used by the general public, please contact the factory.

#### **GENERAL OPERATING PROCEDURES**

Follow these simple instructions for the setup and operation of your new dispenser.

- 1. Lift unit out of shipping container and remove all tapes and packing materials. Do not discard carton until dispenser is completely assembled and working.
- Ensure magnetic impeller and wire grate are installed by lifting plastic lid and looking down into bowl. The word "TOP" should be visible on impeller body. Metal grate should be installed over impeller.
- 3. Add liquid to be heated/dispensed. If working with a powder, mix with water prior to pouring into bowl. For best results, use hot liquid when mixing with powder. This improves mixing and greatly reduces time to reach serving temperature. Do not place chocolate or cocoa powder directly into bowl. Mix first.
- 4. Plug unit into 115V AC outlet.



#### **WARNING**

#### DO NOT CONNECT TO DIRECT CURRENT (DC).

- 5. Turn switch on front right side of unit to ON position. This controls indicator light, heating element and motor. Power is indicated by switch light.
- 6. The recessed area below spigot is intended for use as a drip tray.
- 7. Your new Star dispenser is equipped with a worry-free, trouble proof, pre-set thermostat that maintains the product at proper serving temperature.

#### DISPENSER CLEANING INSTRUCTIONS

1. For best results and customer satisfaction, thoroughly clean dispenser daily.



#### CAUTION

#### TURN UNIT OFF AND UNPLUG PRIOR TO CLEANING.

- 2. Remove contents of bowl before lifting and cleaning. Product removed from the bowl may be placed in a suitable container for overnight refrigerated storage.
- 3. Lift cover and remove grate and impeller.
- After allowing unit to thoroughly cool, remove front of unit by pulling on both sides at the top with your fingers. Release latch to loosen bowl from element band and swing clamp to left.
- 5. Raise bowl until faucet shank touches top of frame, then tilt bowl forward and upward until faucet shank clears unit.
- 6. Clean and dry inset bowl, replacing it in unit by reversing operations of step 5, tighten latch for heating element.
- 7. Reinstall impeller such that the word "TOP" is again visible, and also metal grate.

#### MAINTENANCE AND REPAIRS

Contact the factory, a service representative or a local service company for service or required maintenance.

### **Cleaning & Sanitizing Instructions**

Proper cleaning and sanitizing of the faucet on your tea machine is necessary to delivery great tasting fresh brewed iced tea. SPB and SPBH faucets do not require tools for servicing, cleaning, or sanitizing. Simplified construction means fewer parts to wear out or replace.

To prevent bacterial growth, follow step by step sequence and refer to the diagram below. When ordering replacement parts, be sure to specify our model number. The chart below shows common replacement parts.

IMPORTANT: To prevent bacterial growth and protect tea flavor, clean and sanitize tea brewing and storage equipment at least ONCE A DAY according to manufacturer's directions.

#### **CLEANING & SANITIZING**

#### STEP 1:

Remove the entire upper assembly by unscrewing the bonnet (A).

#### STEP 2:

- Pull seat cup (B) to remove from stem. Inspect for wear or hardening and replace if necessary.
- Clean all parts, including faucet body, in hot soapy water.
- Sanitize with a chlorine (50 PPM), iodine (14 PPM) or quaternary ammonium compound (100 PPM).
- · Rinse with clear hot water.

#### STEP 3:

Snap seat cup over stem end by applying direct pressure.


#### STEP 4:

Screw upper assembly back onto body. **HAND TIGHTEN ONLY!** 

#### NOTE:

To dismantle the entire upper assembly, carefully pull handle from stem while applying pressure to seat cup. Remove spring, stem and seat cup. Reassemble in reverse.

Tomlinson manufactures this same valve for most major tea brewer manufacturers whose names may appear on the handle.



#### Email: service@star-mfg.com

#### THOROUGHLY INSPECT YOUR UNIT ON ARRIVAL

This unit has been tested for proper operation before leaving our plant to insure delivery of your unit in perfect condition. However, there are instances in which the unit may be damaged in transit. In the event you discover any type of damage to your product upon receipt, you must immediately contact the transportation company who delivered the item to you and initiate your claim with same. If this procedure is not followed, it may affect the warranty status of the unit.

#### LIMITED EQUIPMENT WARRANTY

All workmanship and material in Star products have a one (1) year limited warranty on parts & labor in the United States and Canada. Such warranty is limited to the original purchaser only and shall be effective from the date the equipment is placed in service. Star's obligation under this warranty is limited to the repair of defects without charge, by the factory authorized service agency or one of its sub-agencies. Models that are considered portable (*see below*) should be taken to the closest Star service agency, transportation prepaid.

- > Star will not assume any responsibility for loss of revenue.
- > On all shipments outside the United States and Canada, see International Warranty.
- \* The warranty period for the JetStar six (6) ounce & Super JetStar eight (8) ounce series popcorn machines is two (2) years.
- \* The warranty period for the Chrome-Max Griddles is five (5) years on the griddle surface. See detailed warranty provided with unit.
- The warranty period for Teflon/Dura-Tec coatings is one year under normal use and reasonable care. This warranty does not apply if damage occurs to Teflon/Dura-Tec coatings from improper cleaning, maintenance, use of metallic utensils, or abrasive cleaners, abrasive pads, product identifiers and point-of-sale attachments, or any other non-food object tha comes in continuous contact with the roller coating. This warranty does not apply to the "non-stick" properties of such materials.
- > This warranty does not apply to "Special Products" but to regular catalog items only. Star's warranty on "Special Products" is six (6) months on parts and ninety (90) days on labor.
- > This warranty does not apply to any item that is disassembled or tampered with for any purpose other than repair by a Star Authorized Service Center or the Service Center's sub-agency.
- > This warranty does not apply if damage occurs from improper installation, misuse, wrong voltage, wrong gas or operated contrary to the Installation and Operating instructions.
- > This warranty is not valid on Conveyor Ovens unless a "start-up/check-out" has been performed by a Factory Authorized Technician.

#### PARTS WARRANTY

Parts that are sold to repair out of warranty equipment are warranted for ninety (90) days. The part only is warranted. Labor to replace the part is chargeable to the customer

#### SERVICES NOT COVERED BY WARRANTY

- 1. Travel time and mileage rendered beyond the 50 mile radius limit
- 2. Mileage and travel time on portable equipment (see below)
- Labor to replace such items that can be replaced easily during a daily cleaning routine, ie; removable kettles on fryers, knobs, grease drawers on griddles, etc.
- 4. Installation of equipment
- 5. Damages due to improper installation
- 6. Damages from abuse or misuse
- 7. Operated contrary to the Operating and Installation Instructions
- 8. Cleaning of equipment
- 9. Seasoning of griddle plates

- 10. Voltage conversions
- 11. Gas conversions
- 12. Pilot light adjustment
- 13. Miscellaneous adjustments
- 14. Thermostat calibration and by-pass adjustment
- 15. Resetting of circuit breakers or safety controls or reset buttons
- 16. Replacement of bulbs
- 17. Replacement of fuses
- Repair of damage created during transit, delivery, & installation OR created by acts of God

#### PORTABLE EQUIPMENT

Star will not honor service bills that include travel time and mileage charges for servicing any products considered "Portable" including items listed below. These products should be taken to the Service Agency for repair:


- \* The Model 510FD Fryer.
- \* The Model 526TOA Toaster Oven.
- \* The Model J4R, 4 oz. Popcorn Machine.
- \* The Model 518CMA & 526CMA Cheese Melter.
- \* The Model 12MC & 15MC & 18MCP Hot Food Merchandisers.
- \* The Model 12NCPW & 15NCPW Nacho Chip/Popcorn Warmer.
- \* All Hot Dog Equipment except Roller Grills & Drawer Bun Warmers.
- \* All Nacho Cheese Warmers except Model 11WLA Series Nacho Cheese Warmer.
- \* All Condiment Dispensers except the Model HPD & SPD Series Dispenser.
- \* All Specialty Food Warmers except Model 130R, 11RW Series, and 11WSA Series. \* All QCS/RCS Series Toasters except Model QCS3 & RCS3 Series.
- \* All Fast Steamer Models except Direct Connect Series.


- ALL:
- \* Pop-Up Toasters
- \* Butter Dispensers
- \* Pretzel Merchandisers (Model 16PD-A Only)
- \* Pastry Display Cabinets
- \* Nacho Chip Merchandisers
- \* Accessories of any kind
- \* Sneeze Guards
- \* Pizza Ovens (Model PO12 Only)
- \* Heat Lamps
- \* Pumps-Manual

The foregoing warranty is in lieu of any and all other warranties expressed or implied and constitutes the entire warranty.

#### FOR ASSISTANCE

Should you need any assistance regarding the Operation or Maintenance of any Star equipment; write, phone, fax or email our Service Department. In all correspondence mention the Model number and the Serial number of your unit, and the voltage or type of gas you are using.





CERTAIN INSTANCES MAT NOT BE AVAILAI

MODEL: 1-9N & 1-12

STAR MANUFACTURING INTERNATIONAL, INC. SK2115 REV. -

MODEL \_\_\_\_\_1-9N Hot Chocolate Dispensers

Key	Dont	Number	
Key	Part	Per	Description
Number	Number	Unit	Description
1	2D-H8551	1	DRIP PAN
2	M1-H8550	1 1	DRIP PAN GRILL
3	M1-H8552	1	BRACE
4	2R-Y4809	1	FAN BLADE - METAL
5	PS-S8792	1	MOTOR KIT w/o FAN
6	M1-H8560	1	BASE
7	2I-H6579	4	GROMMETS
8	2K-H8558	1	COUPLING
9	M1-H8556	2	PLUG - MAGNET
10	2R-H8590	1	IMPELLER MOTOR MAGNET
11	2C-1506	1	MOUNTING SCREW
12	2E-Y5020	1 1	SWITCH SPST 16A/ 125V
	2E-Y6144	1	SWITCH SPST 20A/120V (#L2002915 and below)
	2E-Y6044	1	SWITCH 10A 250V GRD (#L2002916 and above)
13	M1-19012	1	FRONT BOTTOM PANEL
14	M1-S8644	1	FRONT TOP PANEL
15	2M-H8639	1	SIGN - "DELICIOUS HOT CHOCOLATE"
	2M-Z0447	1	LABEL - OPERATOR
16	2L-Y8933	1	STAINLESS STEEL COVER
	2L-H8548	1	PLASTIC COVER
17	M1-H8597	1	BOWL GASKET
18	2D-S8578	1	BODY ASSEMBLY
19	M1-H8555	1	PLATE - BOTTOM
20	2C-9788	2	MAGNETIC CATCH
21 22	2K-H5417	1	CORD BUSHING
23	2V-Z0568 2P-H8867	2 4	BASE TUBE PLUG END
24	2I-H7685	4	FOOT
25	2I-S7523	1 1	LEAD-IN CORD (#L2002915 and below)
25	M1-90101		LEAD-IN CORD (#L2002915 and below) LEAD-IN CORD (#L2002916 and above)
26	N2-H6968		COVER - THERMOSTAT
27	2T-H6335		THERMOSTAT
28	M1-S8586		HEATING ELEMENT
29	2U-H8778	i	FAUCET
30	2C-H2016	1 1	WASHER - "C"
31	2C-H8779	1 1	WING NUT
32	2D-S8579	1 1	BOWL ASSEMBLY
33	2B-S8573	1 1	IMPELLER ASSEMBLY
34	2R-H8583	1	COATED IMPELLER MAGNET
	2J-8006	1	INDICATOR LIGHT
	2K-H8634	1 1	BUSHING - NYLON

IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER

PAGE 1 0F 2

Some items are included for illustrative purposes only and in certain instances may not be available.



#### MODEL 1-12 Hot Chocolate Dispensers

Number  1 2 3 4 5 7 8 9 10 11 12	Number  2D-H8611 M1-H8615 M1-H8604 2R-Y4809 PS-S8792 2I-H6579 2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	Unit  1 1 1 1 4 1 2 1 4 1 1 1 1	DRIP PAN DRIP PAN GRILL BRACE FAN BLADE - METAL MOTOR KIT (without Fan Blade) GROMMETS (motor mount) COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW SWITCH SPST 16A/ 125V		
2 3 4 5 7 8 9 10 11	M1-H8615 M1-H8604 2R-Y4809 PS-S8792 2I-H6579 2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 1 1 4 1 1 2 1 4	DRIP PAN GRILL BRACE FAN BLADE - METAL MOTOR KIT (without Fan Blade) GROMMETS (motor mount) COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
3 4 5 7 8 9 10 11	M1-H8604 2R-Y4809 PS-S8792 2I-H6579 2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 1 4 1 1 2 1 4	BRACE FAN BLADE - METAL MOTOR KIT (without Fan Blade) GROMMETS (motor mount) COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
4 5 7 8 9 10 11	2R-Y4809 PS-S8792 2I-H6579 2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 1 4 1 1 2 1 4	FAN BLADE - METAL MOTOR KIT (without Fan Blade) GROMMETS (motor mount) COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
5 7 8 9 10	PS-S8792 2I-H6579 2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 4 1 1 2 1 4	MOTOR KIT (without Fan Blade) GROMMETS (motor mount) COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
7 8 9 10 11	2I-H6579 2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	4 1 1 2 1 4	GROMMETS (motor mount) COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
9 10 11	2K-H8558 2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 1 2 1 4	COUPLING SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
9 10 11	2C-Z0644 M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 2 1 4	SET SCREW PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
10 11	M1-H8556 2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	2 1 4 1	PLUG - MAGNET IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
10 11	2R-H8590 2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	1 4 1	IMPELLER MOTOR MAGNET (black) MOUNTING SCREW		
11	2C-1506 2E-Y5020 2E-Y6144 2E-Y6044	4 1	MOUNTING SCREW		
	2E-Y5020 2E-Y6144 2E-Y6044	1	MOUNTING SCREW		
12	2E-Y6144 2E-Y6044		SWITCH SPST 16A/ 125V		
	2E-Y6044	1 1			
I	2E-Y6044		SWITCH SPST 20A/120V (#L2002915 and below)		
		1 1	SWITCH 10A 250V GRD (#L2002916 and above)		
13	M1-S8624	1 1	FRONT BOTTOM PANEL		
14	M1-S8643	1 1	FRONT TOP PANEL		
15	2M-H8639	1 1	SIGN - "DELICIOUS HOT CHOCOLATE"		
.0	2M-Z0447	1 1	LABEL OPERATOR		
16	2L-H8584	1 1	PLASTIC COVER		
.0	2L-Y8933	1 1	STAINLESS STEEL COVER		
17	M1-H8687	1 1	BOWL GASKET - 24.5" LONG		
18	M1-S8625		BODY ASSEMBLY		
19	M1-H8603		BOTTOM PLATE		
20	2C-9788	1 1	MAGNETIC CATCH		
21	2K-H5417	1 1	CORD BUSHING		
22	2V-Z0569	2	BASE TUBE		
23	2P-H8867	4	PLUG END		
24	2I-H7685	4	FOOT		
25	2I-S7523	1 1	LEAD-IN CORD (#L2002915 and below)		
25	M1-90101		LEAD-IN CORD (#L2002915 and below) LEAD-IN CORD (#L2002916 and above)		
26	N2-H6968	i i	COVER - THERMOSTAT (not shown)		
27	2T-H6335	1 1	THERMOSTAT (CCW = Temperature Down, CW = Temperature Up)		
	N2-H6320	1	INSULATION - THERMOSTAT (not shown)		
28	M1-S8647	1 1	HEATING ELEMENT ASSEMBLY		
29	2U-H8778	1 1	FAUCET		
		1 1	FAUCET SEAT (provided complete with Faucet)		
30	2C-H2016	1 1	WASHER - "C"		
31	2C-H8779	1 1	WING NUT		
32	M1-S8576	1 1	BOWL ASSEMBLY (includes Impeller Pivot Shaft)		
	2A-H8574	1 1	IMPELLER PIVOT SHAFT		
33	2B-S8573	1 1	IMPELLER ASSEMBLY		
34	2R-H8583	1 1	IMPELLER MAGNET (brown)		
	2K-H8634	1	NYLON BUSHING		
	2J-8006	1	INDICATOR LIGHT (#L2002915 and below)		

IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER

PAGE 2 OF 2

Some items are included for illustrative purposes only and in certain instances may not be available.



Star - Holman - Lang - Wells - Bloomfield - Toastmaster 10 Sunnen Drive, St. Louis, MO 63143 U.S.A. (314) 678-6303 www.star-mfg.com