AFD-280E INSTALLATION CHECKLIST



Date:	Serial Number	
Custor	omer	Address
City		State
Postal	al Code	Country
Phone	el	FAX
- F	HOPPER LID LIFT SAD	DDLE
□ ⊢	HOPPER UPPER G	GUIDE ASSEMBLY (SLIDE SCREWS TIGHT)
	DIVERTER 🗌 LOWER (GUIDE ASSEMBLY (SLIDE SCREWS TIGHT)
	DRUM BASKETS	S (10)
	DRIP PAN	
1.	POWER SUPPLY = 24.5 VDC (± 0.2)	
2 .	LIFT SENSOR (L2) / GUIDE SENSOR (L3) RANG	GE, 4 - 6 INCHES (10 - 15 CM)
3.	DRUM MOTOR OPERATES (F15)	
4.	ACTUATE STOP GATE (F14)	
	HOME SWITCH (L6) ON AT END OF CYCLE, OFF	F DURING CYCLE
5.	ACTUATE ACCUMULATOR DOORS (F13)	
	HOME SWITCH (L7) OFF WHEN DOORS ARE CL	LOSED, ON WHEN DOORS ARE OPEN
6.	ACTUATE LIFT SADDLE (F12) , 77 (+1) DOWN,	, 179 (±6) UP
7. 🗌	EXERCISE MODE (F26) OPERATES WITHOUT ERROR	
8.	CALIBRATE NON-CONTACT WEIGHT SENSOR	
9.	SELECTOR SWITCH INDICATES CORRECT INPUTS	
	1.5#/700 gm (L8), 1#/450 gm (L9), AND SING	
10.		
11.		
		FILL AND TRANSITION SMOOTHLY TO THE LOWER
		LIFT SADDLE REMAINS IN THE UP POSITION. THE
	ACCUMULATOR DOORS SHOULD FILL IN PREPAI	ARATION FOR THE NEXT BASKET
12.	CLEAR ERROR LOG (F18)	
13.	INSTRUCT CREW ON DISASSEMBLY	
14.	INSTRUCT CREW ON PROPER CLEANING	
15.	INSTRUCT CREW ON ASSEMBLY	
16.	INSTRUCT CREW ON OPERATION	

PLEASE FAX TO AUTOMATED EQUIPMENT LLC. 1-651-385-2172