

SECTION 2. INSTALLATION

2-1. INTRODUCTION

This section provides the installation instructions for the Henny Penny Multipurpose Holding Cabinet.

NOTICE

Installation of this unit should be performed by a qualified service technician.



Do not puncture the skin of unit with drills or screws as component damage or electrical shock could result.

2-2. UNPACKING

The Henny Penny Multipurpose Holding Cabinet has been tested, inspected, and expertly packed to ensure arrival at its destination in the best possible condition. The cabinet rests on cardboard pads that sit on a wooden skid. The unit is then packed inside a heavy cardboard carton with sufficient padding to withstand normal shipping treatment.

NOTICE

Any shipping damages should be noted in the presence of the delivery agent and signed prior to his or her departure.

To remove the Henny Penny Multipurpose Holding Cabinet from the carton, you should:

1. Carefully cut banding straps.
2. Lift carton off the unit.
3. Lift the unit from the cardboard pads.



Care should be taken when lifting unit to prevent personal injury. The unit weighs approximately 67 lbs. (30 kg).

4. Open drawers and remove the packing or literature that is inside.

2-2. UNPACKING (Continued)

5. Pull off any protective covering from the exterior of the cabinet.
6. Your multipurpose holding cabinet is now ready for location and setup.

2-3. ELECTRICAL REQUIREMENTS

The multipurpose holding cabinet is available from the factory as a 120 VAC unit. The unit is single phase and requires a grounded receptacle with a separate electrical line protected by a fuse or circuit breaker of the proper rating.



To avoid electrical shock, the cabinet must be adequately and safely grounded (earthed) according to local electrical codes.

DATA TABLE:

Model Number	Volts	Phase	Watts	Amps
CF-941	120	1	475	3

2-4. CABINET DIMENSIONS

