# SERVICE SECTION




There's Always Something Cooking!

Service, Parts, and Schematics For Gas Fryers With Options

Including Built-in and UFM (Spacefighter)
Filter Systems

Covering Models 7, 12, 14, 14R, PR14, PM14, & 18









## **Table of Contents (Service)**

| Section   | n 11tte                                    | Page |
|-----------|--|------|
| Table o   | of Contents (Service)                      | i-ii |
| List of I | Figures                                    | ii   |
| Chapte    | r 4: Service                               | 4-1  |
| 4.1       | REPLACEMENT PROCEDURES                     | 4-1  |
| 4.11      | Main Bumer Removal and Replacement         | 4-1  |
| 4.12      | Changing the Main Burner Orifice           | 4-1  |
| 4.13      | Replacing the Heat Baffles                 | 4-1  |
| 4.14      | Pilot Burner Removal and Replacement       | 4-2  |
| 4.15      | Pilot Orifice Replacement                  | 4-2  |
| 4.16      | Thermopile Replacement                     | 4-2  |
| 4.17      | Thermo stat Replacement                    | 4-3  |
| 4.18      | Limit Control Replacement                  | 4-3  |
| 4.19      | Calibrating the KX299 Thermostat           | 4-4  |
| 4.2       | TROUBLESHOOTING FRYERS WITH UNITROL VALVES | 4-5  |
| 4.3       | TROUBLESHOOTING COMPUTER CONTROLS          | 4-7  |
| 4.4       | TROUBLESHOOTING PILOT LIGHTS               | 4-9  |
| 4.5       | TROUBLESHOOTING ELECTRIC THERMOSTATS       | 4-10 |
| 4.6       | TROUBLESHOOTING GO THERMOSTATS             | 4-11 |
| 4.7       | TROUBLESHOOTING ELECTRONIC IGNITIONS       | 4-12 |
| 4.8       | TROUBLESHOOTING BASKET LIFT PROBLEMS       | 4-14 |
| 4.9       | TROUBLESHOOTING BUILT-IN FILTER UNITS      | 4-17 |
| 4.10      | TROUBLESHOOTING UFM FILTER UNITS           | 4-20 |
| Chapte    | r 5: Parts                                 | 5-1  |
|           | ALPHABETICAL PART LIST                     | 5-18 |
|           | NUMERICAL PART LIST                        | 5-26 |
| Chante    | r 6: Schematics                            | 6-1  |

## **List of Figures and Tables**


| Figure No. | Title  | Page |
|------------|--|------|
|            |  |      |
| 5-1        | Outside View5-2  |      |
| 5-2        | Electronic Ignition, Left Entrance Box5-3                                |      |
| 5-3        | Frame-Cabinet / Electrical Assemblies With Components5-5                 |      |
| 5-4        | UFM Filter, Frame/Electrical Assembly5-7                                 |      |
| 5-5        | UFM Filter, Pick-Up/Pan Assembly5-9                                      |      |
| 5-6        | UFM-A Filter, Motor / Return Assembly5-11                                |      |
| 5-7        | Built-in Filter Pan With Components5-13                                  |      |
| 5-8        | Built-in Filter Piping With Components 5-15                              |      |
| 5-9        | Built-in Filter With Accessories5-17                                     |      |
|            |  |      |
| Table No.  | Title  | Page |
|            |  |      |
| 5-1        | Built-in Filter Frame-Cabinet / Electrical Assemblies With Components5-4 |      |
| 5-2        | UFM Filter, Frame/Electrical Assembly5-6                                 |      |
| 5-3        | UFM Filter, Pick-Up/Pan Assembly5-8                                      |      |
| 5-4        | UFM Filter, Motor / Return Assembly5-10                                  |      |
| 5-5        | Built-in Filter Pan With Components5-12                                  |      |
| 5-6        | Built-in Filter Piping With Components5-14                               |      |
| 5-7        | Built-in Filter With Accessories5-16                                     |      |

### **Chapter 4: Service**

This chapter provides the qualified technician with the replacement and troubleshooting procedures necessary to service the Pitco fryer.

#### 4.1 REPLACEMENT PROCEDURES

These procedures are provided to the qualified technician as a guide to removal and replacement of various fryer components. If a test is required to verify component operation after installation, it will be referenced.



To prevent bums, always ensure the fryer is completely SHUT DOWN and COOLED down before working on the fryer. Do not break any fryer gas connections while the unit is connected to a gas supply line.



The power supply must be disconnected before servicing or cleaning the appliance.

#### 4.1.1 Main Burner Removal and Replacement

- a. Loosen the set screw in the base of the burner casing.
- b. Unscrew and remove the two hex head screws at the top of the burner.
- c. Loosen the set screw on the air collar. Lift the burner and air collar up to clear the top of the burner fitting. Remove the burner from the fryer.
- d. To re-install the burner, reverse the procedure.

#### 4.1.2 Changing the Main Burner Orifice

- a. Unscrew the orifice with a 3/8" wrench and remove the orifice.
- b. Insert the new orifice and tighten with the 3/8" wrench. Ensure the orifice is tight enough to prevent gas leakage around the orifice.

#### 4.1 .3 Replacing the Heat Baffles

a. Remove the Main Burner as described in 4.1.1.

- b. The heat baffles are located inside the heat tubes. They are attached to the rear of the baffle supported by tack welds. Using a chisel, break away the baffle support and remove the old baffles. Be careful not to puncture the heat tubes because this will require complete tank replacement.
- c. Insert the new baffles in the tubes in the original position. The new baffles sit in position and do not require welding.
- d. Install the main burners.

#### 4.1.4 Pilot Burner Removal and Replacement

- a. Unscrew the tubing nut from the pilot tubing connection at the gas valve. Disconnect the thermopile from the connection on the gas valve.
- b. Unscrew and remove the two screws that attach the pilot assembly to the fryer tank. Lift the entire pilot assembly out of the fryer.
- c. To replace the pilot assembly, reverse the procedure.

#### **4.1.5** Pilot Orifice Replacement

- a. Remove the pilot assembly as described in 4.1.4.
- b. Unscrew the tubing nut from the pilot tubing connection at base of the pilot burner. The pilot orifice is located inside the tubing connection.
- c. Remove the orifice and replace with the new orifice. Ensure the orifice is tight enough to prevent gas leakage around the orifice.
- d. Replace the tubing nut in the pilot tubing connection and tighten enough to prevent gas leakage.
  - e. Replace the pilot assembly and adjust the pilot flame as described in 1.5.2.

#### 4.1.6 Thermopile Replacement

- a. Remove the pilot assembly as described in 4.1.4.
- b. Unscrew and remove the thermopile from the pilot assembly.
- c. Remove from gas valve magnet.
- d. Insert the new thermopile in the pilot assembly.
- e. Replace the pilot assembly and adjust the pilot flame as described in 1.5.2.

#### **4.1.7 Thermostat Replacement**

The thermostat includes the temperature adjustment knob, temperature sensor inside the fryer tank, and connecting capillary tubing. The high limit controls also has a temperature sensor in the fryer tank, so ensure you are removing the correct temperature sensor.

#### **CAUTION**

Thermostat capillary tubing is very delicate. Be VERY CAREFUL when working with the capillary tubing. If the tubing is kinked or broken the thermostat is no longer usable.

- a. Drain the oil from the fryer and remove the heat tube screens. The thermostat probe (heat sensor) is clamped to the heat tube inside the tank. Unscrew and remove the two screws in the thermostat probe clamp.
- b. Remove the thermostat probe from the clamp and straighten the capillary tubing. Unscrew the small hex nut inside the cabinet under the tank for the thermostat control.
- c. Unscrew the large connector nut from the tank and pull the thermostat probe and capillary tubes through the opening.
- d. Pull the knob off of the thermostat. Remove the two self tapping screws from the retaining plate.
- e. Remove the two slot head screws that hold the thermostat control unit in the fryer cabinet.
- f. Remove the two self tapping screws that hold the sheet metal switch cover in place. Carefully remove the sheet metal cover over the capillary tubes.
- g. Mark and remove the wire from the terminals or the tubing from the fittings on the thermostat body. Remove the defective thermostat control unit from the fryer.
- h. Install the new thermostat in reverse order. Remember to be careful with the capillary tubes.
- i. Use pipe joint compound on the large fitting before installing to prevent oil leakage. DO NOT use joint compound on the small nut.
- j. Perform the calibration procedures detailed in section 1.5.6.

#### 4.1.8 Limit Control Replacement

The limit control includes a temperature sensor inside the fryer tank, control unit inside the fryer cabinet, and connecting capillary tubing. The high limit control temperature sensor looks like the thermostat temperature sensor, so ensure you are removing the correct temperature sensor clamp.

#### **CAUTION**

The limit control capillary tubing is very delicate. Be VERY CAREFUL when working with the capillary tubing. If the tubing is kinked or broken the limit control is no longer usable.


- a. Drain the oil from the fryer and remove the heat tube screens.
- b. The limit control probe (heat sensor) is clamped to the heat tube inside the tank. Unscrew and remove the two screws in the probe clamp.
- c. Remove the probe from the clamp and straighten the capillary tubing. Unscrew the small hex nut inside the cabinet at the bottom of the tank for the limit control.
- d. Unscrew the large connector nut from the tank and pull the probe and capillary tubes through the opening.
- e. Remove the two mounting screws from the limit control bracket and remove the limit control unit. Disconnect the wires from the limit control box.
- f. Reverse the procedure to install the new limit control.
- g. Use pipe joint compound on the large fitting before installing to prevent oil leakage. DO NOT use joint compound on the small nut.


#### **4.1.9** Calibrating the KX299 Thermostat

To calibrate this thermostat the dial must be removed from the shaft. The adjustment for the thermostat is inside the dial shaft.


- a. Set the thermostat dial to 325°F.
- b. Remove the thermometer dial by pulling the knob straight out. DO NOT rotate the dial.
- c. Hold the outside of the shaft so it does not move. Use the tip of a small, flat tip screw driver to scrape away the sealing compound from the adjustment screw. Turn the adjustment screw clockwise to lower the temperature setting and counterclockwise to raise the temperature. One quarter turn will change the temperature approximately 25°F.
- d. Turn the adjustment until the burners turn off at 325°F. Replace the knob and allow the fryer to cycle 4 to 6 times. Check the temperature of the thermometer against the thermostat dial, if it is greater than 5°F repeat the calibration procedure.
- e. When the calibration is correct, remove the thermometer and replace the tube screen.


#### 4.2 TROUBLESHOOTING FRYERS WITH UNITROL VALVES






#### 4.3 TROUBLESHOOTING COMPUTER CONTROLS







#### 4.4 TROUBLESHOOTING PILOT LIGHTS




#### 4.5 TROUBLESHOOTING ELECTRIC THERMOSTATS




#### 4.6 TROUBLESHOOTING GO THERMOSTATS





#### 4.7 TROUBLESHOOTING ELECTRONIC IGNITIONS






#### 4.8 TROUBLESHOOTING BASKET LIFT PROBLEMS










the wrong position the miscrswitch could be misaligned..


#### 4.9 TROUBLESHOOTING BUILT-IN FILTER UNITS








#### 4.10 TROUBLESHOOTING UFM FILTER UNITS






### **Chapter 5: Parts**

This chapter contains listings of the components used in the different models of universal fryers. These components are listed in two places, with the illustration and in ordered listings. The illustrations in this chapter are provided to show relative location of components located in the fryer. The fryer you have may not be illustrated in this chapter, but the part locations should be the same. With each illustration there is a table of components in numerical order by illustration number. The illustration has numbered lines pointing to components which are listed in the table.

At the end of this chapter there are alphabetical and numerical listings of all parts used in the universal fryers. The alphabetical part list is arranged in alphabetical order according to the part name. Each part name also has the Pitco Frialator part number. The numerical list is in Pitco Frialator part number order. A brief description of each component is provided for each part.



| Index<br>Number | Description                   | Index<br>Number | Description |
|-----------------|-------------------------------|-----------------|-------------|
| 1               | Filter Module Caster 4/Filter |                 |             |
| 2               | Caster with Locking Device    |                 |             |
| 3               | Left Door                     |                 |             |
| 4               | Chrome Door Handle            |                 |             |
| 5               | Amber Heating Lamp Assembly   |                 |             |
| 6               | White Power Lamp Assembly     |                 |             |
| 7               | Rocker Switch ON-OFF-TEST     |                 |             |
| 8               | Basket, 14" Oblong            |                 |             |
| 9               | Basket Lift                   |                 |             |
| 10              | Basket Lift Timer             |                 |             |
| 11              | Right Door                    |                 |             |
| 12              | Filter Module                 |                 |             |

Figure 5-1 Outside View




Figure 5-2 Electronic Ignition, Left Entrance Box

Table 5-1 Built-in Filter Frame-Cabinet / Electrical Assemblies With Components

| Item Number | Pitco Frialator<br>Part Number | Description                  | Quantity<br>Per Unit |
|-------------|--------------------------------|------------------------------|----------------------|
| 1           | B7446005                       | Pan Liner #14                | 1                    |
|             | B7446006                       | Pan Liner #18                | 1                    |
| 2           | A6611401                       | Stop #14                     | 1                    |
|             | A6611403                       | Stop #18                     | 1                    |
| 3           | P5046980                       | Heater Strip                 | 2                    |
| 4           | P6071448                       | Plug Hole 2"                 | 1                    |
| 5           | A6613101                       | Cover, Side                  | 1                    |
| 6           | A1819602                       | Bracket, Door Magnet         | 1                    |
| 7           | P6071300                       | Magnet                       | 1                    |
| 8           | B3900909                       | Leg Set                      | 1                    |
| 9           | B7402238                       | Bracket, Circuit Breaker     | 1                    |
| 10          | PP10104                        | Circuit Breaker              | 1                    |
| 11          | PP10082                        | Light, 125V Amber            | 1                    |
| 12          | PP10195                        | Screw, Button Head Hex       | 2                    |
| 13          | A6042801                       | Overlay                      | 1                    |
| 14          | PP10098                        | Switch, Rocker               | 1                    |
| 15          | Call Factory                   | Front Panel Weldment         | 1                    |
| 16          | B7230202                       | Hinge, Top Door              | 1                    |
| 17          | B2301205                       | Door #14                     | 1                    |
|             | B2301206                       | Door #18                     | 1                    |
| 18          | P6071516                       | Handle, Door                 | 1                    |
| 19          | B7230302                       | Hinge, Bottom Door           | 1                    |
| 20          | P0075200                       | Screw, 2 #8 x 1/2 Self Drill | 10                   |
| 21          | PP10686                        | Screw 6-32 x 1/4             | 2                    |
| 22          | PP10025                        | Screw 10-32 x 1/4            | 2                    |




Figure 5-3 Frame-Cabinet/ Electrical Assemblies With Components

Table 5-2 UFM Filter, Frame/Electrical Assembly

| Item Number | Pitco Frialator<br>Part Number | Description                                 | Quantity<br>Per Unit |
|-------------|--------------------------------|---|----------------------|
| 1           | B6621101                       | Filter Frame, Weldment (SF50A)              | 1                    |
| 2           | A6683002                       | Filter, Cover Motor (SF50A)                 | 1                    |
| 3           | A6685702                       | Filter, Bracket Mounting Cover              | 1                    |
| 4           | A6684202                       | Filter, Cover Tubing (SF50A)                | 1                    |
| 5           | A6684502                       | Filter, Cover Tubing Cap                    | 1                    |
| 6           | PP10741                        | Filter, QD SNP 23 Nipple                    | 1                    |
| 7           | A6683802                       | Filter, Guard Tubing Channel                | 1                    |
| 8           | A6683102                       | Filter, Panel, Switch                       | 1                    |
| 9           | PP10331                        | Lamp, 125V Green Rectangular                | 1                    |
| 10          | PP10735                        | Switch, Rocker DPST 15A, with Breaker       | 1                    |
| 11          | A6055801                       | Label, Overlay Filter Module                | 1                    |
| 12          | A7680402                       | Plate, Switch Pasta                         | 1                    |
| 13          | A6683302                       | Filter, Box Electrical Body                 | 1                    |
| 14          | P6071062                       | Caster, 2" With Top Plate                   | 4                    |
| 15          | P0011300                       | Screw, 10-24 x 3/8" Indent Hex              | 16                   |
| 16          | PP10176                        | Nut, Center Lock 10-24                      | 16                   |
| 17          | PP10147                        | Clip, Cable 0.375 ID                        | 2                    |
| 18          | PP10107                        | Bushing, Strain Relief                      | 1                    |
| 19          | B6717901                       | Wiring, Cord, Filter with Termination       | 1                    |
| 20          | P0093300                       | Nut, Hex (KEP) 1/4-20 ZN                    | 5                    |
| 21          | A6682802                       | Filter, Guide Cable (SF50A)                 | 1                    |
| 22          | B6717101                       | Wiring, Cable Filter Assembly (SF50A)       | 1                    |
| 23          | PP10192                        | Bushing, Strain Relief 90                   | 2                    |
| 24          | PP10460                        | Switch, Rocker Circuit Breaker SPST 8A 125V | 1                    |
| 25          | PP10119                        | Label, Warning Motor Reset                  | 1                    |
| 26          | P6071490                       | Plug, Hole 7/8" Plated                      | 2                    |
| 27          | PP10692                        | Screw, 10-24 x 5/16" TH Phillips ZN         | 5                    |
| 28          | PP10752                        | Screw, 10-32 x 1/2" Thread Roller           | 18                   |
| 29          | P0000100                       | Screw, 6-32 x 7/8" RH ZN                    | 2                    |
| 30          | P009100                        | Nut, Hex 6-32 ZN (KEP)                      | 2                    |
| 31          | P0075200                       | Screw, TEK 2 #8 x 1/2" SLF DR               | 1                    |
| 32          | P6071497                       | Plug, Hole 3/4" Plated                      | 1                    |
| 33          | B6622301                       | Hose Assembly With Quick Disconnect         | 1                    |




Figure 5-4 UFM Filter, Frame/Electrical Assembly

Table 5-3 UFM Filter, Pick-Up/Pan Assembly

| Item Number | Pitco Frialator<br>Part Number | Description                                | Quantity<br>Per Unit |
|-------------|--------------------------------|--|----------------------|
| 1           | B6621001                       | Filter Pan, Weldment (SF50A)               | 1                    |
| 2           | B6620001                       | Filter, Rack                               | 1                    |
| 3           | B6617001                       | Filter, Screen Clip                        | 1                    |
| 4           | B6621202                       | Filter, Catch Crumb, Weldment              | 1                    |
| 5           | A6056001                       | Label, Filter Instruction - Pan            | 1                    |
| 6           | B6621301                       | Filter, Cover Pan. Weldment (SF50A)        | 1                    |
| 7           | P6071516                       | Handle, Door, 3" C to C                    | 1                    |
| 8           | A6681802                       | Filter, Coupling Top                       | 1                    |
| 9           | B6615301                       | Filter, Screen Inlet                       | 1                    |
| 10          | PP10409                        | 0-Ring Viton 11/16" x .094" W              | 1                    |
| 11          | B6621601                       | Filter, Tube Suction, Weldment             | 1                    |
| 12          | PP10629                        | Ring, Retaining - Internal .875"           | 1                    |
| 13          | A6684601                       | Filter, Insulation Pick-Up                 | 1                    |
| 14          | P0062100                       | Screw, 1/4-20 x 3/8" Set                   | 2                    |
| 15          | P0007300                       | Screw, 8-32 x 1/4" Hex & N 2N              | 2                    |
| 16          | PP10613                        | Filter Paper, 18-1/2" x 20-1/2" Heavy Duty | 1                    |




Figure 5-5 UFM Filter, Pick-Up/Pan Assembly

Table 5-4 UFM Filter, Motor / Return Assembly

| Item Number | Pitco Frialator<br>Part Number | Description                                  | Quantity<br>Per Unit |
|-------------|--------------------------------|--|----------------------|
| 1           | PP10101                        | Pump/Motor 1/3 HP, 115/230V, 50/60Hz         | 1                    |
|             | PP10416                        | Filter Motor Only 115V                       | 1                    |
|             | PP10417                        | Filter Pump Only UFM                         | 1                    |
| 2           | PP10106                        | Fitting, Elbow Male 90 .50D x .5 NPT         | 2                    |
| 3           | A6682702                       | Filter, Tubing Out SS (SF50A)                | 1                    |
| 4           | PP10731                        | Fitting, Elbow Male 90 .50D x .375 NPT       | 1                    |
| 5           | B6621401                       | Filter, Tubing Pump - Inlet Weldment (SF50A) | 1                    |
| 6           | PP10039                        | Heat Tape, 1/2" x79" 110V 165 Watt           | 1                    |
| 7           | PP10111                        | 0-Ring, Viton .50ID x .688 x .094W           | 2                    |
| 8           | A6685601                       | Filter, Insulator 0-Ring Fitting             | 1                    |
| 9           | P0062100                       | Screw, 1/4-20 x 3/8" Set                     | 1                    |
| 10          | B6717701                       | Wiring, Motor Harness                        | 1                    |
| 11          | PP10739                        | Thermostat, Snap Disc                        | 1                    |
| 12          | PP10687                        | Screw, 6-32 x 5/16" TH Phillips ZN           | 2                    |
| 13          | P009110                        | Nut, Hex (KEP) 6-32 ZN                       | 2                    |
| 14          | PP10738                        | Nut, Retaining Clip 5/16" -18                | 1                    |
| 15          | P0144000                       | Nut, Hex 5/16" -18 SST                       | 2                    |
| 16          | P0115000                       | Screw, 5/16" -18 x 3/4" HHC SSBB             | 3                    |




Figure 5-6 UFM-A Filter, Motor / Return Assembly

**Table 5-5 Built-in Filter Pan With Components** 

| Item Number | Pitco Frialator<br>Part Number | Description                 | Quantity<br>Per Unit |
|-------------|--------------------------------|-----------------------------|----------------------|
| 1           | B6602001                       | Pan #14                     | 1                    |
|             | B6602101                       | Pan #18                     | 1                    |
| 2           | B6603001                       | Paper Retainer #14          | 1                    |
|             | B6603002                       | Paper Retainer #18          | 1                    |
| 3           | B6602401                       | Hose #14                    | 1                    |
|             | B6602402                       | Hose #18                    | 1                    |
| 4           | P6071123                       | Quick Disconnect, Male      | 1                    |
| 5           | P7037752-1                     | Elbow 90° 3/8 Street Plated | 1                    |
| 6           | A6641802                       | Handle #14                  | 2                    |
|             | A6641804                       | Handle #18                  | 2                    |
| 7           | P'6072611                      | Paper Support Rack #14      | 1                    |
|             | P6072612                       | Paper Support Rack #18      | 1                    |
| 8           | P7037316-1                     | Stand Pipe #14              | 1                    |
|             | P7037320-1                     | Stand Pipe #18              | 1                    |
| 9           | P7037675                       | Elbow 90° 3/8 Plated        | 1                    |




Figure 5-7 Built-in Filter Pan With Components

Table 5-6 Built-in Filter Piping With Components

| Item Number | Pitco Frialator<br>Part Number | Description                      | Quantity<br>Per Unit |
|-------------|--------------------------------|----------------------------------|----------------------|
| 1           | P5046381                       | Filter Pump and Motor Assy       | 1                    |
| 2           | P6071530                       | Filter Pump Only (Non-UFM)       | 1                    |
| 3           | P5046384                       | Filter Motor Only 115V (Non-UFM) | 1                    |
| 4           | B7402241                       | Quick Disconnect                 | 1                    |
| 5           | P0020600                       | Bolt 1/4-20x5/8"                 | 4                    |
| 6           | P0080650                       | Washer, Flat                     | 8                    |
| 7           | P0093300                       | Nut, Keep                        | 4                    |

**Revised** 5/28/93




Figure 5-8 Built-in Filter Piping With Components

Table 5-7 Built-in Filter With Accessories

| Item<br>Number | Pitco Frialator<br>Part Number | Description                      | Quantity<br>Per Unit |
|----------------|--------------------------------|----------------------------------|----------------------|
| 1              | P5044768                       | Food Warmer, Built-in            | 1                    |
|                | P5044760                       | Food Warmer, Free Standing       | 1                    |
| 2              | P6072155                       | Drain Screen #14                 | 1                    |
|                | P6072156                       | Drain Screen #18                 | 1                    |
| 3              | B5802001                       | Pan Liner #14                    | 1                    |
|                | B5802003                       | Pan Liner #18                    | 1                    |
| 4              | PP10732                        | Filter Powder, 8oz Packet Sample |                      |
| 5              | P6071371                       | Paper #14 Standard               |                      |
|                | PP10612                        | Paper #14 Heavy Duty             |                      |
|                | P6071373                       | Paper #18 Standard               |                      |
|                | PP10606                        | Paper #18 Heavy Duty             |                      |
| 6              | Al 100802                      | Basket Hanger #14                | 1                    |
|                | A1100804                       | Basket Hanger #18                | 1                    |

**Revised** 5/28/93




Figure 5-9 Built-In Filter With Accessories

#### ALPHABETICAL PART LIST

| Part Description                                | Models<br>Used on | Pitco Frialator<br>Part No. |
|---|-------------------|-----------------------------|
| ADAPTER, DRAIN VALVE END 14/18 UFM/BIF LH       | ALL               | B6610801                    |
| ADAPTER, DRAIN VALVE END 14/18 UFM/BIF RH       | ALL               | B6610901                    |
| ADAPTOR, DRAIN VALVE CENTER LINE UFM            | ALL               | B6610701                    |
| ADAPTER, DRAIN VALVE END 7 UFM                  | ALL               | B7412602                    |
| AIR COLLAR N/S NO THREADS                       | ALL               | A8001001                    |
| BAFFLE TANK 14PR & 14PM -14R                    | 14PR,             | 710001001                   |
|   | 14PM-14R          | B1000601                    |
| BAFFLE TANK 6-12                                | 6,12              | B1000701                    |
| BAFFLES, WELDMENT 7-14-18 STANDARD              | 7,14,18           | B1000801                    |
| BASKET HANGER, #7 STAINLESS STEEL               | 7                 | A1100102                    |
| BASKET HANGER, #12 C/R STD ONLY                 | 12                | A1102903                    |
| BASKET HANGER, #12 S/S STD ONLY                 | 12                | A1102904                    |
| BASKET HANGER, #14 S/S STD ONLY                 | 14,14R            | A1100108                    |
| BASKET HANGER, #18 S/S STD ONLY                 | 18                | A1100110                    |
| BASKET HANGER #18 C/R STD. ONLY                 | 18                | A1100109                    |
| BASKET HANGER #14 C/R STD ONLY                  | 14.14R            | A1100107                    |
| BASKET HANGER #7 C/R STD ONLY                   | 7                 | A1100101                    |
| BASKET RM OBL TWIN #18                          | 18                | P6072184                    |
| BASKET OBLG LONG HANDLE, FINE MESH #18,         | 18                | P6072188                    |
| BASKET OBLG LONG HANDLE, REGULAR MESH,          |                   |                             |
| #18, 3-PER FRYER                                | 18                | P6072185                    |
| BASKET, OBLG 13-1/2" X 6-1/2" X 5-1/2" DEEP,    |                   |                             |
| LONG HANDLE, REGULAR MESH                       | 7,14              | P6072145                    |
| BASKET, OBLG 13-1/2" X 6-1/2" X 5-1/2" DEEP,    |                   |                             |
| LONG HANDLE, FINE MESH                          | 7,14              | P6072146                    |
| BASKET, OBLG 11-1/2" X 5-1/2" X 4-1/4",         |                   |                             |
| LONG HANDLE, REGULAR MESH                       | 12                | P6072125                    |
| BASKET, OBLG 11-1/2" X 5-1/2" X 4-1/4",         |                   |                             |
| LONG HANDLE, FINE MESH                          | 12                | P6072126                    |
| BASKET, OBLG 13-1/2" X 4-1/2" X 5-1/2" DEEP,    |                   |                             |
| LONG HANDLE, REGULAR MESH, 3 PER FRYER          | 14                | P6072147                    |
| BASKET, SQUARE 13-1/2" X 13-1/2" X 5-1/2" DEEP, |                   |                             |
| LONG HANDLE, REGULAR MESH                       | 14                | P6072143                    |
| BASKET, SQUARE 13-1/2" X 13-1/2" X 5-1/2" DEEP, |                   |                             |
| LONG HANDLE, FINE MESH                          | 14                | P6072144                    |
| BASKET, SQUARE 11-1/2" X 11-1/2" X 4-1/4",      |                   |                             |
| LONG HANDLE, REGULAR MESH                       | 12                | P6072123                    |
| BASKET, SQUARE 11-1/2" X 11-1/2" X 4-1/4",      |                   |                             |
| LONG HANDLE, FINE MESH                          | 12                | P6072124                    |
| BASKET SQ SIDE HANDLES #18, FINE MESH           | 18                | P6072187                    |

| Part Description                          | Models<br>Used on | Pitco Frialator<br>Part No. |
|---|-------------------|-----------------------------|
| BASKET SQ FRONT HANDLES #18, FINE MESH    | 18                | P6072181                    |
| BASKET SQ SIDE HANDLES #18, REGULAR MESH  | 18                | P6072180                    |
| BRACKET, DOOR MAGNET                      | ALL               | A1819602                    |
| BRACKET T-STAT A GS                       | ALL               | A8006101                    |
| BRACKET T-STAT B GS                       | ALL               | A8006001                    |
| BRUSH FRYER CLEANING                      | ALL               | PP10056                     |
| BURNER FITTING N/S NO THREADS             | ALL               | A8001101                    |
| BURNER, PILOT 6CH-14-6, NATURAL GAS       | ALL               | P6071450                    |
| BURNER, PILOT 6CH-14-6, LP GAS            | ALL               | P6071449                    |
| BURNER, PILOT WITH HIGH VOLTAGE UFM       | ALL               | PP10280                     |
| BURNER 4"                                 | 7,14,18           | P6071050                    |
| BURNER 4" WITHOUT PORTS                   | 7,14,18           | P6071049                    |
| BURNER 6"                                 | 14R.PR14          |                             |
|   | PM14              | P6071051                    |
| BURNER BOLT                               | ALL               | P0115000                    |
| BUSHING, STRAIN RELIEF                    | UFM               | PP10107                     |
| BUSHING, STRAIN RELIEF 90                 | UFM               | PP10192                     |
| CABLE, CONTROL-PC 16AWG 150°C             | UFM               | PP10200                     |
| CASTER (4/FILTER)                         | UFM,BIF           | P6071062                    |
| CASTER ASSEMBLY 7" WITH LOCKING DEVICE    | UFM               | PP10811                     |
| CASTER ASSEMBLY 7" WITHOUT LOCKING DEVICE | UFM               | PP10810                     |
| CASTER ASSEMBLY ADJ 6" W/OUT LOCK         | ALL               | PP10808                     |
| CASTER ASSEMBLY ADJUSTABLE 6" W/LOCK      | ALL               | PP10809                     |
| CASTER SET 6"                             | ALL               | B3901501                    |
| CASTER SET 7"                             | ALL               | B3901502                    |
| CATCH MAGNET STANDARD                     | ALL               | P6071300                    |
| CHANNEL STRIP #12                         | 12                | A1900102                    |
| CHANNEL STRIP #14-2                       | 14                | A1900104                    |
| CHANNEL STRIP #18-2                       | 18                | A1900114                    |
| CIRCUIT BREAKER                           | ALL               | PP10104                     |
| CLAMP, BAND (FILTER)                      | ALL               | PP10034                     |
| CLEAN-OUT ROD                             | ALL               | A3301001                    |
| CLEANER FRYER, 25 LB.                     | ALL               | P6071397                    |
| CLIP CABLE .375ID                         | UFM               | PP10147                     |
| COMPUTER MODULE 8 PROD 14/18-884-LP       | ALL               | PP10401                     |
| COMPUTER MODULE 1 PROD 14/18-184 LP       | ALL               | PP10400                     |
| COMPUTER MODULE 1 PROD 7-184 NAT          | 7                 | P5044856                    |
| COMPUTER MODULE 1 PROD 7-184 LP           | 7                 | PP10398                     |
| COMPUTER MODULE 1 PROD 14/18 184 NAT      | 14,18             | P5044851                    |
| COMPUTER MODULE 8 PROD 14/18-884 NAT      | 14,18             | P5044850                    |

|   | Models  | Pitco Frialator |
|---|---------|-----------------|
| Part Description                                | Used on | Part No.        |
| COMPUTER MODULE 8 PROD 7-884 NAT                | 7       | P5044855        |
| COMPUTER MODULE 8 PROD 7-884 LP                 | 7       | PP10399         |
| CONVERSION KIT #12 TO LP NON-EI                 | 12      | B7510006        |
| CONVERSION KIT #12 TO NAT NON-EI                | 12      | B7510005        |
| CONVERSION KIT #14 TO LP NON-EI                 | ALL     | B7510008        |
| CONVERSION KIT #14 TO NAT NON-EI                | ALL     | B7510007        |
| CONVERSION KIT #14R TO LP NON-EI                | ALL     | B7510042        |
| CONVERSION KIT #14R TO NAT NON-EI               | ALL     | B7510041        |
| CONVERSION KIT #18 TO LP NON-EI                 | ALL     | B7510012        |
| CONVERSION KIT #18 TO NAT NON-EI                | ALL     | B7510011        |
| CONVERSION KIT #7 TO LP NON-EI                  | ALL     | B7510004        |
| CONVERSION KIT #7 TO NAT NON-EI                 | ALL     | B7510003        |
| CORD, PLUG MOLDED 16-3 NEMA 5-15P               | UFM     | PP10609         |
| CORD, POWER SUPPLY - 14 AWG                     | ALL     | PP10452         |
| CORD PLUG MOLDED 16-3 SJO                       | ALL     | PP10439         |
| COVER, SIDE                                     | ALL     | A6613101        |
| CRUMB CATCH                                     | UFM     | B6621201        |
| CRUMB CATCH BASKET                              | BIF     | P6072165        |
| CRUMB CATCH RETAINER 14                         | 14      | B6601901        |
| CRUMB CATCH RETAINER 18                         | 18      | B6601902        |
| DOOR, UFM 7 LEFT & RIGHT, UNIVERSAL             | 7       | B2301207        |
| DOOR, UFM 14 LEFT & RIGHT, UNIVERSAL            | 14      | B2301208        |
| DOOR, UFM 18 LEFT & RIGHT, UNIVERSAL            | 18      | B2301210        |
| DOOR, 7, UNIVERSAL                              | 7       | B2301202        |
| DOOR, 14, UNIVERSAL                             | 14      | B2301205        |
| DOOR, 18, UNIVERSAL                             | 18      | B2301206        |
| DRAIN ELBOW, SHORT BIF                          | BIF     | B6621901        |
| DRAIN ELBOW, LONG BIF                           | BIF     | B6621902        |
| DRAIN LINE RETAINER RING                        | ALL     | A6643001        |
| DRAIN OUTLET EXT. 1-1/4 X 6" NON-FILTERED UNITS | ALL     | A2502503        |
| DRAIN SCREEN #14                                | BIF     | P6072155        |
| DRAIN SCREEN #18                                | BIF     | P6072156        |
| FILTER, COVER PAN, WELDMENT (SF50A)             | UFM     | B6621301        |
| FILTER, COVER PAN, WELDMENT (SF65A)             | UFM     | B6621302        |
| FILTER CRUMB SCOOP                              | ALL     | B7404801        |
| FILTER HOSE UFM RPB14 ONLY                      | RPB14   | B6622002        |
| FILTER HOSE UFM                                 | UFM     | B6622001        |
| FILTER, INSULATION PICK-UP                      | UFM     | A6684601        |
| FILTER, INSULATOR TOP                           | UFM     | A6685401        |
| FILTER MOTOR ONLY, 110V                         | BIF     | P5046384        |

|  | Models  | Pitco Frialator |
|--|---------|-----------------|
| Part Description                             | Used on | Part No.        |
| FILTER MOTOR ONLY, 115V, SF50/65             | UFM     | PP10416         |
| FILTER PAN, WELDMENT (SF50A)                 | UFM     | B6621001        |
| FILTER PAN, WELDMENT (SF65A)                 | UFM     | B6621002        |
| FILTER, PIPING DRAIN TEE LH                  | UFM.BIF | B6610801        |
| FILTER, PIPING DRAIN TEE RH                  | UFM.BIF | B6610901        |
| FILTER POWDER 120 PACKETS, 80Z               | ALL     | PP10733         |
| FILTER PUMP AND MOTOR ASSY 110V              | BIF     | P5046381        |
| FILTER PUMP ONLY 110V (NON-UFM)              | BIF     | P6071530        |
| FILTER PUMP & MOTOR ASSEMBLY, 115/230 VAC,   |         |                 |
| 60HZ, 1/3 HP                                 | UFM     | PP10101         |
| FILTER PUMP & MOTOR ASSEMBLY, 250 VAC,       |         |                 |
| 50 HZ 1/3 HP                                 | UFM     | PP10171         |
| FILTER PUMP ONLY, SF50/65                    | UFM     | PP10417         |
| FILTER, QD SNP 23 NIPPLE                     | UFM     | PP10741         |
| FILTER RACK                                  | UFM     | B6620001        |
| FILTER RETURN INSULATION DISCONNECT ASSY, FM | UFM     | B6622801        |
| FILTER, SCREEN CLIP                          | UFM     | B6617001        |
| FILTER, TUBE SUCTION, COMPLETE               | UFM     | B6621701        |
| FISH GRID 13-1/4" X 13-1/4"                  | 14      | B7425301        |
| FISH GRID 17-1/2 X 17-1/2"                   | 18      | B7425401        |
| FITTING, ELBOW MALE 90 .50D X -5NPT          | ALL     | PP10106         |
| FLOAT RETAINER CLIP                          | ALL     | P7038080        |
| FLOAT SWITCH, 24" WIRE                       | ALL     | P5047217        |
| FLUSH HOSE ASSY COMPLETE 5 FOOT              | ALL     | B6602501        |
| FLUSH HOSE ASSY COMPLETE 6 FOOT              | ALL     | B6602502        |
| FLUSH HOSE ASSY COMPLETE 8 FOOT              | ALL     | B6608501        |
| FRONT PANEL, WELDMENT                        | ALL     | CALL            |
|  |         | FACTORY         |
| FRYER CRUMB SCOOP                            | ALL     | B7490701        |
| FUSE, 2 AMP SLOW BLOW                        | ALL     | P5045700        |
| FUSE, 2 AMP SLOW BLOW, GLASS                 | ALL     | P5045717        |
| FUSE, 4A SLOW BLOW GLASS                     | ALL     | P5045720        |
| FUSE, 7A-SLOW BLOW (GLASS)                   | ALL     | P5045721        |
| FUSE, 1 AMP SLOW BLOW GLASS                  | ALL     | PP10122         |
| FUSE HOLDER                                  | ALL     | P5045794        |
| GAS VALVE, UNITROL 1/2" AMSGOR LP            | 12      | P5045658        |
| GAS VALVE, UNITROL 1/2" AMSGOR NAT           | 12      | P5045659        |
| GAS VALVE, 24V El (NAT)                      | ALL     | PP10593         |
| GAS VALVE, 24V EI (LP)                       | ALL     | PP10594         |
| GASKET, DRAIN LINE (SLEEVE)                  | ALL     | PP10032         |

|   | Models    | Pitco Frialator |
|---|-----------|-----------------|
| Part Description                                    | Used on   | Part No.        |
| GAS VALVE, 24V El (LP)                              | ALL       | PP10594         |
| GASKET, DRAIN LINE (SLEEVE)                         | ALL       | PP10032         |
| GASKET RETAINER                                     | UFM       | A6668302        |
| HANDLE, DOOR, CHROME 3" CTOC                        | ALL       | P6071516        |
| HANDLE, DRAIN VALVE, 7 GAS                          | ALL       | B4000701        |
| HANDLE, VALVE 3/8 BALL, COATED RED                  | ALL       | PP10048         |
| HANDLE, VALVE 3/8 BALL, COATED BLUE                 | ALL       | PP10049         |
| HANDLE, VALVE 3/8 BALL, COATED YELLOW               | ALL       | PP10050         |
| HANDLE, DRAIN VALVE, 7,14, 18/UFM                   | ALL       | B4000707        |
| HANDLE, DRAIN VALVE, BIF 14R                        | 14,18     | B4000705        |
| HANDLE, NOZZLE (BLACK)                              | ALL       | P6071190        |
| HEAT TAPE, 1/2" X 79", 110V, 165 WATT (SF50A/SF65A) | UFM       | PP10039         |
| HEATER STRIP, FILTER PAN - 500W                     | BIF       | P5046980        |
| HEATER TAPE 110V, 165W, 1/2 X 79                    | UFM       | PP10039         |
| HINGE, DOOR-WELDMENT T L, B R CR                    | 14,18 UFM | B3800101        |
| HINGE, DOOR-WELDMENT T R, B R CR                    | 14,18 UFM | B3800103        |
| HINGE DOOR BOTTOM L.H. (AL/S)                       | ALL       | B7230301        |
| HINGE DOOR BOTTOM R.H.(AL/S)                        | ALL       | B7230302        |
| HINGE DOOR TOP L.H. (AL/S)                          | ALL       | B7230201        |
| HINGE DOOR TOP R.H. (AL/S)                          | ALL       | B7230202        |
| HOSE ASSEMBLY WITH QUICK DISCONNECT                 | UFM       | B6622301        |
| HOSE, FLUSH, 5 FOOT W/ENDS P/D                      | ALL       | B6602405        |
| HOSE, FLUSH, 6 FOOT W/ENDS P/D                      | ALL       | B6602406        |
| HOSE, INLET BIF/14 PITCO                            | 14 BIF    | B6602401        |
| HOSE, INLET BIF/18 PITCO                            | 18 BIF    | B6602402        |
| HOSE, QUICK DISCONNECT, COMPLETE - NON RPB          | UFM       | B6622301        |
| HOSE NOZZLE ONLY, FLUSH                             | ALL       | B6604401        |
| IGNITION CONTROL, G77-MGC LP                        | ALL       | PP10070         |
| IGNITION CONTROL, G77-MGA NAT                       | ALL       | PP10071         |
| KNOB, EXTENSION UNITROL 14B/14R                     | 14R       | B7510102        |
| KNOB, EXTENSION UNITROL 12 COUNTER                  | 12        | B7510101        |
| KNOB, 200-400 GAS, GS OIL                           | ALL       | PP10537         |
| KNOB, 200-400 OFF ELECTRIC                          | ALL       | PP10539         |
| LABEL, BLUE FLUSH DRAIN VALVE                       | ALL       | PP10030         |
| LABEL, FILTER INSTRUCTION - PAN                     | UFM       | A6056001        |
| LABEL, GREEN DRAIN VALVE                            | ALL       | PP10031         |
| LABEL, RED RETURN VALVE                             | ALL       | PP10029         |
| LABEL, WARNING-MOTOR RESET                          | UFM       | PP10119         |
| LAMP, 125V GREEN RECT W/S                           | UFM       | PP10331         |
| LAMP, RECTANGULAR-CLEAR 24 VAC                      | ALL       | P5045043        |

| Part Description                                 | Models  | Pitco Frialator |
|--|---------|-----------------|
| -  | Used on | Part No.        |
| LAMP, RECTANGULAR-AMBER 24 VAC                   | ALL     | P5045044        |
| LAMP, 125 VAC AMBER RECTANGULAR                  | ALL     | PP10082         |
| LAMP, 125 VAC WHITE RECTANGULAR                  | ALL     | PP10083         |
| LAMP, 250 VAC - AMBER                            | UFM     | PP10100         |
| LAMP GREEN RECT. 28V                             | ALL     | P5045042        |
| LAMP RED RECT. 28V                               | ALL     | P5045040        |
| LEG, ADJUSTABLE, 7"                              | UFM     | B3900408        |
| LEG ADJUSTABLE 6"                                | ALL     | B3900909        |
| LEG, ADJUSTABLE 6" SET                           | ALL     | B3900701        |
| MAGNET, DOOR                                     | ALL     | P6071300        |
| MECH. TIMER DPDT W/OFF POSITION                  | ALL     | PP10232         |
| MOTOR RIGHT REAR, MOUNT TYPE, BASKET LIFT        | ALL     | P5046380        |
| MOTOR LEFT REAR, MOUNT TYPE, BASKET LIFT         | ALL     | B1000007        |
| 0-RING, VITON .50ID X .688 X .094W (SF50A/SF65A) | UFM     | PP10111         |
| ORIFICE, PILOT, ELECTRONIC IGNITION, NAT         | ALL     | P6071331        |
| ORIFICE, PILOT, ELECTRONIC IGNITION, LP GAS      | ALL     | P6071332        |
| PAN ASSY BF14                                    | 14      | B6602001        |
| PAN ASSY BF18                                    | 18      | B6602101        |
| PAN ASSY UFM 14 SF50A                            | 14 UFM  | B6621001        |
| PAN ASSY UFM 18 SF65A                            | 18 UFM  | B6621002        |
| PAN LINER #14                                    | 14BIF   | B5802001        |
| PAN LINER#18                                     | 18BIF   | B5802003        |
| PAPER 13-1/2" X 24" PITCO #14 BIF/PORTABLE       | 14      | P6071371        |
| PAPER 17-1/2" X 28" PITCO #18-34 BIF/PORTABLE    | 18-34   | P6071373        |
| PAPER 18 X 20-1/2 UFM 14 & 18                    | 14,18   | PP10613         |
| PAPER RETAINER RACK 14 PITCO                     | 14      | B6603001        |
| PAPER RETAINER RACK 18 PITCO                     | 14      | B6603002        |
| PAPER SUPPORT RACK 14 PITCO                      | 14      | P6072611        |
| PAPER SUPPORT RACK 18-34 PITCO                   | 18      | P6072612        |
| PILOT COMP, WITH HEAT SHIELD, LP STD.            | ALL     | B3302602        |
| PILOT COMP, WITH HEAT SHIELD, NAT STD.           | ALL     | B3302601        |
| PILOT W/HIGH VOLTAGE WIRE EI                     | 14,18   | P5045410        |
| PLUG, HOLE 3/4" PLATED                           | UFM     | P6071467        |
| PLUG, HOLE 7/8"                                  | ALL     | P6071490        |
| PLUG, HOLE 2"                                    | ALL     | P6071448        |
| PROBE CLAMP, HIGH LIMIT                          | ALL     | B7370402        |
| PROBE ELECTRONIC IGNITION, FLAME SENSING         | ALL     | P5046626        |
| QUICK DISCONNECT, MALE                           | BIF     | P6071123        |
| QUICK DISCONNECT, FEMALE BLACK RING              | BIF     | B7402241        |
| QUICK DISCONNECT, FEMALE WHITE RING              | BIF     | B7402240        |

| Part Description                                | Models  | Pitco Frialator<br>Part No. |
|---|---------|-----------------------------|
|   | Used on |                             |
| QUICK DISCONNECT RING ONLY, WHITE               | BIF     | P6071253                    |
| QUICK DISCONNECT RING ONLY, BLACK               | BIF     | P6071254                    |
| RECEPTACLE, 3 PRONG, 15A, 125VAC                | ALL     | PP10103                     |
| RELAY, 24 VAC DPDT                              | ALL     | P5046686                    |
| RELAY, 24 VAC SPDT (MTG. TAB)                   | ALL     | P5046688                    |
| RELAY24 VDC SPDT                                | ALL     | P5046690                    |
| ROLLER GAS REAR LIFT TYPE, BASKET LIFT          | ALL     | P6071024                    |
| SCREEN BREAD & BATTER PAN #14 GAS & ELEC        | BIF     | P6072155                    |
| SCREEN BREAD & BATTER PAN #18 GAS & ELEC        | BIF     | P6072156                    |
| SCREW S/ROLLER GAS, REAR TYPE                   | ALL     | P0048980                    |
| SEAL DRAIN ELBOW ROUND                          | ALL     | PP10045                     |
| SNAP TITE FEMALE BLACK ASSY                     | BIF     | B7402241                    |
| SNAP TITE FEMALE WHITE ASSY                     | BIF     | B7402240                    |
| SWITCH, PROXIMITY SENSOR                        | ALL     | PP10262                     |
| SWITCH, PROXIMITY ACTUATOR                      | ALL     | PP10263                     |
| SWITCH ROCKER, CKT BKR, 8 AMP, SPST 115 VAC     | UFM     | PP10460                     |
| SWITCH ROCKER, CKT BKR, 4 AMP, DPST 240VAC      | UFM     | PP10470                     |
| SWITCH, ROLLER - SPDT (BASKET LIFT)             | ALL     | P5047169                    |
| SWITCH, HI-LIMIT LCHM 05030                     | ALL     | PP10084                     |
| SWITCH, ROCKER, DPDT W/BK (ON/OFF/MON ON)       | ALL     | PP10094                     |
| SWITCH, DPDT ON-OFF-ON - MINI                   | ALL     | PP10097                     |
| SWITCH, ROCKER, DPDT (ON-OFF-ON)                | ALL     | PP10098                     |
| TANK, WELDMENT, ALL                             | ALL     | CALL                        |
|   |         | FACTORY                     |
| THERMOPILE CP2 24" NO El                        | ALL     | P5047541                    |
| THERMOSTAT, ELECTRIC SPST KX-299-36, COMP. B.U. | ALL     | P5047587                    |
| THERMOSTAT KNOB GO & C5                         | ALL     | P6071270                    |
| THERMOSTAT, SNAP DISC                           | UFM     | PP10739                     |
| T-STAT & LIMIT GAS BULB CLAMP                   | ALL     | A1401002                    |
| T-STAT DIAL LOCK                                | ALL     | P6071505                    |
| T-STAT G5-OIL THERMOSTAT                        | ALL     | P5047588                    |
| T-STAT G5 POTENTIOMETER 0-475 OHM               | ALL     | B6702601                    |
| T-STAT G5 SOLID STATE MODULE                    | ALL     | P5046355                    |
| T-STAT, GO SOLID STATE MODULE W/MELT LP         | ALL     | PP10540                     |
| T-STAT, GO SOLID STATE MODULE W/MELT            | ALL     | P5046356                    |
| T-STAT, SOLID STATE MODULE GO 24 VAC LP         | ALL     | PP10561                     |
| T-STAT, SOLID STATE MOD GO 24 VAC ON-4S OFF-26S | ALL     | PP10562                     |
| T-STAT, GO POTENTIOMETER, 0-900 OHM             | ALL     | P5046582                    |
| T-STAT PROBE FOR GO, G5 & COMPUTER GAS          | ALL     | B6700601                    |
| TIMER, 15 MIN, 115V 60 HZ                       | ALL     | P5047561                    |

| Part Description                     | Models  | Pitco Frialator |
|--------------------------------------|---------|-----------------|
| Tale Bescription                     | Used on | Part No.        |
| TIMER, MECHANICAL (15 MIN.)          | ALL     | P6071710        |
| TIMER 15 MIN., 240V 50 HZ            | ALL     | PP10095         |
| TIMER KNOB BUTTON, ALL               | ALL     | P6071280        |
| TIMER KNOBS, ALL                     | ALL     | P6071279        |
| TIMER MELT, SOLID STATE, 115 VAC     | ALL     | P5047564        |
| TRANSFORMER 120/208/240 TO 24V 40 VA | ALL     | PP10210         |
| TRANSFORMER 208-240 TO 120 VAC 56 VA | ALL     | PP10211         |
| TUBE RACK 11-1/2" X 11-1/2"          | 12      | P6073128        |
| TUBE RACK #14                        | 14      | P6073148        |
| TUBE RACK #18                        | 18      | P6073186        |
| TUBE SCREEN (MESH) #18               | 18      | P6072186        |
| TUBE SCREEN (MESH) 14 14R            | 14      | P6072148        |
| TUBE SCREEN 13-1/2" X 7-1/2"         | 7       | P6072108        |
| TUBE SCREEN 11-1/2" X 11-1/2"        | 12      | P6072128        |
| UNITROL 1/2" AMSER, 120 VAC LP       | 7       | P5045656        |
| UNITROL 1/2" AMSER, 120 VAC NAT      | 7       | P5045657        |
| UNITROL 1/2" AMSER, 24 VAC LP        | 7       | P5045641        |
| UNITROL 1/2" AMSER, 24 VAC NAT       | 7       | P5045640        |
| UNITROL 1/2" AMSGOR, LP              | 7       | P5045658        |
| UNITROL 1/2" AMSGOR, NAT             | 7       | P5045659        |
| UNITROL 1/2" BMSER, 120 VAC LP       | 14,18   | P5045652        |
| UNITROL 1/2" BMSER, 120 VAC NAT      | 14,18   | P5045650        |
| UNITROL 1/2" BMSER, 24 VAC NAT       | 14,18   | P5045638        |
| UNITROL 1/2" BMSER, 24 VAC LP        | 14,18   | P5045639        |
| UNITROL 1/2" BMSGOR, LP              | 14,18   | P5045644        |
| UNITROL 1/2" BMSGOR, NAT             | 14,18   | P5045642        |
| UNITROL ACTUATOR 115 VAC             | ALL     | P5045002        |
| UNITROL ACTUATOR 24 VAC              | ALL     | P5045005        |
| UNITROL KNOB                         | ALL     | P6071267        |
| UNITROL PRESS/REGULATOR LP ONLY      | ALL     | P6071553        |
| UNITROL PRESS/REGULATOR NAT ONLY     | ALL     | P6071551        |
| VALVE, BALL 3/8" PLTD W/0 HANDLE     | ALL     | P6071780        |
| VALVE, 1" UNPLATED, DRAIN            | 12      | P6171769        |
| VALVE, BALL 1 1/4"                   | ALL     | P6071785        |
| VALVE EI GAS LP W/IGN G60 & G600     | ALL     | P6071777        |
| VALVE EI GAS NAT W/IGN G60 & G600    | ALL     | P6071776        |
| VALVE GAS, MANUAL SHUT-OFF EI        | ALL     | P6071767        |
| WIRE EI SENSING PROBE                | ALL     | P5045113        |
| WIRE RADIX ASSEMBLY                  | ALL     | B6779850        |

#### NUMERICAL PART LIST

| Pitco Frialator<br>Part No. | Part Description                                | Models<br>Used on |
|-----------------------------|---|-------------------|
| A1100101                    | BASKET HANGER #7 C/R STD ONLY                   | 7                 |
| Al 100102                   | BASKET HANGER, #7 S/S STD ONLY                  | 7                 |
| A1100107                    | BASKET HANGER #14 C/R STD ONLY                  | 14 & 14R          |
| A1100108                    | BASKET HANGER, #14 S/S STD ONLY                 | 14 & 14R          |
| Al 100109                   | BASKET HANGER #18 C/R STD. ONLY                 | 18                |
| A1100110                    | BASKET HANGER, #18 S/S STD ONLY                 | 18                |
| A1102903                    | BASKET HANGER #12 C/R STD ONLY                  | 12                |
| A1102904                    | BASKET HANGER #12 S/S STD ONLY                  | 12                |
| A1401002                    | T-STAT & LIMIT GAS BULB CLAMP                   | ALL               |
| A1819602                    | BRACKET, DOOR MAGNET                            | ALL               |
| A1900102                    | CHANNEL STRIP #12                               | 12                |
| A1900104                    | CHANNEL STRIP #14-2                             | 14                |
| A1900114                    | CHANNEL STRIP #18-2                             | 18                |
| A2502503                    | DRAIN OUTLET EXT. 1-1/4 X 6" NON-FILTERED UNITS | ALL               |
| A3301001                    | CLEAN-OUT ROD                                   | ALL               |
| A6056001                    | LABEL, FILTER INSTRUCTION - PAN                 | UFM               |
| A6613101                    | COVER, SIDE                                     | ALL               |
| A6643001                    | DRAIN LINE RETAINER RING                        | ALL               |
| A6668302                    | GASKET RETAINER                                 | UFM               |
| A6684601                    | FILTER, INSULATION PICK-UP                      | UFM               |
| A6685401                    | FILTER, INSULATOR TOP                           | UFM               |
| A8001001                    | AIR COLLAR N/S NO THREADS                       | ALL               |
| A8001101                    | BURNER FITTING N/S NO THREADS                   | ALL               |
| A8006001                    | BRACKET T-STAT B GS                             | ALL               |
| A8006101                    | BRACKET T-STAT A GS                             | ALL               |
| B1000007                    | MOTOR LEFT REAR, MOUNT TYPE, BASKET LIFT        | ALL               |
| B1000601                    | BAFFLE TANK 14PR & 14PM -14R                    | 14PR&             |
|                             |   | 14PM-14R          |
| B1000701                    | BAFFLE TANK 6-12                                | 6,12              |
| B1000801                    | BAFFLES, WELDMENT 7-14-18 STANDARD              | 7,14,18           |
| B2301202                    | DOOR, 7, UNIVERSAL                              | 7                 |
| B2301205                    | DOOR, 14, UNIVERSAL                             | 14                |
| B2301206                    | DOOR, 18, UNIVERSAL                             | 18                |
| B2301207                    | DOOR, UFM 7 LEFT & RIGHT, UNIVERSAL             | 7                 |
| B2301208                    | DOOR, UFM 14 LEFT & RIGHT, UNIVERSAL            | 14                |
| B2301210                    | DOOR, UFM 18 LEFT & RIGHT, UNIVERSAL            | 18                |
| B3302601                    | PILOT COMP, WITH HEAT SHIELD, NAT STD.          | ALL               |
| B3302602                    | PILOT COMP, WITH HEAT SHIELD, LP STD.           | ALL               |
| B3800101                    | HINGE, DOOR-WELDMENT T L, B R CR                | 14,18 UFM         |
| B3800103                    | HINGE, DOOR-WELDMENT T R, B R CR                | 14,18 UFM         |

| Pitco Frialator<br>Part No. | Part Description                          | Models<br>Used on |
|-----------------------------|---|-------------------|
| B3900408                    | LEG, ADJUSTABLE, 7"                       | UFM               |
| B3900701                    | LEG, ADJUSTABLE 6" SET                    | ALL               |
| B3900909                    | LEG ADJUSTABLE 6"                         | ALL               |
| B4000701                    | HANDLE, DRAIN VALVE, 7 GAS                | ALL               |
| B4000705                    | HANDLE, DRAIN VALVE, BIF 14R              | 14,18             |
| B4000707                    | HANDLE, DRAIN VALVE, 7,14, 18/UFM         | ALL               |
| B3901501                    | CASTER SET 6"                             | ALL               |
| B3901506                    | CASTER SET 7"                             | ALL               |
| B5802001                    | PAN LINER #14                             | 14 BIF            |
| B5802003                    | PAN LINER #18                             | 18 BIF            |
| B6601901                    | CRUMB CATCH RETAINER 14                   | 14                |
| B6601902                    | CRUMB CATCH RETAINER 18                   | 18                |
| B6602001                    | PAN ASSY BF14                             | 14                |
| B6602101                    | PAN ASSY BF18                             | 18                |
| B6602401                    | HOSE INLET BIF/14 PITCO                   | 14 BIF            |
| B6602402                    | HOSE INLET BIF/18 PITCO                   | 18 BIF            |
| B6602405                    | HOSE FLUSH, 5 FOOT W/ENDS P/D             | ALL               |
| B6602406                    | HOSE FLUSH, 6 FOOT W/ENDS P/D             | ALL               |
| B6602501                    | FLUSH HOSE ASSY COMPLETE 5 FOOT           | ALL               |
| B6602502                    | FLUSH HOSE ASSY COMPLETE 6 FOOT           | ALL               |
| B6603001                    | PAPER RETAINER RACK 14 PITCO              | 14                |
| B6603002                    | PAPER RETAINER RACK 18 PITCO              | 14                |
| B6604401                    | HOSE NOZZLE ONLY, FLUSH                   | ALL               |
| B6608501                    | FLUSH HOSE ASSY COMPLETE 8 FOOT           | ALL               |
| B6610701                    | ADAPTER, DRAIN VALVE CENTER LINE UFM/BIF  | ALL               |
| B6610801                    | ADAPTER, DRAIN VALVE END 14/18 LH UFM/BIF | ALL               |
| B6610801                    | FILTER, PIPING DRAIN TEE LH               | UFM.BIF           |
| B6610901                    | ADAPTER, DRAIN VALVE END 14/18 RH UFM/BIF | ALL               |
| B6610901                    | FILTER, PIPING DRAIN TEE RH               | UFM.BIF           |
| B6617001                    | FILTER, SCREEN CLIP                       | UFM               |
| B6620001                    | FILTER RACK                               | UFM               |
| B6621001                    | FILTER PAN, WELDMENT (SF50A)              | UFM               |
| B6621002                    | FILTER PAN, WELDMENT (SF65A)              | UFM               |
| B6621201                    | CRUMB CATCH                               | UFM               |
| B6621301                    | FILTER, COVER PAN, WELDMENT (SF50A)       | UFM               |
| B6621302                    | FILTER, COVER PAN, WELDMENT (SF65A)       | UFM               |
| B6621701                    | FILTER, TUBE SUCTION, COMPLETE            | UFM               |
| B6621901                    | DRAIN ELBOW, SHORT BIF                    | BIF               |
| B6621902                    | DRAIN ELBOW, LONG BIF                     | BIF               |
| B6622001                    | FILTER HOSE, UFM EXCEPT RPB               | UFM               |

| Pitco Frialator<br>Part No. | Part Description                             | Models<br>Used on |  |
|-----------------------------|--|-------------------|--|
| B6621902                    | DRAIN ELBOW, LONG BIF                        | BIF               |  |
| B6622001                    | FILTER HOSE, UFM EXCEPT RPB                  | UFM               |  |
| B6622002                    | FILTER HOSE, UFM FOR RPB                     | RPB               |  |
| B6622301                    | HOSE, QUICK DISCONNECT, COMPLETE - NON RPB   | UFM               |  |
| B6622801                    | FILTER RETURN INSULATION DISCONNECT ASSY, FM | UFM               |  |
| B6700601                    | T-STAT PROBE FOR GO, G5 & COMPUTER GAS       | ALL               |  |
| B6702601                    | T-STAT C5 POTENTIOMETER 0-475 OHM            | ALL               |  |
| B6779850                    | WIRE RADIX ASSEMBLY                          | ALL               |  |
| B7230201                    | HINGE DOOR TOP L.H. (AL/S)                   | ALL               |  |
| B7230202                    | HINGE DOOR TOP R.H. (AL/S)                   | ALL               |  |
| B7230301                    | HINGE DOOR BOTTOM L.H. (AL/S)                | ALL               |  |
| B7230302                    | HINGE DOOR BOTTOM R.H.(AL/S)                 | ALL               |  |
| B7370402                    | PROBE CLAMP & HIGH LIMIT                     | ALL               |  |
| B7402240                    | QUICK DISCONNECT, FEMALE WHITE RING          | BIF               |  |
| B7402241                    | QUICK DISCONNECT, FEMALE BLACK RING          | BIF               |  |
| B7404801                    | FILTER CRUMB SCOOP                           | ALL               |  |
| B7412602                    | ADAPTER, DRAIN VALVE END 7 UFM/BIF           | ALL               |  |
| B7425301                    | FISH GRID 13-1/4" X 13-1/4"                  | 14                |  |
| B7425401                    | FISH GRID 17-1/2 X 17-1/2"                   | 18                |  |
| B7490701                    | FRYER CRUMB SCOOP                            | ALL               |  |
| B7510003                    | CONVERSION KIT #7 TO NAT NON-EI              | ALL               |  |
| B7510004                    | CONVERSION KIT #7 TO LP NON-EI               | ALL               |  |
| B7510005                    | CONVERSION KIT #12 TO NAT NON-EI             | 12                |  |
| B7510006                    | CONVERSION KIT #12 TO LP NON-EI              | 12                |  |
| B7510007                    | CONVERSION KIT #14 TO NAT NON-EI             | ALL               |  |
| B7510008                    | CONVERSION KIT #14 TO LP NON-EI              | ALL               |  |
| B7510011                    | CONVERSION KIT #18 TO NAT NON-EI             | ALL               |  |
| B7510012                    | CONVERSION KIT #18 TO LP NON-EI              | ALL               |  |
| B7510041                    | CONVERSION KIT #14R TO NAT NON-EI            | ALL               |  |
| B7510042                    | CONVERSION KIT #14R TO LP NON-EI             | ALL               |  |
| B7510101                    | KNOB, EXTENSION UNITROL 12 COUNTER           | 12                |  |
| B7510102                    | KNOB, EXTENSION UNITROL 14B/14R              | 14R               |  |
| CALL                        |  |                   |  |
| FACTORY                     | TANK, WELDMENT, ALL                          | ALL               |  |
| CALL                        |  |                   |  |
| FACTORY                     | FRONT PANEL, WELDMENT                        | ALL               |  |
| P0048980                    | SCREWS/ROLLER GAS, REAR TYPE                 | ALL               |  |
| P0115000                    | BURNER BOLT                                  | ALL               |  |
| P5044850                    | COMPUTER MODULE 8 PROD 14/18-884 NAT         | 14,18             |  |
| P5044851                    | COMPUTER MODULE 1 PROD 14/18 184 NAT         | 14,18             |  |

| Pitco Frialator<br>Part No. | Part Description                          | Models<br>Used on |
|-----------------------------|---|-------------------|
| P5044855                    | COMPUTER MODULE 8 PROD 7-884 NAT          | 7                 |
| P5044856                    | COMPUTER MODULE 1 PROD 7-184 NAT          | 7                 |
| P5045002                    | UNITROL ACTUATOR 115 VAC                  | ALL               |
| P5045005                    | UNITROL ACTUATOR 24 VAC                   | ALL               |
| P5045040                    | LAMP RED RECT. 28V                        | ALL               |
| P5045042                    | LAMP GREEN RECT. 28V                      | ALL               |
| P5045043                    | LAMP, RECTANGULAR-CLEAR 24 VAC            | ALL               |
| P5045044                    | LAMP, RECTANGULAR-AMBER 24 VAC            | ALL               |
| P5045113                    | WIRE EI SENSING PROBE                     | ALL               |
| P5045410                    | PILOT W/HIGH VOLTAGE WIRE EI              | 14,18             |
| P5045638                    | UNITROL 1/2" BMSER, 24 VAC NAT            | 14,18             |
| P5045639                    | UNITROL 1/2" BMSER, 24 VAC LP             | 14,18             |
| P5045640                    | UNITROL 1/2" AMSER, 24 VAC NAT            | 7                 |
| P5045641                    | UNITROL 1/2" AMSER, 24 VAC LP             | 7                 |
| P5045642                    | UNITROL 1/2" BMSGOR, NAT                  | 14,18             |
| P5045644                    | UNITROL 1/2" BMSGOR, LP                   | 14,18             |
| P5045650                    | UNITROL 1/2" BMSER, 120 VAC NAT           | 14,18             |
| P5045652                    | UNITROL 1/2" BMSER, 120 VAC LP            | 14,18             |
| P5045656                    | UNITROL 1/2" AMSER, 120 VAC LP            | 7                 |
| P5045657                    | UNITROL 1/2" AMSER, 120 VAC NAT           | 7                 |
| P5045658                    | UNITROL 1/2" AMSGOR, LP                   | 7                 |
| P5045659                    | UNITROL 1/2" AMSGOR, NAT                  | 7                 |
| P5045700                    | FUSE, 2 AMP SLOW BLOW                     | ALL               |
| P5045717                    | FUSE, 2 AMP SLOW BLOW, GLASS              | ALL               |
| P5045720                    | FUSE, 4A SLOW BLOW GLASS                  | ALL               |
| P5045721                    | FUSE, 7A SLOW BLOW (GLASS)                | ALL               |
| P5045794                    | FUSE HOLDER                               | ALL               |
| P5046355                    | T-STAT G5 SOLID STATE MODULE              | ALL               |
| P5046356                    | T-STAT, GO SOLID STATE MODULE W/MELT      | ALL               |
| P5046380                    | MOTOR RIGHT REAR, MOUNT TYPE, BASKET LIFT | ALL               |
| P5046381                    | FILTER PUMP AND MOTOR ASSY 110V           | BIF               |
| P5046384                    | FILTER MOTOR ONLY, 110V                   | BIF               |
| P5046582                    | T-STAT POTENTIOMETER, GO 0-900 OHM        | ALL               |
| P5046626                    | PROBE ELECTRONIC IGNITION, FLAME SENSING  | ALL               |
| P5046686                    | RELAY, 24 VAC DPDT                        | ALL               |
| P5046688                    | RELAY, 24 VAC SPDT (MTG. TAB)             | ALL               |
| P5046690                    | RELAY, 24 VDC SPDT                        | ALL               |
| P5046980                    | HEATER STRIP, FILTER PAN - 500W           | BIF               |
| P5047169                    | SWITCH, ROLLER - SPDT (BASKET LIFT)       | ALL               |
| P5047217                    | FLOAT SWITCH, 24" WIRE                    | ALL               |

| Pitco Frialator<br>Part No. | Part Description                                | Models<br>Used on |
|-----------------------------|---|-------------------|
| P5047541                    | THERMOPILE CP2 24" NO El                        | ALL               |
| P5047561                    | TIMER, 15 MIN., 115V 60 HZ                      | ALL               |
| P5047564                    | TIMER MELT, SOLID STATE, 115 VAC                | ALL               |
| P5047587                    | THERMOSTAT, ELECTRIC SPST KX-299-36, COMP. B.U. | ALL               |
| P5047588                    | T-STAT G5-OIL THERMOSTAT                        | ALL               |
| P6071024                    | ROLLER GAS REAR LIFT TYPE, BASKET LIFT          | ALL               |
| P6071049                    | BURNER 4" WITHOUT PORTS                         | 7,14,18           |
| P6071050                    | BURNER 4"                                       | 7,14,18           |
| P6071051                    | BURNER 6"                                       | 14R.PR14,         |
|                             |   | PM14              |
| P6071062                    | CASTER (4/FILTER)                               | UFM,BIF           |
| P6071123                    | QUICK DISCONNECT, MALE                          | BIF               |
| P6071190                    | HANDLE, NOZZLE (BLACK)                          | ALL               |
| P6071253                    | QUICK DISCONNECT RING ONLY, WHITE               | BIF               |
| P6071254                    | QUICK DISCONNECT RING ONLY, BLACK               | BIF               |
| P6071267                    | UNITROL KNOB                                    | ALL               |
| P6071270                    | THERMOSTAT KNOB GO & G5                         | ALL               |
| P6071279                    | TIMER KNOBS, ALL                                | ALL               |
| P6071280                    | TIMER KNOB BUTTON, ALL                          | ALL               |
| P6071300                    | CATCH MAGNET STANDARD                           | ALL               |
| P6071300                    | MAGNET, DOOR                                    | ALL               |
| P6071331                    | ORIFICE, PILOT, ELECTRONIC IGNITION, NAT        | ALL               |
| P6071332                    | ORIFICE, PILOT, ELECTRONIC IGNITION, LP GAS     | ALL               |
| P6071371                    | PAPER 13-1/2" X 24" PITCO #14 BIF/PORTABLE      | 14                |
| P6071373                    | PAPER 17-1/2" X 28" PITCO #18-34 BIF/PORTABLE   | 18-34             |
| P6071397                    | CLEANER FRYER, 25 LB.                           | ALL               |
| P6071448                    | PLUG, HOLE 2"                                   | ALL               |
| P6071449                    | BURNER, PILOT 6CH-14-6, LP GAS                  | ALL               |
| P6071450                    | BURNER, PILOT 6CH-14-6, NATURAL GAS             | ALL               |
| P6071467                    | PLUG, HOLE 3/4" PLATED                          | UFM               |
| P6071490                    | PLUG, HOLE 7/8"                                 | ALL               |
| P6071505                    | T-STAT DIAL LOCK                                | ALL               |
| P6071516                    | HANDLE, DOOR, CHROME 3" CTOC                    | ALL               |
| P6071530                    | FILTER PUMP ONLY 110V (NON-UFM)                 | BIF               |
| P6071530                    | PUMP ONLY, NON-UFM                              | BIF               |
| P6071551                    | UNITROL PRESS/REGULATOR NAT ONLY                | ALL               |
| P6071553                    | UNITROL PRESS/REGULATOR LP ONLY                 | ALL               |
| P6071710                    | TIMER, MECHANICAL(15 MIN.)                      | ALL               |
| P6071767                    | VALVE GAS, MANUAL SHUT-OFF EI                   | ALL               |
| P6071769                    | VALVE 1" UNPLATED, DRAIN                        | 12                |


| Pitco Frialator<br>Part No. | Part Description                                  | Models<br>Used on |
|-----------------------------|---|-------------------|
| P6071776                    | VALVE EI GAS NAT W/IGN G600 & G600                | ALL               |
| P6071777                    | VALVE EI GAS LP W/IGN G60 & G600                  | ALL               |
| P6071780                    | VALVE, BALL 3/8" PLTD W/0 HANDLE                  | ALL               |
| P6071785                    | VALVE, BALL 1 1/4"                                | ALL               |
| P6072108                    | TUBE SCREEN 13-1/2" X 7-1/2"                      | 7                 |
| P6072123                    | BASKET, SQUARE 11-1/2" X 11-1/2" X 4-1/4",        |                   |
|                             | LONG HANDLE, REGULAR MESH                         | 12                |
| P6072124                    | BASKET, SQUARE 11-1/2" X 11-1/2" X 4-1/4",        |                   |
|                             | LONG HANDLE, FINE MESH                            | 12                |
| P6072125                    | BASKET, OBLONG 11-1/2" X 5-1/2" X 4-1/4",         |                   |
|                             | LONG HANDLE, REGULAR MESH                         | 12                |
| P6072126                    | BASKET, OBLONG 11-1/2" X 5-1/2" X 4-1/4",         |                   |
|                             | LONG HANDLE, FINE MESH                            | 12                |
| P6072128                    | TUBE RACK 11-1/2" X 11-1/2"                       | 12                |
| P6072143                    | BASKET, SQUARE 13-1/2" X 13-1/2" X 5-1/2" DEEP,   |                   |
|                             | LONG HANDLE, REGULAR MESH                         | 14                |
| P6072144                    | BASKET, SQUARE 13-1/2" X 13-1/2" X 5-1/2" DEEP,   |                   |
|                             | LONG HANDLE, FINE MESH                            | 14                |
| P6072145                    | BASKET, OBLG 13-1/2" X 6-1/2" X 5-1/2" DEEP, LONG |                   |
|                             | HANDLE, REGULAR MESH                              | 7,14              |
| P6072146                    | BASKET, OBLG 13-1/2" X 6-1/2" X 5-1/2" DEEP, LONG | ,                 |
|                             | HANDLE, FINE MESH                                 | 7,14              |
| P6072147                    | BASKET, OBLG 13-1/2" X 4-1/2" X 5-1/2" DEEP, LONG | ŕ                 |
|                             | HANDLE, REGULAR MESH, 3 PER FRYER                 | 14                |
| P6072148                    | TUBE SCREEN (MESH) 14 14R                         | 14                |
| P6072155                    | SCREEN BREAD & BATTER PAN #14 GAS & ELEC          | BIF               |
| P6072155                    | DRAIN SCREEN #14                                  | BIF               |
| P6072156                    | SCREEN BREAD & BATTER PAN #18 GAS & ELEC          | BIF               |
| P6072156                    | DRAIN SCREEN #18                                  | BIF               |
| P6072165                    | CRUMB CATCH BASKET                                | BIF               |
| P6072180                    | BASKET SQ SIDE HANDLES, REGULAR MESH, #18         | 18                |
| P6072181                    | BASKET SQ FRONT HANDLES, REGULAR MESH, #18 18     |                   |
| P6072184                    | BASKET OBL TWIN, REGULAR MESH, #18                | 18                |
| P6072185                    | BASKET OBLG LONG HANDLE #18, REGULAR MESH,        |                   |
| -                           | 3-PER FRYER                                       | 18                |
| P6072186                    | TUBE SCREEN (MESH) #18                            | 18                |
| P6072187                    | BASKET SQ, SIDE HANDLES #18                       | 18                |
| P6072188                    | BASKET OBLG TWIN , FINE MESH, #18                 | 18                |
| P6072611                    | PAPER SUPPORT RACK 14 PITCO                       | 14                |
| P6072612                    | PAPER SUPPORT RACK 18-34 PITCO                    | 18                |

| Pitco Frialator | Part Description                                    | Models  |
|-----------------|---|---------|
| Part No.        |   | Used on |
| P6073128        | TUBE RACK 11-1/2" X 11-1/2"                         | 12      |
| P6073148        | TUBE RACK #14                                       | 14      |
| P6073186        | TUBE RACK #18                                       | 18      |
| P7038080        | FLOAT RETAINER CLIP                                 | ALL     |
| PP10029         | LABEL, RED RETURN VALVE                             | ALL     |
| PP10030         | LABEL, BLUE FLUSH DRAIN VALVE                       | ALL     |
| PP10031         | LABEL, GREEN DRAIN VALVE                            | ALL     |
| PP10032         | GASKET, DRAIN LINE (SLEEVE)                         | ALL     |
| PP10034         | CLAMP, BAND (FILTER)                                | ALL     |
| PP10039         | HEAT TAPE, 1/2" X 79", 110V, 165 WATT (SF50A/SF65A) | UFM     |
| PP10045         | SEAL DRAIN ELBOW ROUND                              | ALL     |
| PP10048         | HANDLE, VALVE 3/8 BALL, COATED RED                  | ALL     |
| PP10049         | HANDLE, VALVE 3/8 BALL, COATED BLUE                 | ALL     |
| PP10050         | HANDLE, VALVE 3/8 BALL, COATED YELLOW               | ALL     |
| PP10056         | BRUSH FRYER CLEANING                                | ALL     |
| PP10070         | IGNITION CONTROL, G77-MGC LP                        | ALL     |
| PP10071         | IGNITION CONTROL, G77-MGA NAT                       | ALL     |
| PP10082         | LAMP, 125 VAC AMBER RECTANGULAR                     | ALL     |
| PP10083         | LAMP, 125 VAC WHITE RECTANGULAR                     | ALL     |
| PP10084         | SWITCH, HI-LIMIT LCHM 05030                         | ALL     |
| PP10094         | SWITCH, ROCKER, DPDT W/BK (ON/OFF/MON ON)           | ALL     |
| PP10095         | TIMER 15 MIN., 240V 50 HZ                           | ALL     |
| PP10097         | SWITCH, DPDT ON-OFF-ON - MINI                       | ALL     |
| PP10098         | SWITCH, ROCKER, DPDT (ON-OFF-ON)                    | ALL     |
| PP10100         | LAMP, 250 VAC - AMBER                               | UFM     |
| PP10101         | PUMP & MOTOR ASSEMBLY, 115/230 VAC, 60HZ, 1/3 HP    | UFM     |
| PP10103         | RECEPTACLE, 3 PRONG, 15A, 125VAC                    | ALL     |
| PP10104         | CIRCUIT BREAKER                                     | ALL     |
| PP10106         | FITTING, ELBOW MALE 90 .50D X .5NPT                 | ALL     |
| PP10107         | BUSHING, STRAIN RELIEF                              | UFM     |
| PP10111         | 0-RING, VITON .50ID X .688 X .094W                  | UFM     |
| PP10119         | LABEL, WARNING-MOTOR RESET                          | UFM     |
| PP10122         | FUSE, 1 AMP SLOW BLOW GLASS                         | ALL     |
| PP10147         | CLIP CABLE .375ID                                   | UFM     |
| PP10171         | PUMP & MOTOR ASSEMBLY, 250 VAC, 50 HZ 1/3 HP        | UFM     |
| PP10192         | BUSHING, STRAIN RELIEF 90 UFM                       |         |
| PP10200         | CABLE, CONTROL-7C 16AWG 150°C                       | UFM     |
| PP10210         | TRANSFORMER 120/208/240 TO 24V 40 VA                | ALL     |
| PP10211         | TRANSFORMER 208-240 TO 120 VAC 56 VA                | ALL     |
| PP10232         | MECH. TIMER DPDT W/OFF POSITION                     | ALL     |


| Pitco Frialator<br>Part No. | Part Description                             | Models<br>Used on |
|-----------------------------|--|-------------------|
| PP10262                     | SWITCH, PROXIMITY SENSOR                     | ALL               |
| PP10263                     | SWITCH, PROXIMITY ACTUATOR                   | ALL               |
| PP10280                     | BURNER, PILOT WITH HIGH VOLTAGE UFM          | ALL               |
| PP10331                     | LAMP, 125V GREEN RECT W/S                    | UFM               |
| PP10398                     | COMPUTER MODULE 1 PROD 7-184 LP              | 7                 |
| PP10399                     | COMPUTER MODULE 8 PROD 7-884 LP              | 7                 |
| PP10400                     | COMPUTER MODULE 1 PROD 14/18-184 LP          | ALL               |
| PP10401                     | COMPUTER MODULE 8 PROD 14/18-884 LP          | ALL               |
| PP10416                     | FILTER MOTOR ONLY, 115V, SF50/65             | UFM               |
| PP10417                     | FILTER PUMP ONLY, SF50/65                    | UFM               |
| PP10439                     | CORD PLUG MOLDED 16-3 SJO                    | ALL               |
| PP10452                     | CORD, POWER SUPPLY - 14 AWG                  | ALL               |
| PP10460                     | SWITCH ROCKER, CKT BKR, 8 AMP, SPST 115 VAC  | UFM               |
| PP10470                     | SWITCH ROCKER, CKT BKR, 4 AMP, DPST 240VAC   | UFM               |
| PP10537                     | KNOB, 200-400 GAS, GS OIL                    | ALL               |
| PP10539                     | KNOB, 200-400 OFF ELECTRIC                   | ALL               |
| PP10540                     | T-STAT G0 SOLID STATE MODULE W/MELT LP       | ALL               |
| PP10561                     | T-STAT, SOLID STATE TEMPER CONTROL MODULE G0 |                   |
|                             | 24 VAC LP                                    | ALL               |
| PP10562                     | T-STAT, SOLID STATE CONTROL MODULE G0 24 VAC |                   |
|                             | ON-4S OFF-26S                                | ALL               |
| PP10593                     | GAS VALVE, 24V EI (NAT)                      | ALL               |
| PP10594                     | GAS VALVE, 24V El (LP)                       | ALL               |
| PP10609                     | CORD, PLUG MOLDED 16-3 NEMA 5-15P            | UFM               |
| PP10613                     | PAPER 18 X 20-1/2 UFM 14 & 18                | 14,18             |
| PP10733                     | FILTER POWDER 120 PACKETS, 80Z               | ALL               |
| PP10739                     | THERMOSTAT, SNAP DISC                        | UFM               |
| PP10741                     | FILTER, QD SNP 23 NIPPLE                     | UFM               |
| PP10809                     | CASTER ASSEMBLY ADJUSTABLE 6" W/LOCK         | ALL               |
| PP10808                     | CASTER ASSEMBLY ADJ 6" W/OUT LOCK            | ALL               |
| PP10810                     | CASTER ASSEMBLY 7" WITHOUT LOCKING DEVICE    | UFM               |
| PP10811                     | CASTER ASSEMBLY 7" WITH LOCKING DEVICE       | UFM               |


# **Chapter 6: Schematics**


| Schematic Description  | Schematic<br>Number |
|--|---------------------|
| SCHEMATIC, FILTER - SF50A, SF65A 115 VAC                       | 700141              |
| SCHEMATIC, GBB SYSTEM - BETTER AND BEST MODELS                 | 700142              |
| SCHEMATIC, FILTER - SF50A, SF65A 220 VAC                       | 700144              |
| SCHEMATIC, FILTER - SF50A, SF65A 240 VAC                       | 700145              |
| SCHEMATIC, SCHEMATIC, FILTER, 115 VAC, 60 HZ OPTION W/0 HEATER | 700150              |
| SCHEMATIC, SCHEMATIC, FILTER, 115 VAC, 60 HZ OPTION W/ HEATER  | 700151              |
| SCHEMATIC, FILTER MOBILE 120VAC W/0 HEATER                     | 700156              |
| SCHEMATIC, FILTER MOBILE 240V W/0 HEATER                       | 700157              |
| SCHEMATIC, FILTER MOBILE 120V W/HEATER                         | 700158              |
| SCHEMATIC, FILTER MOBILE 240V W/HEATERS                        | 700159              |
| SCHEMATIC, SCHEMATIC, BFRPB14, 115 VAC, 50/60 HZ W/ HEATER     | 700164              |
| SCHEMATIC, BFRPB14,115/230 VAC, 50/60HZ, W/HEATER              | 700172              |



|              | PARTS LIST |  |     |  |
|--------------|------------|--|-----|--|
| NOMENCLATURE | PART NO.   | DESCRIPTION                                      | QTY |  |
| CB1          | PP10460    | CIRCUIT BREAKER, 8 AMP-SINGLE POLE               | 1   |  |
| DS1          | PP10331    | LAMP, 125 VAC-GREEN                              | 1   |  |
| HR1          | PP10039    | HEAT TAPE - 110 VAC, 165 W                       | 1   |  |
| M1           | PP10101    | PUMP/MOTOR ASSY, 115/230 VAC 1/3 HP              | 1   |  |
| J1           | PP10089    | CONNECTOR, JACK-3 SKT MOLEX                      | 1   |  |
| P1           | PP10090    | CONNECTOR, PLUG-3 PIN MOLEX                      | 1   |  |
| P17          | PP10609    | CORD, PLUG MOLDED 16-3 NEMA 5-15P 17.5' (SF50A)  | 1   |  |
| 1 17         | PP10711    | CORD, PLUG MOLDED 16-3 NEMA 5-15P 23. 5' (SF65A) | ] ' |  |
| S1           | PP10735    | SWITCH. ROCKER-DPST CON-OFF)                     | 1   |  |
| S2           | PP10739    | SWITCH, THERMAL 135°F OPEN 105°F CLOSE           | 1   |  |










#### NOTES.


- 1. A CONTINUOUS GREY WIRE IS CONNECTED BETWEEN P7 POSITIONS 1 AND 2 WHEN NEITHER THE FLOAT SWITCH S8 NOR THE DRAIN SWITCH S8 IS AN OPTION
- AT FUSES F1 AND F2 USE FUSE HOLDER (P5045794).
- CONNECT HI-LIMIT S12 -TC VALVE VI WITH WIRE ASSEMBLY (P5047625)
- 4. UNLESS OTHERWISE SPECIFIED ALL WIRES ARE 18 AW6
- DESIGNATION OF RIGHT ANO LEFT BASKETLIFT MOTOR AS VIEWED FRCH FRONT OF FRYER
- 6. 220 VAC UNITS ARE WIRED IDENTICALLY TO 240 VAC UNITS
- 220, 240 VAC MODELS ONLY, P15 IS OMITTED. P1 IS WIRED TO 10 FT Of 14-3 POWER SUPPLY CORD (PP10515) - BROWN TC P1-3. BLUE TC P1-2, GREEN/YELLOW TO P1-1.
- 8. A CONTINUOUS GREY WIRE IS CONNECTED BETWEEN P10 POSITION 5 AND K5 WHEN THE BLANCH SWITCH S7 IS NOT AN OPTION.
- 9. 120 VAC MODELS. CONNECT BLACK LEAD TO PIN 3 ON T1 AND T2 220, 240 VAC MODELS. CONNECT BLACK LEAD TO PIN 1 ON T1 AND T2
- IF "NO BACK-UP THERHOSTAT" OPTION IS SPECIFIED, OMIT S2 AND YELLOW WIRE FROM S2 TO P14-6. TAPE OFF REMAINING LEAD TO S1 AND P14-3.
- CONNECT ELECTRONIC IGNITION (A2) TO FLAME SENSOR (E1) WITH WIRE ASSEMBLY (P5045113)
- 12. FOR MODEL 7, OMIT S5. M1. AND TM2 OR K4.







| PSO45638   VALVE, 3AS 1/2 BMSER 24V TPILE NAT  |                   |           |  |
|--|-------------------|-----------|--|
| P5045639 VALVE, SAS 1/2 BOER 24V TPILE LP PP10581 VALVE, SAS 1/2 BOER 24V EL NAT PP10581 VALVE, SAS 1/2 BOER 24V EL NAT PP10581 VALVE, SAS 1/2 BOER 24V EL NAT EL P5046826 SENSCR, FLAME PROBE E2 PP10280 PILLOT, ELECTRONIC IGNITION A3 PP10561 CONTROLLER, SO - 24 VAC ON-85 OFF-22S PP10400 PILLOT, ELECTRONIC IGNITION, 24 VAC 677 PP10399 CMPTR, PITCONATIC 184-7 ON-85 OFF-22S PP10400 CMPTR, PITCONATIC 184-7 ON-85 OFF-22S PP10400 CMPTR, PITCONATIC 184-11 ON-85 OFF-22S PP10400 CMPTR, PITCONATIC 184-11 ON-85 OFF-22S PP10400 CMPTR, PITCONATIC 184-11 ON-85 OFF-22S PP10401 CMPTR, PITCONATIC 184-11 ON-85 OFF-22S PP10402 BACKLORY SAY LH - 120 VAC B5500802 BA/L, MOTOR ASSY LH - 240 VAC B5500802 BA/L, MOTOR ASSY LH - 120 VAC B5500802 BA/L,  |                   | P5045638  | VALVE, GAS 1/2 SMSEP 24V TPILE NAT     |
| PRIOSS3   VALVE, SAS 1/2 80ER 24V EL NAT   PPO19594   VALVE, SAS 1/2 80ER 24V EL LP   PPO19596   PRIOSS94   VALVE, SAS 1/2 80ER 24V EL LP   PPO19596   PRIOSS96   P   | ٧١                |           |  |
| PP10594   VALVE, GAS 1/2 BDER 24V EL LP  |                   | PP10593   | VALVE, GAS 1/2 BOER 24V EL NAT         |
| E1 P5046526 SEMSCR, FLAME PROBE E2 PP10280 PILOT, ELECTRONIC IGNITION A3 PP10561 CONTROLLER, 60 - 24 VAC ON-85 OFF-225 A2 PP10071 ELECTRONIC IGNITION, 24 VAC 677 PP10398 CMPTR, PITCONATIC 184-17 ON-85 OFF-225 PP10399 CMPTR, PITCONATIC 184-17 ON-85 OFF-225 PP10400 CMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP10401 CMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP10401 CMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP10401 MOTOR, SEAR-240VAC 50 HZ (B/L) PP10396 MOTOR, SEAR-240VAC 50 HZ (B/L) PP10396 MOTOR, SEAR-240VAC 50 HZ (B/L) PP10401 B/L, MOTOR ASSY LH - 240 VAC RT1 P5044876 PP0686, THEMISTOR-100K RT1 P5044876 PP0686, THEMISTOR-100K RT1 P5045041 LAMP, P6CTAMBULAR - JLEAR 24 VAC DS1 P5045041 LAMP, P6CTAMBULAR - JLEAR 24 VAC DS1 P5045041 LAMP, P6CTAMBULAR - JHBER 24 VAC PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 240 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 240 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PP10395 SHITCH, ROLLER-SPOT (MASKETLIFT) P5047152 SHITCH, TOGELE-SPST (MASKETLIFT) P5047152 SHITCH, TOGELE-SPST (MASKETLIFT) PP10395 SHITCH, ROCKER-DP0T W/BK (0-1-(1)) P6 PP10390 SHITCH, ROCKER-DP0T W/BK (0-1-(1)) P6 PP10390 SHITCH, ROCKER-DP0T W/BK (0-1-(1)) P6 PP10390 COMMECTOR, PLUG-3 PIN MOLEX P1,P11,P15 PP10390 COMMECTOR, PLUG-3 PIN MOLEX P1,P11,P15 PP10390 COMMECTOR, PLUG-3 PIN MOLEX P1,P13 PP10395 COMMECTOR, PLUG-3 SKT MOLEX P1,P13 PP10395 COMMECTOR, JACK-2 SKT MOLEX P1,P13 PP10398 COMMECTOR, JACK-2 SKT MOLEX P1,P10475 RECEPTACLE, NEWA S-1SR (120V) PP10476 RECEPTACLE, NEWA S-1SR (120V) PP10477 RECEPTACLE, NEWA S-1SR (120V) PP10478 RECEPTACLE, NEWA S-1SR (120V) PP1047   | ٧2                |           |  |
| E2 PP10280 PILOT, ELECTRONIC IGNITION A3 PP10561 CHITROLLER, SO - Z4 VAC GH-85 OFF-225 A2 PP10371 CHITROLLER, SO - Z4 VAC GH-85 OFF-225 PP10398 CHPTR, PITCONATIC 184-T7 ON-85 OFF-225 PP10400 CHPTR, PITCONATIC 184-T7 ON-85 OFF-225 PP10400 CHPTR, PITCONATIC 184-T7 ON-85 OFF-225 PP10400 CHPTR, PITCONATIC 184-T1 ON-85 OFF-225 PP10401 CHPTR, PITCONATIC 184-T1 ON-85 OFF-225 PP10401 CHPTR, PITCONATIC 184-T1 ON-85 OFF-225 PP10402 CHPTR, PITCONATIC 184-T1 ON-85 OFF-225 PP10403 HOTOR, SEAR-120VAC 50 HZ (B/L) PP10398 HOTOR, SEAR-240VAC 50 HZ (B/L)  A2 85600801 B/L, MOTOR ASSY LH - 120 VAC B5500802 B/L, MOTOR ASSY LH - 240 VAC B5500801 B/L, MOTOR ASSY LH B - 240 VAC B51 P5047561 TIHER, 120 VAC 50 HZ 15 HIN (B/L) PF04751 SHITCH, HOLLER-SPOT (BASKELL)FIT B504751 SHITCH, HOLLER-SPOT (BASKELL)FIT B504751 SHITCH, HOLLER-SPOT (BASKELL)FIT B51 PP10593 SHITCH, HOLLER-SPOT (BASKELL)FIT B52 PF047587 SHITCH, TOKALE-SPOT (BASKELL)FIT B73 PP10693 SHITCH, HOLLER-SPOT (BASKELL)FIT B74 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B75 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B75 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B76 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B77 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B77 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B78 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B79 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B71 PP10759 SHITCH, HOLLER-SPOT (BASKELL)FIT B72 PP10759 CONNECTOR, PLUG-9 PIN HOLLEX B73 PP10759 CONNECTOR, JACK-9 SKT HOLLEX B74 PP10759 CONNECTOR, JACK-9  | £1                |           |  |
| ## A3  |                   |           |  |
| A2 PP10371 ELECTRONIC ISHITION, 24 VAC G77 PP10398 CMPTR, PITCONATIC 184-7 ON-85 OFF-225 PP10409 CMPTR, PITCONATIC 184-7 ON-85 OFF-225 PP10400 CMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP10400 IMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP1046380 IMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP1046380 IMPTR, PITCONATIC 184-14 ON-85 OFF-225 PP10465 IMPTR PITCONATIC 184-14 ON-85 OFF-225 PP10450 IMPTR PITCONATIC 184-14 ON-85 OFF-225 PP1045041 IMPTR PITCONATIC 184-14 ON-85 OFF-225 PP1045041 IMPTR PITCONATIC 184-14 ON-85 OFF-225 PP1045041 IMPTR PITCONATION IMPT PI   |                   |           |  |
| PP10398   CMPTR, PITCONATIC 184-7 ON-85 OFF-225  |                   |           |  |
| ## PP10399 CMPTR, PITCONATIC 884-7 CN-85 OFF-225 ## PP10400 CMPTR, PITCONATIC 184-14 CN-85 OFF-225 ## PP10401 CMPTR, PITCONATIC 184-14 CN-85 OFF-225 ## PP10401 CMPTR, PITCONATIC 884-14 CN-85 OFF-225 ## PP10396 MOTOR, SEAR-120VAC 60 MZ (8/L) ## PP10396 MOTOR, SEAR-240VAC 50 MZ (8/L) ## PP10396 MOTOR, SEAR-240VAC 50 MZ (8/L) ## PP10396 MOTOR, SEAR-240VAC 50 MZ (8/L) ## PP10396 BOTOR, SEAR-240VAC 50 MZ (8/L) ## PP10397 BP10397 BP   | - ^4              | 2010071   | CLECTRUMIC SMITTUM, 24 VAC 677         |
| PP10400   CMPTR, PITCOMATIC 184-14 CM-85 CFF-225   |                   |           |  |
| PP10401   CMPTP, PITCONATIC 884-14 ON-85 OFF-225   P504539   MOTOR, SEAR-129VAC 50 HZ (B/L)   P504539   MOTOR, SEAR-129VAC 50 HZ (B/L)   85600801   B/L, MOTOR ASSY LH - 120 VAC   85600802   B/L, MOTOR ASSY LH - 240 VAC   9500000000000000000000000000000000000   | A1                | PP10399   | CHPIR, PITCURATIC 884-7 CN-85 UFF-225  |
| P5046380   MOTOR, SEAR-120VAC 50   HZ (B/L)  |                   | PP10400   | CMPTR, PITCCHATIC 184-14 CN-85 CFF-225 |
| PP10096   HOTOR, SEAR-240VAC 50 HZ (B/L)   |                   | PP10401   | CHPTP, PITCOMATIC 884-14 CN-85 CFF-225 |
| PP10096   HOTOR, SEAR-240VAC 50 HZ (B/L)     25600802   B/L, MOTOR ASSY LH - 120 VAC     85600802   B/L, MOTOR ASSY LH - 120 VAC     811, 12   PP10210   TRANSFORMER, 40VA-120/208/240V TC 24V     95049613   LAMP, 9ECTANGULAR - LEAR 24 VAC     95045044   LAMP, 9ECTANGULAR - LEAR 24 VAC     PP10095   TIMER, 240 VAC 50 HZ 15 HIM (B/L)     PP10095   TIMER, 120 VAC 50 HZ 15 HIM (B/L)     PP10095   TIMER, 120 VAC 50 HZ 15 HIM (B/L)     PP10095   SHITCH, HIGH TEMPERATURE LIHIT     S5,56   PP047189   SMITCH, HIGH TEMPERATURE LIHIT     S5,56   PP047189   SMITCH, ROLLER-SPOT (BASKETLIFT)     S6   PP10262   SMITCH, PROXINITY SEMSOR (DVI ON. ")     S7   PP047152   SMITCH, TOGALE-SPST (BLANCH CPTION)     S4   PP047217   SMITCH, TIGGLE-SPST (BLANCH CPTION)     S4   PP047217   SMITCH, TIGGLE-SPST (BLANCH CPTION)     S5   PP047217   SMITCH, TIGGLE-SPST (BLANCH CPTION)     S6   PP10093   SMITCH, ROCKER-SPOT (W-ON-ON)     S7   PP047157   SMITCH, TIGGLE-SPST (BLANCH CPTION)     S6   PP10093   SMITCH, ROCKER-SPOT (W-ON-ON)     P1   PP10093   SMITCH, ROCKER-SPOT (W-ON-ON)     P1   PP10095   SMITCH, ROCKER-SPOT (W-ON-ON)     P1   PP10275   SMITCH, TISTAT ELECTRIC (ALTERNATE)     PP10275   SMITCH, TISTAT ELECTRIC (ALTERNATE)     PP10275   SMITCH, TISTAT ELECTRIC (ALTERNATE)     P1   PP10295   CONNECTOR, PLUG-3 PIN MOLEX     P1   P10204   CONNECTOR, PLUG-3 PIN MOLEX     P1   P104058   CONNECTOR, PLUG-3 PIN MOLEX     P1   P104059   CONNECTOR, PLUG-3 PIN MOLEX     P1   P104059   CONNECTOR, PLUG-6 PIN MOLEX     P1   P104059   CONNECTOR, PLUG-6 PIN MOLEX     P1   P104059   CONNECTOR, PLUG-6 PIN MOLEX     P1   P104059   CONNECTOR, JACK-3 SKT MOLEX     P1   P10475   CONNECTOR, JACK-3 SKT MOLEX     P10475   CONNECTOR, JACK-3 SKT MOLEX     P10475   CONNECTOR, JACK-3 SKT MOLEX     P10476   CONNECTOR,  | M1                |           |  |
| ## ## ## ## ## ## ## ## ## ## ## ## ##   |                   |           |  |
| S500902   B/L, MOTOP ASSY LH - 240 VAC   | -                 | 35600801  | B/L, MCTCR ASSY LH - 120 VAC           |
| 11. 72 P910210   TRANSFORMER, 40VA-120/208/240V TC 24V   | 112               | 85500802  | 8/L, MOTOR ASSY LH - 240 VAC           |
| 11. 72 P910210   TRANSFORMER, 40VA-120/208/240V TC 24V   | RT1               | P5044876  | PROBE, THERMISTOR-100K                 |
| DS1  | 11, 12            |           |  |
| DS2  |                   |           |  |
| TH2, TH3  P5047561 TIMER, 120 VAC 50 HZ 15 HIN (B/L)  PP10095 TIMER, 240 VAC 50 HZ 15 HIN (B/L)  PP10095 SHITCH, P40 VAC 50 HZ 15 HIN (B/L)  S5,56 P5047163 SHITCH, RQLER-SPOT (BASKETLIFT)  S8 P910762 SHITCH, RQLER-SPOT (BASKETLIFT)  S7 P5047162 SHITCH, PGCKIRITY SENSOR (DVI CRL*)  S1 P5047162 SHITCH, TOEGLE-SPST (BLANCH OPTION)  S1 P504757 SHITCH, FLGAT (OPTIONAL)  S2 P5047587 SHITCH, FLGAT (OPTIONAL)  S1 P91053 SHITCH, ROCKER-SPOT (CALTERNATE)  S1 P91053 SHITCH, ROCKER-SPOT (CALTERNATE)  P5 P91053 SHITCH, ROCKER-OPOT W/BK (O-1-(1))  P6 P9052 CONNECTOR, PLUG-9 PIN HOLEX  P1, P1, P16 P910090 CONNECTOR, PLUG-9 PIN HOLEX  P1, P1, P16 P910090 CONNECTOR, PLUG-9 PIN HOLEX  P1, P1, P16 P910090 CONNECTOR, PLUG-9 PIN HOLEX  P1, P7, P36 P5045829 CONNECTOR, PLUG-9 PIN HOLEX  P3, P8, P41 P910206 CONNECTOR, PLUG-9 PIN HOLEX  P3, P8, P41 P910206 CONNECTOR, PLUG-9 PIN HOLEX  P1, P1, P13 P91039 CONNECTOR, PLUG-9 PIN HOLEX  P15 P91039 CONNECTOR, PLUG-9 PIN HOLEX  P17 P10475 P10475 CONNECTOR, JACK-9 SKT HOLEX  J17 P10475 CONNECTOR, JACK-9 SKT HOLEX  J17 P910475 RECEPTACLE, NEWA G-15R (120V)  P910475 RECEPTACLE, NEWA G-15R (120V)  P910475 P10475 FCEPTACLE, NEWA G-15R (120V)  P910475 P10475 FCEPTACLE, NEWA G-15R (120V)  P910475 FCEPTACLE, NEWA G-15R (120V)  P910476 FCEPTACLE, NEWA G-15R (120V)  P910477 FCEPTACLE, NEWA G-15R (120V)  P910477 FCEPTACLE, NEWA G-15R (120V)  P910477 FCEPTACLE,   |                   |           | LAMP, RECTANGULAR - AMBER 24 VAC       |
| S12  |                   |           |  |
| S12  | TH2, TH3          | PP10095   | TIMER 240 VAC 50 HZ 15 MIN (8/1)       |
| SS,56  | \$12              | 2010004   | SWITCH HIGH TEMPERATURE ! INIT         |
| Second Color   Seco   |                   | 95047150  | ISUITCH DOLLED-SOUT (BASKET) 1571      |
| P5047162 SMITCH, TOGGLE-SPST (BLANCH CPTION)   |                   | 991 0707  | EUTTON MOCKETTY CENSOR (DUT ON A)      |
| P5047217 SHITCH, FLGAT (QPTIGNAL)   S3   |                   |           |  |
| \$3 PP10093 SHITCH, ACCKER - SPOT (CN-ON)  \$2 PS04787 SHITCH, T-STAT ELECTRIC (ALTERNATE)  \$1 PP10559 SHITCH, RCCKER-OPDT W/8K (0-1-(1))  \$5 PP10202 COMMECTER, PLU6-4 PIN HOLEX  \$14 P5045860 COMMECTOR, PLU6-3 PIN HOLEX  \$19,19,16 PP10090 COMMECTOR, PLU6-3 PIN HOLEX  \$1,11,19,16 PP10090 COMMECTOR, PLU6-3 PIN HOLEX  \$2,79,8,14 PP10208 COMMECTOR, PLU6-3 PIN HOLEX  \$2,79,8,14 PP10208 COMMECTOR, PLU6-12 PIN HOLEX  \$2,79,8,14 PP10209 COMMECTOR, PLU6-12 PIN HOLEX  \$2,79,77 PP10439 COM, PLU6-HOLD 14-3 NEMA S-1SP  \$2,79,79 PP10449 COMMECTOR, PLU6-6 PIN HOLEX  \$2,70,77 PP10204 COMMECTOR, PLU6-6 PIN HOLEX  \$3,48 PS045850 RELAY, 24V0C - SPOT  \$4,77,36 PS045850 POTENTIONETER, SOOD  \$1,2,1,1,19 PP10208 COMMECTOR, JACK-3 SKT HOLEX  \$3,20,177 PP10208 COMMECTOR, JACK-9 SKT HOLEX  \$3,18,341 PP10208 COMMECTOR, JACK-2 SKT HOLEX  \$3,18,341 PP10208 COMMECTOR, JACK-2 SKT HOLEX  \$3,18,341 PP10208 COMMECTOR, JACK-2 SKT HOLEX  \$4,77,356 PS045839 COMMECTOR, JACK-2 SKT HOLEX  \$3,18,341 PP10208 COMMECTOR, JACK-2 SKT HOLEX  \$4,77,36 PS045839 COMMECTOR, JACK-2 SKT HOLEX  \$5,70 PS045830 COMMECTOR, JACK-2 SKT HOLEX  \$6,70 PS045830 COMMECTOR, JACK-2 SKT HOLEX  \$6,70 PS045830 COMMECTOR, JACK-2 SKT HOLEX  \$7,80 PS045830 COMMECTOR, JACK-2 SKT HOLEX  \$7,90 PS045830 COMMECTOR, JACK-2 |                   |           |  |
| PS047587 SWITCH, T-STAT ELECTRIC (ALTERNATE)   |                   | P5047217  | ISHTICH, FEGAT (OPTIONAL)              |
| S1   |                   | PP10093   | SWITCH, RCCKER - SPUT (CN-CN)          |
| P6 PP10202 CONNECTOR, PLUE-4 P1N HOLEX P14 P5045860 CONNECTOR, PLUE-9 P1N HOLEX P1,P11,P15 PP10000 CONNECTOR, PLUE-9 P1N HOLEX P10 P5045826 CONNECTOR, PLUE-9 P1N HOLEX P11 PP10205 CONNECTOR, PLUE-9 P1N HOLEX P12,P13 PP10439 CONNECTOR, PLUE-12 P1N HOLEX P15 PP10439 CONNECTOR, PLUE-12 P1N HOLEX P15 PP10439 CONNECTOR, PLUE-12 P1N HOLEX P16 PP10439 CONNECTOR, PLUE-12 P1N HOLEX P170,P27 PP10439 CONNECTOR, PLUE-12 P1N HOLEX P170,P27 PP10439 CONNECTOR, PLUE-6 P1N HOLEX P170,P27 PP10439 CONNECTOR, PLUE-6 P1N HOLEX P170,P27 PP10439 CONNECTOR, JACK-9 SKT HOLEX J172,J11,J16 PP10089 CONNECTOR, JACK-9 SKT HOLEX J172,J13 PP10705 CONNECTOR, JACK-9 SKT HOLEX J172,J13 PP10705 CONNECTOR, JACK-9 SKT HOLEX J174,J75 PP10705 CONNECTOR, JACK-2 SKT HOLEX J175,J17 PP10705 CONNECTOR, JACK-2 SKT HOLEX J177 PP10103 RECEPTACLE, NEHA E-15R (120V) PP10103 CONNECTOR, JACK-9 SLOW (GLASS) F1 PP0073 CONNECTOR, JACK-9 SLOW (GLASS) F1 PP0073 FUSE, 1 MP-SLOW SLOW (GLASS) F1 PP0075 FUSE, 2 MP-SLOW SLOW (GLASS)   |                   |           |  |
| P14 P5045860 CONNECTOR, PLUG-9 PIN HOLEX P1,P11,P16 P910090 CONNECTOR, PLUG-3 PIN HOLEX P1,P11,P16 P910090 CONNECTOR, PLUG-3 PIN HOLEX P3,P3,P3 P5045873 CONNECTOR, PLUG-2 PIN HOLEX P3,P3,P41 P910208 CONNECTOR, PLUG-12 PIN HOLEX P15 P910439 CORD, PLUG-HOLD 14-3 NEPNA 5-15P P12,P13 P910204 CONNECTOR, PLUG-12 PIN HOLEX P15,P13 P910204 CONNECTOR, PLUG-9 PIN HOLEX R3-K6 P5046580 RELAY, 24YOC - SPOT K1 P5046586 RELAY, 24 VAC - OPDT W/MTG TABS R1 P504586 RELAY, 24 VAC - OPDT W/MTG TABS P11,2,J11,J16 P910089 CONNECTOR, JACK-3 SKT HOLEX J12,J13 P910205 CONNECTOR, JACK-3 SKT HOLEX J12,J13 P910205 CONNECTOR, JACK-9 SKT HOLEX J14,7,J36 P504583 CONNECTOR, JACK-9 SKT HOLEX J17,J18,J41 P910203 CONNECTOR, JACK-2 SKT HOLEX P910103 RECEPTACLE, NEMA 5-15R (120V) P910175 RECEPTACLE, NEMA 5-15R (240V) P910175 FUSE, 1 MP9-SLON BLON (GLASS) HOMENCLATURE PART NO. OESCRIPTION  |                   |           |  |
| P1,P11,P15   |                   |           |  |
| P10  |                   | P5045860  | CONNECTOR, PLUG-9 PIN HULEX            |
| P4,P7,P38 P504SE29 COMMECTOR, PLUE-2 PIN HOLEX P3,P9,P41 PP10208 COMMECTOR, PLUE-12 PIN HOLEX P15 PP10439 CORD, PLUE-HOLD 14-3 MEPA 5-15P P12,P13 PP10204 COMMECTOR, PLUE-6 PIN HOLEX P15,P13 PP10204 COMMECTOR, PLUE-6 PIN HOLEX R3-K8 P5046S80 RELAY, 24 VAC - SPOT K1 P5046S86 RELAY, 24 VAC - SPOT MYHTG TABS R1 P5046S82 POTENTIONETER, 3000 J1,J2,J11,J16 PP10089 COMMECTOR, JACK-3 SKT HOLEX J12,J13 PP10205 COMMECTOR, JACK-9 SKT HOLEX J12,J13 PP10205 COMMECTOR, JACK-9 SKT HOLEX J14,J7,J36 P504S829 COMMECTOR, JACK-9 SKT HOLEX J13,J8,J41 PP10209 COMMECTOR, JACK-2 SKT HOLEX PP10103 RECEPTACLE, NEMA 5-15R (120V) PP10476 RECEPTACLE, NEMA 5-15R (120V) PP10476 RECEPTACLE, NEMA 5-15R (120V) PP104776 RECEPTACLE, NEMA 5-15R (120V) F5 PP10203 COMMECTOR, JACK-9 SKT HOLEX J17 PP10476 RECEPTACLE, NEMA 5-15R (120V) F5 PP10477 RECEPTACLE, NEMA 5-15R (120V) F7 PP10477  |                   |           |  |
| P3,P8,P41 PP10208 CONNECTOR, PLUG-12 PIN MOLEX P15 PP10433 CORD, PLUG-MOLD 14-3 NETA 5-1SP P12,P13 PP10204 CONNECTOR, PLUG-6 PIN MOLEX P12,P13 PP10204 CONNECTOR, PLUG-6 PIN MOLEX P5046586 RELAY, 24 VAC - OPDT W/MTG TABS R1 P5046582 POTENTIONETER, 9000 P1,J2,J11,J16 PP10089 CONNECTOR, JACK-3 SKT MOLEX J14,P7,J36 PP10208 CONNECTOR, JACK-3 SKT MOLEX J12,J13 PP10205 CONNECTOR, JACK-3 SKT MOLEX J12,J13 PP10205 CONNECTOR, JACK-2 SKT MOLEX J14,J7,J36 P5045839 CONNECTOR, JACK-2 SKT MOLEX J13,J8,J41 PP10208 CONNECTOR, JACK-2 SKT MOLEX PP10103 RECEPTACLE, NEMA S-1SR (120V) PP1013 RECEPTACLE, NEMA S-1SR (120V) PP1013 CONNECTOR, JACK-2 SKT MOLEX PP10103 RECEPTACLE, NEMA S-1SR (120V) PP1013 RECEPTACLE, NEMA S-1SR (120V) PP1013 CONNECTOR, JACK-1 PIN MOLEX F1 PP1023 CONNECTOR, JACK-1 PIN MOLEX F1 PP1023 CONNECTOR, JACK-1 PIN MOLEX F1 PP1015 CONNECTOR, JACK-1 PIN MOLEX F1 PP1015 CONNECTOR, JACK-1 PIN MOLEX F1 PF045717 FUSE, 1 MPP-SLOW SLOW (GLASS) MOMENCLATURE PART WO OSSCRIPTION   |                   |           |  |
| P15 PP10439 CORO, PLUE-MOLD 14-3 NEMA S-1SP P12,P77 PP10204 COMMECTOR, PLUE-6 PIN MOLEX P20,P77 PP10204 COMMECTOR, PLUE-6 PIN MOLEX R3-K6 PS046580 RELAY, 24 VAC - SPOT K1 PS046585 RELAY, 24 VAC - OPDT W/MTG TABS R1 PS046582 PPTEM1 DUMETER, 3000 J1,J2,J11,J16 PP10089 COMMECTOR, JACK-3 SKT MOLEX J12,J13 PP10205 COMMECTOR, JACK-9 SKT MOLEX J12,J13 PP10205 COMMECTOR, JACK-9 SKT MOLEX J12,J13 PP10205 COMMECTOR, JACK-2 SKT MOLEX J14,J7,J36 PS045839 COMMECTOR, JACK-2 SKT MOLEX J3,J8,J41 PP10209 COMMECTOR, JACK-2 SKT MOLEX J17 PP10103 RECEPTACLE, NEMA S-1SR (120V) PP10176 RECEPTACLE, NEMA S-1SR (120V) PP10476 RECEPTACLE, NEMA S-1SR (120V) PP10476 RECEPTACLE, NEMA S-1SR (120V) F1 PP10203 COMMECTOR, JACK-4 PIN MOLEX F2 PP10122 FUSE, 1 MPS-5L04 SL04 (GLASS) MOMENCLATURE PART WO. OESCRIPTION   |                   |           |  |
| P12,P13  |                   |           |  |
| P20.P27 PP10204 COMMETTER, PLUE-S PIN HOLEX  K1 P5046580 RELAY, 24 VAC - OPDT W/MTG TABS  R1 P5046582 POTENTIONETER, 9000  J1,J2,J11,J16 PP10083 COMMECTOR, JACK-3 SKT HOLEX  J14 P5045838 COMMECTOR, JACK-3 SKT HOLEX  J12,J13 J20,J27 PP10205 COMMECTOR, JACK-6 SKT HOLEX  J20,J27 PP10205 COMMECTOR, JACK-6 SKT HOLEX  J3,J8,J41 PP10209 COMMECTOR, JACK-2 SKT HOLEX  J3,J8,J41 PP10209 COMMECTOR, JACK-2 SKT HOLEX  PP10103 RECEPTACLE, NEMA 5-15R (120V)  PP10476 RECEPTACLE, NEMA 5-15R (120V)  PP10476 RECEPTACLE, NEMA 5-15R (120V)  J6 PP10203 COMMECTOR, JACK-4 PIN HOLEX  F2 PP10123 FUSE, JAPP-SLOW BLOW (GLASS)  HOMENCLATURE PART NO. DESCRIPTION  OESCRIPTION   | P15               | PP10439   | CORO, PLUG-HOLD 14-3 NEMA 5-15P        |
| PSO   PSO   PSO   PSO   PSO   PSO   PSO  | P12,P13           | 9916364   | PROMETTON OF IN- S OIL HOLEY           |
| K3-K8 P5046880 RELAY, 24V0C - SPOT K1 P5046886 RELAY, 24 VAC - OPDT W/MTG TABS R1 P5046882 POTENT IONFEER, 3000 J1,J2,J11,J16 PP10089 CONNECTOR, JACK-3 SKT MOLEX J14 P5045838 CONNECTOR, JACK-3 SKT MOLEX J12,J13 PP10205 CONNECTOR, JACK-5 SKT MOLEX J10 P5045827 CONNECTOR, JACK-9 SKT J4,77,J36 P5045839 CONNECTOR, JACK-9 SKT J4,77,J36 P5045839 CONNECTOR, JACK-12 SKT MOLEX J3,J8,J41 PP10203 CONNECTOR, JACK-12 SKT MOLEX PP10103 RECEPTACLE, NEMA S-1SR (120V) PP10103 RECEPTACLE, NEMA S-1SR (120V) J6 PP10203 CONNECTOR, JACK-4 P1N MOLEX F2 PP10122 FUSE, 1 MPS-5L04 SL04 (GLASS) MOMENCLATURE PART NO. 0ESCRIPTION  | P20.P27           | 7710204   | CONTROL PLOS FIR MALEA                 |
| KI P5045886 RELAY, 24 VAC - OPDT W/HTG TABS R1 P5045882 POTENTIONETER, 9000 J1, J2, J11, J16 PP10089 CONNECTOR, JACK-9 SKT HOLEX J12, J13 PP10209 CONNECTOR, JACK-9 SKT HOLEX J12, J17 PP10209 CONNECTOR, JACK-9 SKT HOLEX J20, J27 J10 P5045827 CONNECTOR, JACK-9 SKT J4, J7, J36 P5045829 CONNECTOR, JACK-2 SKT HOLEX J3, J8, J41 PP10209 CONNECTOR, JACK-12 SKT HOLEX J17 PP10103 RECEPTACLE, NEMA 5-1SR (120V) PP10476 RECEPTACLE, NEMA 5-1SR (120V) PP10476 RECEPTACLE, NEMA 5-1SR (240V) F2 PP10123 CONNECTOR, JACK-4-P1N HOLEX F2 PP10122 FUSE, 1 MP-SLOW SLOW (GLASS) F1 P5045717 FUSE, 2 MP-SLOW SLOW (GLASS) HOMENCLATURE PART NO. 0ESCRIPTION   |                   | PS046690  | IRELAY, 24VOC - SPOT                   |
| R1 PSOASSE2 POTENTIONETER, 3000  21, J2, J11, J16 PP10083 CONNECTOR, JACK-3 SKT MOLEX  J14 PSO4S838 CONNECTOR, JACK-9 SKT MOLEX  J12, J13 PP10205 CONNECTOR, JACK-6 SKT MOLEX  J10 PSO4S839 CONNECTOR, JACK-6 SKT MOLEX  J4, J7, J36 PSO4S839 CONNECTOR, JACK-2 SKT MOLEX  J3, J8, J41 PP10209 CONNECTOR, JACK-2 SKT MOLEX  PP10103 RECEPTACLE, NEMA S-15R (120V)  PP10478 RECEPTACLE, NEMA S-15R (120V)  J5 PP10203 CONNECTOR, JACK-4 PIN MOLEX  F2 PP10123 FUSE, AMP-SLOW BLOW (GLASS)  F1 PSO4S717 FUSE, AMP-SLOW BLOW (GLASS)  MOMENCLATURE PART NO. DESCRIPTION   |                   | P5046686  | RELAY, 24 VAC - OPDT W/MTG TABS        |
| J1, J2, J11, J16   |                   |           |  |
| J14  |                   |           |  |
| J12, J13 J20, J27 J10 P504S827 COMMECTOR, JACK-6 SKT HOLEX J4, J7, J36 P504S839 COMMECTOR, JACK-2 SKT J4, J7, J36 P504S839 COMMECTOR, JACK-2 SKT HOLEX J3, J8, J41 PF10703 COMMECTOR, JACK-12 SKT HOLEX PF10103 RECEPTACLE, NEMA S-1SR (120Y) PF10476 RECEPTACLE, NEMA S-1SR (120Y) J5 PF10476 RECEPTACLE, NEMA S-1SR (240Y) J5 PF104776 RECEPTACLE, NEMA S-1SR (36NS) F2 PF10123 COMMECTOR, JACK-4 PIN HOLEX F2 PF10123 FUSE, 1 AMP-SLOW BLOW (GLASS) HOMENCLATURE PART NO. DESCRIPTION   |                   | PS045878  | CONNECTOR JACK-9 SKT HOLEY             |
| J20, J27 PP10205 COMMECTOR, JACK-6 SKT HOLEX  J10 P5045827 COMMECTOR, JACK-9 SKT  J4, 77, J36 P5045839 COMMECTOR, JACK-9 SKT  J3, J8, J41 PP10209 COMMECTOR, JACK-12 SKT HOLEX  PP10103 RECEPTACLE, NEHA 5-15R (120V)  PP10203 COMMECTOR, JACK-4 P1N HOLEX  PP 10203 COMMECTOR, JACK-4 P1N HOLEX  F2 PP10123 FUSE, MPP-SLOW SLOW (SLASS)  HOMENCLATURE PART NO. OESCRIPTION  |                   |           | · · · · · · · · · · · · · · · · · · ·  |
| 110  |                   | PP10205   | CONNECTOR, JACK-6 SKT HOLEX            |
| J4, J7, J36 P5045839 CONNECTOR, JACK-2 SKT HOLEX J3, J8, J41 PP10209 CONNECTOR, JACK-12 SKT HOLEX PP10103 RECEPTACLE, NEMA S-15R (120V) PP10476 RECEPTACLE, NEMA S-15R (120V) J6 PP10203 CONNECTOR, JACK-4 PIN HOLEX F2 PP10122 FUSE, 1 APP-SLON SLON (GLASS) F1 P5045717 FUSE, 2 APP-SLON SLON (GLASS) HOMENCLATURE PART NO. 0ESCRIPTION  |                   | 200 ica=2 | COMPRESSOR LINEY OF CASE               |
| J3, J8, J41 PP10209 COMMECTOR, JACK-12 SKT HOLEX  PP10103 RECEPTACLE, NEMA 5-15R (120V)  PP10476 RECEPTACLE, NEMA 5-15R (120V)  J6 PP10203 COMMECTOR, JACK-4 PIN HOLEX  F2 PP10122 FUSE, NEPA-5LON SLON (GLASS)  F1 P5045717 FUSE, 2 APP-5LON SLON (GLASS)  MOMENCLATURE PART NO. DESCRIPTION  |                   |           |  |
| J17  |                   |           |  |
| PP10476   RECEPTACLE, NEMA G-15R (240V)   J6   | ۱۶۰,۵۴,۲ <u>۱</u> | -710209   | promotion, JACK-12 SKI MULEA           |
| PP10478   RECEPTACLE, NEWA S-1SK (240V)  | J17               | P10103    | HECEPTAGLE, NEWA S-TSR (120V)          |
| F2 PP10122   FUSE, 1 AMP-SLON SLON (GLASS)  F1 PS045717   FUSE, 2 AMP-SLON BLON (GLASS)  MOMENCLATURE   PART NO.   DESCRIPTION   |                   | PP10475   | RECEPTACLE, NEMA 6-15R (240V)          |
| F1 PS045717 FUSE, 2 AMP-SLOW BLOW (BLASS)  NOMENCLATURE PART NO. DESCRIPTION   |                   |           |  |
| MOMENCLATURE PART NO. DESCRIPTION  |                   | PP10122   | FUSE, AMP-SLOW SLOW (GLASS)            |
| MOMENCLATURE PART NO. DESCRIPTION  |                   | PS045717  | FUSE, 2 AMP-SLOW BLOW (GLASS)          |
| PARTS LIST   | MOMENCY ATTION    | PART NO.  | DESCRIPTION                            |
|  | MORIENCEATORE     |           |  |










|              | PARTS LIST |   |     |  |
|--------------|------------|---|-----|--|
| NOMENCLATURE | PART NO.   | DESCRIPTION                                     | QTY |  |
| CB1          | PP10470    | CIRCUIT BREAKER, 4 AMP-DOUBLE POLE              | 1   |  |
| DS1          | PP10736    | LAMP, 250 VAC-GREEN                             | 1   |  |
| HR1          | PP10080    | HEAT TAPE - 240 VAC, 165 W                      | 1   |  |
| M1           | PP10101    | PUMP/MOTOR ASSY, 115/230 VAC 1/3 HP             | 1   |  |
| J1           | PP10089    | CONNECTOR. JACK-3 SKT MOLEX                     | 1   |  |
| P1           | PP10090    | CONNECTOR, PLUG-3 PIN MOLEX                     | 1   |  |
|              | PP10572    | CORD, PLUG MOLDED 16-3 NEMA 6-15P 17.5" (SF50A) |     |  |
| P17          | PP10710    | CORD, PLUG MOLDED 16-3 NEMA 6-15P 23.5" (SF65A) | 1   |  |
| S1           | PP10735    | SWITCH, ROCKER-DPST (ON-OFF)                    | 1   |  |
| S2           | PP10739    | SWITCH, THERMAL 135°F OPEN 105°F CLOSE          | 1   |  |







|              | PARTS LIST |   |     |  |
|--------------|------------|---|-----|--|
| NOMENCLATURE | PART NO.   | DESCRIPTION                                     | QTY |  |
| CB1          | PP10470    | CIRCUIT BREAKER, 4 AMP-DOUBLE POLE              | 1   |  |
| DS1          | PP10736    | LAMP, 250 VAC-GREEN                             | 1   |  |
| HR1          | PP10080    | HEAT TAPE - 240 VAC, 165 W                      | 1   |  |
| M1           | PP10171    | PUMP/MOTOR ASSY, 240 VAC SO HZ 1/3 HP           | 1   |  |
| J1           | PP10083    | CONNECTOR, JACK-3 SKT MOLEX                     | 1   |  |
| P1           | PP10090    | CONNECTOR, PLUG-3 PIN MOLEX                     | 1   |  |
| P17          | PP10572    | CORD, PLUG MOLDED 16-3 NEMA 6-15P 17.5' (SF50A) | 1   |  |
| 1 17         | PP10710    | CORD, PLUG MOLDED 16-3 NEMA 6-15P 23.5" (SF6SA) | '   |  |
| S1           | PP10735    | SWITCH, ROCKER-DPST (ON-OFF)                    | 1   |  |
| S2           | PP10739    | SWITCH, THERMAL 135°F OPEN 105°F CLOSE          | 1   |  |







|              | PARTS LIST |   |  |  |
|--------------|------------|---|--|--|
| NOMENCLATURE | PART NO.   | DESCRIPTION                             |  |  |
| S1           | PP10098    | SW, RKR DPDT 15A W / BK (1-0-1)         |  |  |
| P1           | P5045829   | CONN, PLUG 2 PIN MLX                    |  |  |
| P2           | PP10439    | CORD, PLUG-MLD 14-3 NEMA 5-15P          |  |  |
| M1           | P5046381   | PUMP / MTR ASSY, 1/2 HP 115 / 230V 60HZ |  |  |
| J1           | P5045839   | CONN, JACK 2 SKT MOLEX                  |  |  |
| CB1          | PP10104    | CKT BKR, TOG-SPST 10A 250V 50 / 60HZ    |  |  |







| PARTS LIST   |          |                                     |  |
|--------------|----------|-------------------------------------|--|
| NOMENCLATURE | PART NO. | DESCRIPTION                         |  |
| S1           | PP10098  | SW, RKR DPDT 15A W / BK (1-0-1)     |  |
| P1           | PP10202  | CONN, PLUG 4 PIN MOLEX              |  |
| P2           | PP10439  | CORD, PLUG-MLD 14-3 NEMA 5-15P      |  |
| M1           | P5046381 | PUMP/MTR ASSY, 1/2 HP 115/230V 60HZ |  |
| J1           | PP10203  | CONN, JACK 4 SKT MOLEX              |  |
| CB1          | PP10104  | CKT BKR, TOG-SPST 10A 250V 50/60HZ  |  |
| DS1          | PP10082  | LAMP, 125V AMBER RECT               |  |
| HR1, HR2     | 5046980  | HEATER, STRIP 500W 120V             |  |







| PARTS LIST   |          |  |     |
|--------------|----------|--|-----|
| NOMENCLATURE | PART NO. | DESCRIPTION                                    | QTY |
| CB1          | PP10104  | CIRCUIT BREAKER, TOGGLE SPST 10A 250V 50/60 HZ | 1   |
| M1           | P5046381 | PUMP/MOTOR .5HP 115/230 VAC 60HZ               | 1   |
| Ј1           | PP10089  | CONNECTOR, JACK-3 SKT MOLEX                    | 1   |
| P1           | PP10090  | CONNECTOR. PLUG-3 PIN MOLEX                    | 1   |
| P17          | PP10439  | CORD, PLUG MOLDED 14-3 NEMA 5-15P              | 1   |
| S1           | P5047163 | SWITCH, TOGGLE-SPDT 20A CTR-OFF                | 1   |







| PARTS LIST |          |  |     |
|------------|----------|--|-----|
| NOMENCLATU | PART NO. | DESCRIPTION                                  | QTY |
| CB1        | P5045215 | CIRCUIT BREAKER, TOGGLE DPST 7A 250V 50/60HZ | 1   |
| DS1        | P5045020 | LAMP, BASE 220V CIRC                         | 1   |
| Ml         | P5046383 | PUMP/MOTOR ASSY, 240 VAC 50 HZ 1/2 HP        | 1   |
| J1         | PP10089  | CONNECTOR. JACK-3 SKT MOLEX                  | 1   |
| P1         | PP10090  | CONNECTOR, PLUG-3 PIN MOLEX                  | 1   |
| P17        | PP10439  | CORD, PLUG MOLDED 14-3 NEMA 6-15P            | 1   |
| S1         | P5047165 | SWITCH, TOGGLE DPDT (ON-OFF-ON)              | 1   |







| PARTS LIST   |          |   |     |
|--------------|----------|---|-----|
| NOMENCLATURE | PART NO. | DESCRIPTION                                   | QTY |
| CB1          | PP10104  | CIRCUIT BREAKER, TOGGLE SPST 10A 250V 50/60HZ | 1   |
| DS1          | P5045010 | LAMP, BASE 110V CIRC                          | 1   |
| HR1          | P5046980 | HEATER, STRIP 500W 120V                       | 2   |
| Ml           | P5046381 | PUMP/MOTOR ASSY, 115/230 VAC 1/2 HP           | 1   |
| J1           | PP10089  | CONNECTOR, JACK-3 SKT MOLEX                   | 1   |
| P1           | PP10090  | CONNECTOR, PLUG-3 PIN MOLEX                   | 1   |
| P17          | PP10439  | CORD, PLUG MOLDED 14-3 NEMA 5-15P             | 1   |
| S1           | P5047163 | SWITCH, TOGGLE SPDT 20A (ON-OFF-ON)           | 1   |





| PARTS LIST   |          |  |     |
|--------------|----------|--|-----|
| NOMENCLATURE | PART NO. | DESCRIPTION                                  | QTY |
| CB1          | P5045215 | CIRCUIT BREAKER, TOGGLE DPST 7A 25OV 50/60HZ | 1   |
| D51          | P5045010 | LAMP, BASE 110V CIRC                         | 1   |
| HR1          | P5046980 | HEATER, STRIP 500W 120V                      | 2   |
| M1           | P5046381 | PUMP/MOTOR ASSY, 115/230 VAC 1/2 HP          | 1   |
| J1           | PP10089  | CONNECTOR, JACK-3 SKT MOLEX                  | 1   |
| P1           | PP10090  | CONNECTOR, PLUG-3 PIN MOLEX                  | 1   |
| P17          | PP10439  | CORD, PLUG MOLDED 14-3 NEMA 5-15P            | 1   |
| S1           | P5047165 | SWITCH, TOGGLE DPDT (ON-OFF-ON)              | 1   |





J3. J8

NOMENCLATURE

PP10209


P5045717

PART NO.

CONNECTOR, JACK-12 SKT MOLEX

FUSE, 2 AMP-SLOW BLOW (GLASS)

DESCRIPTION PARTS LIST



| PARTS LIST   |          |                                      |  |
|--------------|----------|--------------------------------------|--|
| NOMENCLATURE | PART NO. | DESCRIPTION                          |  |
| 51           | PP10098  | SW, RKR DPDT 15A W/BK (1-0-1)        |  |
| P1           | PP10202  | CONN, PLUG 4 PIN MOLEX               |  |
| P2           | PP10439  | CORD, PLUG-MLD 14-3 NEMA 5-15P       |  |
| M1           | PP10101  | PUMP/MTR-1/3HP 115/230V 50/60HZ HGT, |  |
| J1           | PP10203  | CONN, JACK A SKT MOLEX               |  |
| CB1          | PP10104  | CKT BKR, TOG-SPST 10A 250V 50/50HZ   |  |
| DS1          | PP10082  | LAMP, 125V AMBER RECT                |  |
| HR1, HR2     | 5046980  | HEATER, STRIP 500W 120V              |  |

