IMPORTANT INFORMATION ON ATTACHING THE WALL BRACKETS TO THE WALL:

All necessary fasteners are found in the Installation Kit included with your new Powersoak.

Use the #10 x 1-1/2 stainless flat Phillips head sheetmetal screws for this purpose. These screws (marked 29188) are for attaching faucet wall brackets to metal studs, FRP-over-plywood, 5/8 inch (16mm) drywall when used with toggle fasteners (marked 29191), or when used with conical anchors (marked 29189), to tile or concrete.

 ∞

All brackets MUST be installed. The standpipe, Item 6, is marked for placement of the wall brackets.

Trim the standoffs to length so that, when installed, the riser will be plumb.

When the standoff has been trimmed, slide the ferrel over the standoff, insert its end into the wall bracket, and tighten the nut.

Use a 5/32 inch (4mm) dia drill bit for pilot holes when fastening to studs or FRP-over-plywood.

NOTE: NEVER INSTALL SHEETMETAL SCREWS IN DRYWALL WITHOUT THE USE OF A TOGGLE FASTENER. If installing on drywall, see Toggle Installation Tips below. If installing on tile or concrete, see Anchor Installation Tips below.

Toggle Installation Tips

Use only TOGGLER® BRAND TC® hollow-wall anchors with setting key included in Installation Kit.

- 1. Drill a 5/16 inch (8mm) diameter hole through the wall.
- 2. Fold the toggle fastener in the middle and tap it flush to the wall.
- 3. Insert the red "key" into the toggle fastener. Push the key inward to set the toggle, then withdraw the key. Never hammer the key. Refer to the pictographs on the TOGGLER® TC® anchor instruction sheet.

4. Insert the screw through the fixture and into the toggle fastener. Tighten flush, then stop.

Anchor Installation Tips

1. Using a masonry bit, drill a 1/4 inch (6.3mm) dia hole at least 1-1/2 inch (38mm) deep.

(15)

SPOUT, VALVE AND HOSE

00000 000000 000000

O-RINGS AND SEAT WASHERS

USE KIT No. 28224

- 2. Blow all dust from the hole.
- Drive the anchor into the hole until it's flush with the surrounding surface.
- Insert the screw through the fixture and into the anchor.

METCRAFT 26981 PRE-RINSE INSTALLATION GUIDE

TO ORDER SERVICE PARTS 800-444-9624

METCRAFT, INC. 13910 KESSLER DRIVE GRANDVIEW, MO 64030

FAX 816-761-0544 E-MAIL service@powersoak.com

26981

14		13	12	11	10	9	8	7	6	5	4	3	2	-	Item
2022/	29134	28221	28832	28217	28222	29114	29113	29112	28228	28227	29111	28219	28220	29110	Part Number
	Faceplate, Bumper & Screw	Pre-Rinse Valve Assembly	Angled Pre-Rinse Spray Assembly	Grip	Hose Assembly	Support Bracket	Wall Bracket Assembly	3/8" NPT Hose Adapter Kit	Riser & Swivel Arm Assembly	Designer Handle Kit	1-3/8" Wrench	Cold Valve Assembly	Hot Valve Assembly	Mounting Kit	Description

26981 BOX INSERT.DWG K53-5500-PS