



N8000, N8000-R, N8100B, N8100-BR, N8100-FA, 8100-EF, N8200, N8200G, N8600, N8700-D, N8700-R, N8800 Drop Ins

Service, Installation and Care Manual

Please read this manual completely before attempting to install or operate this equipment!
Notify carrier of damage! Inspect all components immediately.



**Hot Food Wells, Cold Pans, Granite Cold Slabs,
Frost Tops and Hot/Cold Food Wells**



May 2010



Important Warning And Safety Information

WARNING Read This Manual Thoroughly Before Operating, Installing, Or Performing Maintenance On The Equipment.



WARNING Failure To Follow Instructions In This Manual Can Cause Property Damage, Injury Or Death.



WARNING Do Not Store Or Use Gasoline Or Other Flammable Vapors Or Liquids In The Vicinity Of This Or Any Other Appliance.



WARNING Unless All Cover And Access Panels Are In Place And Properly Secured, Do Not Operate This Equipment.



WARNING Do Not Clean With Water Jet.



CAUTION Observe the following:



- Minimum clearances must be maintained from all walls and combustible materials.
- Keep the equipment area free and clear of combustible material.
- Adequate clearance for air openings.
- Operate equipment only on the type of electricity indicated on the specification plate.
- Retain this manual for future reference.

Contents

Receiving And Inspecting Unit	3
Specifications	4-7
Installation	
Curved Drop-In Cutout Details	8
N8000, N8000N, N8000-R, N8100B, N8100NB, N8100-BR, N8200, N8200G, 8100-FA, 8100-EF Series	9
N8600 Series	9
N8700-D, N8700N, N8700-R & N8800 Series	10
Operation	
N8100B, N8100NB, N8100-BR	11
N8100-FA	11
8100-EF	12
N8200 & N8200G	12
N8600	13
N8700-D, N8700N, N8700-R & N8800 Series	14
Maintenance	15
Unit Assembly N8100-FA	16
Wiring Diagram	
N8100-FA	16
N8100B, N8100NB & N8100-BR	17
8100-EF & 8100-EFN	17
N8200 & N8200G	17
N8600	18-19
N8800	19
N8700-D, N8700N & N8700-R	20
Louver Diagram	21
Miscellaneous Replacement Parts	21
N8100-FA Replacement Parts List	22
Condensing Unit Assembly Parts List	23-26
Food Well Assembly Parts List	27-28
Standard Labor Guidelines	29
Standard Warranties	30-31

Serial Number Location

The serial number on self-contained refrigerated units is on the electrical specifications tag located near the condensing unit.

The serial number on remote refrigerated units is on the outside bottom of the food well.

On hot food pans and hot/cold combination pans, the serial number tag is located on the back of the control raceway or remote panel.

The serial number tag also lists the refrigerant used and the amount of charge.

Always have the serial number of your unit available when calling for parts or service.

This manual covers only standard 8000 series units. If you have a custom designed unit, you should contact our parts/service department at (800) 733-8829 for questions.

©2010 The Delfield Company. All rights reserved. Reproduction without written permission is prohibited. "Delfield" is a registered trademark of The Delfield Company.

Receiving And Inspecting The Equipment

Even though most equipment is shipped crated, care should be taken during unloading so the equipment is not damaged while being moved into the building.

1. Visually inspect the exterior of the package and skid or container. Any damage should be noted and reported to the delivering carrier immediately.
2. If damaged, open and inspect the contents with the carrier.
3. In the event that the exterior is not damaged, yet upon opening, there is concealed damage to the equipment notify the carrier. Notification should be made verbally as well as in written form.
4. Request an inspection by the shipping company of the damaged equipment. This should be done within 10 days from receipt of the equipment.

5. Also open the compressor compartment housing and visually inspect the refrigeration package. Be sure lines are secure and base is still intact.
6. Freight carriers can supply the necessary damage forms upon request.
7. Retain all crating material until an inspection has been made or waived.

Uncrating The Equipment

First cut and remove the banding from around the crate. Remove the front of the crate material, use of some tools will be required.



Specifications

N8100B Series Self-Contained Mechanically Cooled Pans - R134A

Model	L	D	H	Counter Cutout Dimensions	V/Hz/Ph	Amps	H.P.	BTU	Evap BTU/ TD/TEMP	Sys Cap	Ship Weight	Refrig. Charge	NEMA Plug	12"x20" Pans
N8118B	18" (45.7cm)	26" (66cm)	21.87" (55.5cm)	17" X 25" (43.2cm x 63.5cm)	115/60/1	4.0	1/5	204	19/38°/-3°	708	100lbs (45kg)	8.0oz	5-15P	1
N8130B	30.75" (78.1cm)	26" (66cm)	21.87" (55.5cm)	29.75" x 25" (75.6cm x 63.5cm)	115/60/1	4.0	1/5	379	26/31°/4°	812	140lbs (64kg)	8.0oz	5-15P	2
N8143B	43.5" (110.5cm)	26" (66cm)	21.87" (55.5cm)	42.50" X 25" (108.6cm x 63.5cm)	115/60/1	4.0	1/5	569	35/26°/9°	889	173lbs (78kg)	8.0oz	5-15P	3
N8156B	56.25" (142.9cm)	26" (66cm)	21.87" (55.5cm)	55.25" x 25" (140.3cm x 63.5cm)	115/60/1	7.0	1/4	758	43/32°/3°	1373	205lbs (93kg)	16.0oz	5-15P	4
N8169B	69" (175.3cm)	26" (66cm)	21.87" (55.5cm)	68" X 25" (172.7cm x 63.5cm)	115/60/1	7.0	1/4	948	51/29°/6°	1469	225lbs (102kg)	16.0oz	5-15P	5
N8181B	81.75" (208cm)	26" (66cm)	21.87" (55.5cm)	80.75" x 25" (205.1cm x 63.5cm)	115/60/1	8.0	1/3	1138	59/32°/3°	1921	258lbs (117kg)	11.5oz	5-15P	6

N8100NB Series Self-Contained Mechanically Cooled Pans Narrow Style - R134A

N8146NB	46.75" (118.7cm)	18" (45.7cm)	21.81" (55.4cm)	45.75" x 17" (113.7cm x 43.2cm)	115/60/1	4.0	1/5	454	17/40°/-5°	680	175lbs (80kg)	8.0oz	5-15P	2
N8168NB	67.5" (171.5cm)	18" (45.7cm)	21.81" (55.4cm)	66.5" x 17" (168.9cm x 43.2cm)	115/60/1	4.0	1/5	676	26/31°/4°	804	240lbs (109kg)	8.0oz	5-15P	3

N8100BR Series Curved Self-Contained Mechanically Cooled Pans - R134A

Model	L	D	H	Counter Cutout Dimensions	V/Hz/Ph	Amps	H.P.	BTU	Evap BTU/ TD/TEMP	Sys Cap	Ship Weight	Refrig. Charge	NEMA Plug	12"x20" Pans
N8144-BR	40.43" (103cm)	26.05" (66cm)	21.81" (55cm)	see drawing on page 8	115/60/1	4.0	1/5	379	26/31°/4°	812	161lbs (72kg)	8.0oz	5-15P	2
N8159-BR	57.22" (145cm)	26.05" (66cm)	21.81" (55cm)	see drawing on page 8	115/60/1	4.0	1/5	569	35/26°/9°	889	184lbs (83kg)	8.0oz	5-15P	3
N8176-BR	73.68" (187cm)	26.05" (66cm)	21.81" (55cm)	see drawing on page 8	115/60/1	7.0	1/4	758	43/32°/3°	1373	233lbs (105kg)	16.0oz	5-15P	4
N8194-BR	89.86" (228cm)	26.05" (66cm)	21.81" (55cm)	see drawing on page 8	115/60/1	7.0	1/4	948	51/29°/6°	1469	243lbs (109kg)	16.0oz	5-15P	5

N8100-FA Series Forced Air Drop-In Mechanically Cooled Cold Pans - R404A

Model	L	D	H	Counter Cutout Dimensions	V/Hz/Ph	Amps	H.P.	BTU	Evap BTU/ TD/TEMP	Sys Cap	Ship Weight	Refrig. Charge	NEMA Plug	12"x20" Pans
N8131-FA	31.25" (79.4cm)	26.67" (67.7cm)	26.62" (68cm)	30.25" x 25.5" (76.8cm x 64.8cm)	115/60/1	7.8	1/4	1339	140/15°/20°	2154	168lbs (76kg)	16.0oz	5-15P	2
N8144-FA	44" (111.8cm)	26.67" (67.7cm)	26.62" (68cm)	43" x 25.5" (109.2cm x 64.8cm)	115/60/1	9.2	1/2	2035	140/22°/13°	3142	175lbs (79kg)	32.0oz	5-15P	3
N8157-FA	56.75" (144.1cm)	26.67" (67.7cm)	26.62" (68cm)	55.75" x 25.5" (141.6cm x 64.8cm)	115/60/1	9.2	1/2	2731	280/14°/21°	3806	225lbs (102kg)	32.0oz	5-15P	4
N8169-FA	69.5" (176.5cm)	26.67" (67.7cm)	28.62" (72.7cm)	68.5" x 25.5" (174.0cm x 64.8cm)	115/60/1	14.8	3/4	3374	280/20°/15°	5545	235lbs (107kg)	48.0oz	5-20P	5
N8182-FA	82.25" (208.9cm)	26.67" (67.7cm)	28.62" (72.7cm)	81.25" x 25.5" (206.4cm x 64.8cm)	115/60/1	14.8	3/4	4070	280/20°/15°	5545	406lbs (184kg)	48.0oz	5-20P	6

Specifications

8100-EF Series LiquiTec® Eutetic Fluid Refrigerated Cold Pans - R404A

<i>Model</i>	<i>L</i>	<i>D</i>	<i>H</i>	<i>Counter Cutout Dimensions</i>	<i>V/Hz/Ph</i>	<i>Amps</i>	<i>H.P.</i>	<i>BTU Load</i>	<i>Evap BTU/ TD/TEMP</i>	<i>Sys Cap</i>	<i>Ship Weight</i>	<i>Refrig. Charge</i>	<i>NEMA Plug</i>	<i>12x20 Pans</i>
8118-EF	18.20" (46.2cm)	26" (66cm)	23.25" (59.1cm)	17" x 25" (43.2cm x 63.5cm)	115/60/1	7.5	1/4	204	19/50°/-15°	928	169lbs (77kg)	24.0oz	5-15P	1
8132-EF	31.76" (80.7cm)	26" (66cm)	23.25" (59.1cm)	30.75" x 25" (78.1cm x 63.5cm)	115/60/1	7.5	1/4	379	26/42°/-7°	1112	215lbs (98kg)	24.0oz	5-15P	2
8145-EF	45.32" (115.1cm)	26" (66cm)	23.25" (59.1cm)	44.25" x 25" (112.4cm x 63.5cm)	115/60/1	7.5	1/4	569	35/36°/-1°	1259	265lbs (120kg)	24.0oz	5-15P	3
8159-EF	58.88" (149.6cm)	26" (66cm)	23.25" (59.1cm)	57.87" x 25" (147cm x 63.5cm)	115/60/1	7.5	1/4	758	43/32°/3°	1373	285lbs (130kg)	24.0oz	5-15P	4
8172-EF	72.44" (184cm)	26" (66cm)	23.25" (59.1cm)	71.5" x 25" (181.6cm x 63.5cm)	115/60/1	7.5	1/4	948	51/29°/6°	1469	295lbs (134kg)	24.0oz	5-15P	5
8186-EF	86" (218.4cm)	26" (66cm)	23.25" (59.1cm)	85" x 25" (215.9cm x 63.5cm)	115/60/1	7.5	1/4	1138	59/26°/9°	1529	394lbs (179kg)	24.0oz	5-15P	6

8100-EFN Series LiquiTec® Slim Line Eutetic Fluid Refrigerated Cold Pans - R404A

<i>Model</i>	<i>L</i>	<i>D</i>	<i>H</i>	<i>Counter Cutout Dimensions</i>	<i>V/Hz/Ph</i>	<i>Amps</i>	<i>H.P.</i>	<i>BTU Load</i>	<i>Evap BTU/ TD/TEMP</i>	<i>Sys Cap</i>	<i>Ship Weight</i>	<i>Refrig. Charge</i>	<i>NEMA Plug</i>	<i>12x20 Pans</i>
8148-EFN	47.66" (121.1cm)	18" (45.7cm)	23.25" (59.1cm)	46.88" x 17.25" (119.1cm x 43.8cm)	115/60/1	7.5	1/4	379	26/42°/-7°	1112	235lbs (107kg)	24.0oz	5-15P	2
8169-EFN	69.22" (175.8cm)	18" (45.7cm)	23.25" (59.1cm)	68.5" x 17.25" (174cm x 43.8cm)	115/60/1	7.5	1/4	569	35/36°/-1°	1259	285lbs (130kg)	24.0oz	5-15P	3
8191-EFN	90.78" (230.6cm)	18" (45.7cm)	23.25" (59.1cm)	90" x 17.25" (228.6cm x 43.8cm)	115/60/1	7.5	1/4	758	43/32°/13°	1373	295lbs (134kg)	24.0oz	5-15P	4

N8000 Series Ice Cooled Cold Pans

<i>Model</i>	<i>L</i>	<i>D</i>	<i>H</i>	<i>Counter Cutout Dimensions</i>	<i>Ship Weight</i>	<i>12"x20" Pans Held</i>
N8018	18" (45.7cm)	26" (66cm)	10.75" (27.3cm)	17" x 25" (43.2cm x 63.5cm)	38lbs (17kg)	1
N8030	30.75" (78.1cm)	26" (66cm)	10.75" (27.3cm)	29.75" x 25" (75.6cm x 63.5cm)	84lbs (38kg)	2
N8043	43.5" (110.5cm)	26" (66cm)	10.75" (27.3cm)	42.5" x 25" (107.9cm x 63.5cm)	110lbs (50kg)	3
N8056	56.25" (142.9cm)	26" (66cm)	10.75" (27.3cm)	55.25" x 25" (140.3cm x 63.5cm)	139lbs (63kg)	4
N8069	69" (175.3cm)	26" (66cm)	10.75" (27.3cm)	68" x 25" (172.7cm x 63.5cm)	160lbs (73kg)	5
N8081	81.75" (208cm)	26" (66cm)	10.75" (27.3cm)	80.75" x 25" (205.1cm x 63.5cm)	197lbs (89kg)	6

N8000N Series Narrow Ice Cooled Cold Pans

N8046N	46.75" (118.8cm)	18" (45.7cm)	10.75" (27.3cm)	45.75" x 17" (116.2cm x 43.2cm)	100lbs (45kg)	2
N8068N	67.5" (171.5cm)	18" (45.7cm)	10.75" (27.3cm)	66.50" x 17" (168.9cm x 43.2cm)	120lbs (55kg)	3



Specifications

N8000-R Series Curved Ice Cooled Cold Pans

Model	L	D	H	Counter Cutout Dimensions	Ship Weight	12"x20" Pans Held
N8044-R	40.48" (103cm)	26.05" (66cm)	10.77" (27cm)	see drawing on page 8	100lbs (45kg)	2
N8059-R	57.22" (145cm)	26.05" (66cm)	10.77" (27cm)	see drawing on page 8	118lbs (53kg)	3
N8076-R	73.68" (187cm)	26.05" (66cm)	10.77" (27cm)	see drawing on page 8	145lbs (65kg)	4
N8094-R	89.89" (228cm)	26.05" (66cm)	10.77" (27cm)	see drawing on page 8	164lbs (74kg)	5

N8200 Series Self-Contained Frost Tops - R404A

Model	L	D	H	Counter Cutout Dimensions	V/Hz/Ph	Amps	H.P.	BTU	Evap BTU/ TD/TEMP	Sys Cap	Ship Weight	Refrig. Charge	NEMA Plug
N8231	31.75" (80.6cm)	26" (66cm)	15.75" (40cm)	30.75" x 25" (78.1cm x 63.5cm)	115/60/1	7.5	1/4	379	26/42°/-7°	1112	142lbs (64kg)	24.0oz	5-15P
N8245	45.63" (115.9cm)	26" (66cm)	15.75" (40cm)	44.63" x 25" (113.3cm x 63.5cm)	115/60/1	7.5	1/4	569	35/36°/-1°	1259	168lbs (76kg)	24.0oz	5-15P
N8259	59.5" (151.1cm)	26" (66cm)	15.75" (40cm)	58.50" x 25" (148.6cm x 63.5cm)	115/60/1	7.5	1/4	758	43/32°/3°	1373	193lbs (88kg)	24.0oz	5-15P
N8273	73.38" (186.4cm)	26" (66cm)	15.75" (40cm)	72.38" x 25" (183.8cm x 63.5cm)	115/60/1	8.0	1/4	948	51/29°/6°	1469	209lbs (95kg)	24.0oz	5-15P
N8287	87.25" (221.6cm)	26" (66cm)	15.75" (40cm)	86.25" x 25" (219.1cm x 63.5cm)	115/60/1	8.0	1/3	1138	59/30°/5°	1787	239lbs (108kg)	24.0oz	5-15P

N8200G Series Self-Contained Granite Cold Slabs

Model	L	D	H	Counter Cutout Dimensions	V/Hz/Ph	Amps	H.P.	BTU	Evap BTU/ TD/TEMP	Sys Cap	Ship Weight	Refrig. Charge	NEMA Plug
N8231G	31.75" (80.6cm)	25.87" (65.7cm)	19" (48.3cm)	30.75" X 25" (78.1cm x 63.5cm)	115/60/1	7.5	1/4	379	26/42°/-7°	1112	219lbs (99kg)	24.0oz	5-15P
N8245G	45.63" (115.9cm)	25.87" (65.7cm)	19" (48.3cm)	44.63" x 25" (113.4cm x 63.5cm)	115/60/1	7.5	1/4	569	35/36°/-1°	1259	284lbs (129kg)	24.0oz	5-15P
N8259G	59.5" (151.1cm)	25.87" (65.7cm)	19" (48.3cm)	58.5" x 25" (148.6cm x 63.5cm)	115/60/1	8.0	1/3	758	43/37°/-2°	1572	338lbs (153kg)	24.0oz	5-15P
N8273G	73.38" (186.4cm)	25.87" (65.7cm)	19" (48.3cm)	72.38" x 25" (183.8cm x 63.5cm)	115/60/1	9.0	1/2	948	51/43°/-8°	2183	425lbs (193kg)	32.0oz	5-15P

N8600 Series Self Contained Combination Hot/Cold Food Wells - R404A

Model	L	D	H	Counter Cutout Dimensions	Control Panel Cutout Dimensions	V/Hz/Ph	Amps	H.P.	BTU	Evap BTU/TD	Sys Cap	Ship Weight	Refrig. Charge	12"x20" Pans
N8630	30.75" (78.1cm)	26" (66cm)	23.75" (60.3cm)	29.75" X 25" (75.5cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	120/60/1	24.0	1/4	379	26/42°/-7°	1112	164lbs (74kg)	16.0oz	2
N8643	43.5" (110.5cm)	26" (66cm)	23.75" (60.3cm)	42.50" x 25" (107.9cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	120/240 /60/1	21.0	1/4	569	35/36°/-1°	1259	198lbs (90kg)	16.0oz	3
N8656	56.25" (142.9cm)	26" (66cm)	23.75" (60.3cm)	55.25" x 25" (140.3cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	120/240 /60/1	21.0	1/4	758	43/32°/3°	1373	233lbs (106kg)	16.0oz	4
N8669	69" (175.3cm)	26" (66cm)	23.75" (60.3cm)	68" x 25" (172.7cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	120/240 /60/1	42.0	1/4	948	51/29°/6°	1469	266lbs (121kg)	16.0oz	5
N8681	81.75" (207.6cm)	26" (66cm)	23.75" (60.3cm)	80.75" x 25" (205.1cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	120/240 /60/1	42.0	1/3	1138	59/30°/5°	1787	301lbs (137kg)	24.0oz	6

Specifications

N8700D Series Individually Controlled Heated Food Wells

Model	L	D	H	Counter Cutout Dimensions	Control Panel Cutout Dimensions	V/Hz/Ph	Amps	Ship Weight	12"x20" Pans
N8717-D	17.88" (45.4cm)	26" (66cm)	9.5" (24cm)*	16.88" X 25" (42.8cm x 63.5cm)	7.00" x 4.62" x 7.00" (17.8cm x 11.7cm x 17.8cm)	120/60/1	8.3	41lbs (19kg)	1
N8731-D	31.75" (80.6cm)	26" (66cm)	9.5" (24cm)*	30.75" x 25" (78.1cm x 63.5cm)	10.31" x 4.62" x 7.00" (26.2cm x 11.7cm x 17.8cm)	120/60/1	16.6	99lbs (45kg)	2
N8745-D	45.63" (115.9cm)	26" (66cm)	9.5" (24cm)*	44.62" x 25" (113.3cm x 63.5cm)	14.5" x 4.62" x 7.00" (36.8cm x 11.7cm x 17.8cm)	208-230 /60/1	15.0/16.0	134lbs (61kg)	3
N8759-D	59.5" (151.1cm)	26" (66cm)	9.5" (24cm)*	58.5" x 25" (148.6cm x 63.5cm)	18.69" x 4.62" x 7.00" (47.5cm x 11.7cm x 17.8cm)	208-230 /60/1	20.0/22.0	166lbs (75kg)	4
N8773-D	73.38" (186.4cm)	26" (66cm)	9.5" (24cm)*	72.37" x 25" (183.8cm x 63.5cm)	22.88" x 4.62" x 7.00" (58.1cm x 11.7cm x 17.8cm)	208-230 /60/1	24.0/27.0	186lbs (84kg)	5
N8787-D	87.25" (221.4cm)	26" (66cm)	9.5" (24cm)*	86.25" x 25" (219.1cm x 63.5cm)	27" x 4.62" x 7.00" (68.6cm x 11.7cm x 17.8cm)	208-230 /60/1	29.0/32.0	236lbs (107kg)	6

*14" Overall height including drain connection

N8700-R Series Curved Individually Controlled Heated Food Wells

Model	L	D	H	Counter Cutout Dimensions	Control Panel Cutout Dimensions	V/Hz/Ph	Amps	Ship Weight	12"x20" Pans
N8744-R	40.48" (103cm)	26.05" (66cm)	9.5" (24cm)*	see drawing on page 8	10.31" x 4.62" x 7.00" (26cm x 12cm x 18cm)	120/60/1	16.6	99lbs (45kg)	2
N8759-R	57.22" (145cm)	26.05" (66cm)	9.5" (24cm)*	see drawing on page 8	14.5" x 4.62" x 7.00" (37cm x 12cm x 18cm)	208-230 /60/1	15.0/16.0	134lbs (61kg)	3
N8776-R	73.68" (187cm)	26.00" (66cm)	9.5" (24cm)*	see drawing on page 8	18.69" x 4.62" x 7.00" (47cm x 12cm x 18cm)	208-230 /60/1	20.0/22.0	166lbs (75kg)	4
N8794-R	89.80" (228cm)	25.91" (66cm)	9.5" (24cm)*	see drawing on page 8	22.88" x 4.62" x 7.00" (58cm x 12cm x 18cm)	208-230 /60/1	24.0/27.0	186lbs (84kg)	5

*14" Overall height including drain connection

N8700N Series Individually Controlled Heated Narrow Food Wells

Model	L	D	H	Counter Cutout Dimensions	Control Panel Cutout Dimensions	V/Hz/Ph	Amps	Ship Weight	12"x20" Pans
N8746N N8746ND	45.61" (116cm)	15.87" (40cm)	9.5" (24cm)	44.62" x 15.0" (113.3cm x 38.1cm)	10.31" x 4.62" x 7.00" (26.2cm x 11.7cm x 17.8cm)	120/60/1	17.0	100lbs (45kg)	2
N8768N N8768ND	67.48" (172cm)	15.87" (40cm)	9.5" (24cm)	66.50" x 15.0" (168.9cm x 38.1cm)	14.50" x 4.62" x 7.00" (36.8cm x 11.7cm x 17.8cm)	208-230 /60/1	15.0/16.0	130lbs (59kg)	3

*ND Models are standard with drains

N8800 Series Single Tank Electric Hot Food Wells

Model	L	D	H	Counter Cutout Dimensions	Control Panel Cutout Dimensions	V/Hz/Ph	Amps	Ship Weight	12"x20" Pans
N8831	31.75" (80.6cm)	26" (66cm)	11" (27.9cm)	30.75" X 25" (78.1cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	120/60/1	17.0	100lbs (45kg)	2
N8845	45.63" (115.9cm)	26" (66cm)	11" (27.9cm)	44.63" x 25" (113.4cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	208-230 /60/1	15.0/16.0	136lbs (62kg)	3
N8859	59.5" (151.1cm)	26" (66cm)	11" (27.9cm)	58.5" x 25" (148.6cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	208-230 /60/1	20.0/22.0	158lbs (72kg)	4
N8873	73.38" (186.4cm)	26" (66cm)	11" (27.9cm)	72.38" x 25" (183.8cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	208-230 /60/1	24.0/27.0	195lbs (88kg)	5
N8887	87.25" (221.6cm)	26" (66cm)	11" (27.9cm)	86.25" x 25" (219.1cm x 63.5cm)	12.25" x 4.25" x 7.00" (31.1cm x 10.8cm x 17.8cm)	208-230 /60/1	29.0/32.0	224lbs (102kg)	6




Curved Drop-In Cutout Details

2 pan standard curved drop-in cutout detail

Models:


- N8044-R
- N8144-BR
- N8744-R



3 pan standard curved drop-in cutout detail

Models:


- N8059-R
- N8159-BR
- N8759-R



4 pan standard curved drop-in cutout detail

Models:


- N8076-R
- N8176-BR
- N8776-R



5 pan standard curved drop-in cutout detail

Models:

- N8094-R
- N8194-BR
- N8794-R



Installation N8000, N8000N, N8000-R, N8100B, N8100NB, N8100-BR, N8200, N8200G, N8100-FA & 8100-EF**Drop In Procedure**

These units are intended for indoor use only. A room temperature of no more than 86°F (30°C) is recommended. Be sure the location chosen has a counter strong enough to support the total weight of the unit and contents. A fully loaded model may weigh as much as 600 pounds! Reinforce the counter as necessary to provide maximum loading.



Unit requires that the sides and bottom are not any closer than 3" (7.6cm) to any combustible material.

The counter cut-out sizes and power requirements are shown on the specification pages. A gasket is installed in the flange of each unit. The weight of the unit on the gasket forms a seal preventing liquids from seeping into the cut-out opening.

Louvers

Self-contained refrigerated units (N8100, N8100NB, N8100-BR, N8200 and N8200G Series) require airflow to the compressor. A 13" x 25" (33 cm x 63.5 cm) louver is provided by Delfield and must be installed in the counter in front of the condenser. The louver cutout dimension is 11" x 22" (27.9 cm x 55.9 cm). The rear must have an opening to permit removal of heated air. The opening must be at least 8" x 11", a total of 88 square inches (20.3 cm x 27.9 cm, a total of 566 square centimeters).

Plumbing

The units drain must have an outlet to an appropriate drainage area or container. A drain trap must be installed. N8200 series have 1/2" drain and N8200G series have 3/4" drain located on end/center. The 1" diameter drain on N8000, N8000-R, N8100, N8100NB, N8100-BR, N8100-FA and 8100-EF Series units is shipped loose and must be connected during installation. N8157-FA, N8169-FA, and N8182-FA have two drains.



Moisture collecting from improper drainage can create a slippery surface on the floor and a hazard to employees. It is the owner's responsibility to provide a container or outlet for drainage.



Some N8000, N8000N, N8000-R, N8100B, N8100NB and N8100-BR may have polyethylene insulation in the drain hole. This can easily be cut out without any contact or damage to the units interior insulation or refrigeration lines.

Electrical connection

Refer to the amperage data on the specification pages, the serial tag or your local code to be sure the unit is connected to the proper power source. A protected circuit of the correct voltage and amperage must be run for connection of the line cord.

Some units have an **ON/OFF** switch located behind the louvered panel in the machine compartment. Simply turn the switch to **ON** to begin operation.

Some units have an **OFF** position on the thermostat dial which is located behind the louvered panel in the machine compartment. Simply turn the dial to begin operation.



The unit must be disconnected from the power source whenever performing service or maintenance functions.

Never operate the unit without the louvered panel in place!

Installation N8600**Drop In Procedure**

These units are intended for indoor use only. A room temperature of no more than 86°F (30°C) is recommended. Be sure the location chosen has a counter strong enough to support the total weight of the unit and contents. A fully loaded model may weigh as much as 600 pounds! Reinforce the counter as necessary to provide for maximum loading.



Unit requires that the sides and bottom are not any closer than 3" (7.6cm) to any combustible material.

The counter cut-out sizes and power requirements are shown on the specification pages. A gasket is installed in the flange of each unit. The weight of the unit on the gasket forms a seal preventing liquids from seeping into the cut-out opening.

The cut-out dimensions for the control box on N8600 Series units is 4.25" x 12.25" (10.8 cm x 31.1 cm).

Louvers

For proper refrigerated operation, N8600 Series units require airflow to the compressor. A 13" x 25" louver is (33.0 cm x 63.5 cm) is provided by Delfield and must be installed in the counter in front of the condenser. The louver cutout dimension is 11"

x 22" (27.9 cm x 55.9 cm). The rear must have an opening to permit removal of heated air. The opening must be at least 8" x 11", a total of 88 square inches (20.3 cm x 27.9 cm, a total of 566 square centimeters).

Plumbing

The units 1" (2.54cm) drain must have an outlet to an appropriate drainage area or container.



Moisture collecting from improper drainage can create a slippery surface on the floor and a hazard to employees. It is the owner's responsibility to provide a container or outlet for drainage.

Electrical connection

Refer to the amperage data on the specification pages, the serial tag or your local code to be sure the unit is connected to the proper power source.



The unit must be disconnected from the power source whenever performing service or maintenance functions.

Never operate the unit without the louvered panel in place!



Installation N8700-D, N8700N, N8700-R & N8800 Series

Drop In Procedure

These units are intended for indoor use only. Be sure the location chosen has a counter strong enough to support the total weight of the unit and contents. A fully loaded model may weigh as much as 600 pounds! Reinforce the counter as necessary to provide maximum loading.



Unit requires that the sides and bottom are not any closer than 3" (7.6cm) to any combustible material.

The counter cut-out sizes and power requirements are shown on the specification pages. A gasket is installed in the flange of each unit. The weight of the unit on the gasket forms a seal preventing liquids from seeping into the cut-out opening.



N8700 Series pans should be installed with the drains at the back, away from the operator's sides.

The controls on N8700-D, N8700-R and N8800 series units are mounted in a control panel, designed to be installed at a "remote" location. The control panel should be installed so that the indicator light for each control is to the right of the control. N8700, N8700N and N8700-R series units have 48" (121.9cm) of conduit and N8800 Series units have 24" (61.0cm) of conduit between the pans and the remote control panel to facilitate this installation.

Plumbing

N8700-D, N8700N-D and N8700-R Plumbing: Unit is equipped with 1/2" (1.3cm) drains, (one per well located in right rear corner 1/2" (1.3cm) female N.P.T.) manifold and 1/2" (1.3cm) gate valve.

N8800 Plumbing: Well is sloped to a 1.00" (2.5cm) male N.P.T. stainless steel drain.



Moisture collecting from improper drainage can create a slippery surface on the floor and a hazard to employees. It is the owner's responsibility to provide a container or outlet for drainage.

Electrical connection

Refer to the amperage data on the specification pages, the serial tag or your local code to be sure the unit is connected to the proper power source.




The unit must be disconnected from the power source whenever performing service or maintenance functions.

Control Panel Installation, N8700-D, N8700N & N8700-R Series

The control panel is designed to be installed on the side opposite the drains.

If you choose to install the control panel on the same side as the drains the control panel will either be upside down or the knobs will control the opposite wells.



Operation N8100B, N8100NB & N8100-BR

N8100 Series mechanically cooled cold pans are adjusted at the factory to provide proper operation without any further adjustments. However, if it is necessary to adjust the temperature, the control is located in the machine compartment. Turn the knob clockwise as indicated on the control. Settings are from 1 thru 7 (7 being the coldest). Adjustments should be made gradually. Several small adjustments will be more effective than one large adjustment. It may take an hour or longer to realize the temperature change depending on the application and location of the unit.

These units are not designed to cool warm food products. Items should be placed in the unit pre-cooled at least to the desired holding temperature, if not slightly colder. In some applications, a gradual warming of product may occur, particularly at the exposed top of the product. Stirring or rotation of the product may be necessary to maintain overall temperature.

Warming of food product can occur very quickly outside of the unit. When loading or rotating product, avoid leaving food items in a non-refrigerated location for any length of time to prevent warming or spoilage.

The temperature control is used to turn the unit on and off as well as control the temperature of the cold pan. The settings range from 1 through 7 (7 being the coldest). To turn the cold pan off, turn the knob to the **OFF** position.

If the cold pan is to be used with ice, it is recommended that the optional perforated bottoms be used. These will allow ice to melt properly.

The unit must be turned off when not in use or overnight for defrosting and cleaning.

Operation N8100-FA

N8100-FA Series forced air mechanically cooled cold pans come equipped with 115-volt, 60 Hertz, single phase refrigeration units. The refrigeration valves are open and ready to operate as soon as the power supply cord is plugged into the standard 115-volt, grounded electrical outlet.

Pressure Control

The temperature is controlled by an adjustable pressure control located in the machine compartment and adjustable control has the word **COLDER** near the knob, with an arrow to indicate the adjustment direction. This control is field adjustable and does not require a service agent. If you have any questions, feel free to contact the Delfield Service Department at (800) 733-8829.



NOTE

In attempting to adjust the pressure control, you can do damage to the unit by accidentally adjusting the differential. Delfield is not responsible for charges incurred while adjusting the pressure control.




NOTE


Food in the N8100-FA pans should not be loaded in such a way as to interfere with the air curtain flowing over the cold pans.

Defrost Timer

Every 2 hours for 15 minutes.



SPADE CONNECTIONS BOTTOM REAR OF HOUSING



30 psi (207 kPa) differential
80 psi (552 kPa) cut-in
50 psi (345 kPa) cut-out

Operation 8100-EF Series

There is a switch on the compressor housing front to turn the 8100-EF units on and off. 8100-EF Series LiquiTec® Eutetic fluid cold pans are adjusted at the factory to provide proper operation without any further adjustments. However, if it is necessary to adjust the temperature, the control is located in the machine compartment. Turn the knob clockwise as indicated on the control to adjust it colder. Adjustments should be made gradually. Several small adjustments will be more effective than one large adjustment. It may take an hour or longer to realize the temperature change depending on the application and location of the unit.

These units are not designed to cool warm food products. Items should be placed in the unit pre-cooled at least to the desired holding temperature, if not slightly colder. In some applications, a gradual warming of product may occur, particularly at the exposed top of the product. Stirring or rotation of the product may be necessary to maintain overall temperature. Warming of food product can occur very quickly outside of the unit. When loading or rotating the product, avoid leaving food items in a non-refrigerated location for any length of time to prevent warming or spoilage.



The cold pan is not intended to be used with ice.


The unit must be turned off when not in use or overnight for defrosting and cleaning.

Temperature Control Settings:

17°F (8°C) differential

25°F (-4°C) cut-in

8°F (-13°C) cut-out



Operation N8200

N8200 Series frost tops are designed to maintain an even layer of frost to pleasantly display product. Once turned on, the compressor will run continuously. The unit should be turned off overnight or when not in use. There is no temperature control on the N8200 series. The ON/OFF switch is the only means available to cycle the unit.

Since it takes time for the frost to accumulate initially, the unit should be turned on approximately one hour before it is actually required. Product should not be placed on the frost top prior to turning the unit on, because it may freeze to the surface of the unit.

The unit must be turned off when not in use or overnight for defrosting and cleaning.

Operation N8200G

N8200G Series granite cold slabs are designed to maintain a low temperature surface for quick turn products such as ice cream. Frost patterns will vary depending on room conditions such as temperature, humidity and airflow. The "work zone" of the granite surface is considered to be inside a 2" (5.1cm) perimeter. Temperatures in the perimeter zone may be higher and again the frost patterns in this area will vary based on room conditions.

Unit is controlled by an on/off switch. Once turned on, the unit will run continuously. There is no temperature control in this unit. Turn the unit on approximately two hours prior to use to allow for ample cool down time. The unit must be turned off when not in use or overnight for defrosting and cleaning.

Operation N8600 Hot/Cold Series

Hot Operation

N8600 Series hot and cold combination pans must be operated with water in the well for proper hot operation. Fill well with a minimum of 4" (10.2cm) of water. Place function switch in **HOT** position. Turn thermostat dial to highest position and allow unit to warm up. Then reset the thermostat to maintain the desired temperature.



NOTE

Never use anything other than plain water in the wells or tank. Failure to observe this warning may result in personal injury or damage to the unit.



DANGER

When operated at the highest temperature setting, the top of the unit will become very hot. Staff and customers using the equipment should be informed about this.

To turn unit off, simply move the function switch to **OFF** position. Drain water and allow unit to cool before cleaning or switching to cold operation.

Cold Operation

Simply place the function switch to the **COLD** position. The compressor controller has been factory set and no temperature adjustment should be necessary. If the cold pan is to be used with ice, it is recommended that the optional perforated bottoms be used. These will allow ice to melt properly.

Switching from hot to cold operation

Follow this procedure:



STEPS

1. Place the function switch in the **OFF** position and drain out hot water.
2. Allow the unit to cool until it can be safely cleaned.
3. When clean up procedures are complete, unit will be ready for cold operation. This takes about one hour.



NOTE

To assure maximum compressor life, do not switch from "hot" to "cold" operation without allowing a cool down period. Never switch from hot to cold operation while hot water remains in the pans. Failure to observe this warning will greatly reduce compressor life and eventually cause premature compressor failure.

Switching from cold to hot operation

No special procedure is required to switch from the cold to hot operation. Be certain to fill well with a minimum of 4" of water.



NOTE

The unit is designed so that the compressor and the heating elements cannot operate at the same time. Continued operation of the compressor in the "hot position" should not be considered normal. Call for service if this happens.

The unit must be turned off when not in use or overnight for defrosting and cleaning.

Operation N8700-D, N8700N, N8700-R & N8800 Series

These units are designed to hold warm food product between 140°F to 160°F (60°C to 71°C).

N8700-D, N8700N and N8700-R series individually heated hot food units may be operated “wet” (with water in the wells) or “dry”. However, “wet” operation is recommended for better performance.

N8800 Series single tank hot food units are designed to be operated “wet” (with water in the tank) only.



Proper water level (approximately 2” [5.1cm]) must be maintained to prevent damage to the tank on the N8800 Series units.

After the unit is hard wired to the electrical system, select desired temperature by rotating temperature control. A knob and indicator light are provided for each individual heated food well.

First Time Use

Before the unit is used the first time for serving, turn the temperature knob to “HI” and heat the well for 20 to 30 minutes.

Any residue or dust that adhered to the heater element(s) will be burned off during this initial preheat period.

When serving thick sauces always use the hot food well in “wet” operation. This provides more uniform temperature for the sauce.



Never place food directly in well. Always use pans.

For most efficient operation, keep covered inserts in each well during preheating or when empty.

Always place covers on pans when not serving to prevent food from drying out.

Wet Operation

Fill the food well with a minimum of 2” (5.1cm) of water and cover with lid or empty pan. To preheat water, set temperature control at “HI”. With pans in place, wells will boil water. Food temperature will vary depending on type and amount of product. To minimize steam and water usage, set control at lowest setting that will maintain proper food temperature. To reduce preheating time, use hot water to fill the well.



When operating these units “wet,” never use anything other than plain water in the wells or tank. Failure to observe this warning may result in personal injury or damage to the unit.



When operated at the highest temperature setting, the top of the unit will become very hot. Staff and customers using the equipment should be informed about this.



Steam can cause serious burns. Always use some type of protective covering on your hands and arms when removing lids from the unit. Lift the lid in a way that will direct escaping steam away from your face and body.

Dry Operation N8700 Series only

Wet operation is usually much more efficient and is preferred. However, these units may be operated without water with no damage to the unit.

When operated dry, the bottom of the well will discolor. To clean, use a stainless steel cleaner or mild abrasive.



The dry well should never be preheated longer than 15 minutes.



When operated dry, the well bottoms become very hot. Do not allow unprotected skin to contact any well surface.

Maintenance

Drain Maintenance - N8100-FA Series

Each unit has a drain located inside the unit that removes the condensation from the evaporator coil and routes it to an external condensate evaporator pan. Each drain can become loose or disconnected during normal use. If you notice water accumulation on the inside of the unit be sure the drain tube is connected to the evaporator drain pan. If water is collecting underneath the unit make sure the end of the drain tube is in the condensate evaporator in the machine compartment. The leveling of the unit is important as the units are designed to drain properly when level. Be sure all drain lines are free of obstructions.



The power switch must be turned to OFF and the unit disconnected from the power source whenever performing service, maintenance functions or cleaning the refrigerated area.

Stainless Steel Care and Cleaning

To prevent discoloration or rust on stainless steel several important steps need to be taken. First, we need to understand the properties of stainless steel. Stainless steel contains 70- 80% iron, which will rust. It also contains 12-30% chromium, which forms an invisible passive film over the steel's surface, which acts as a shield against corrosion. As long as the protective layer is intact, the metal is still stainless. If the film is broken or contaminated, outside elements can begin to breakdown the steel and begin to form discoloration or rust. Proper cleaning of stainless steel requires soft cloths or plastic scouring pads.

NEVER USE STEEL PADS, WIRE BRUSHES OR SCRAPERS!

Cleaning solutions need to be alkaline based or non-chloride cleaners. Any cleaner containing chlorides will damage the protective film of the stainless steel. Chlorides are also commonly found in hard water, salts, and household and industrial cleaners. If cleaners containing chlorides are used be sure to rinse repeatedly and dry thoroughly. Routine cleaning of stainless steel can be done with soap and water. Extreme stains or grease should be cleaned with a non-abrasive cleaner and plastic scrub pad. Always rub with the grain of the steel. There are stainless steel cleaners available which can restore and preserve the finish of the steels protective layer. Early signs of stainless steel breakdown are small pits and cracks. If this has begun, clean thoroughly and start to apply stainless steel cleaners in attempt to restore the passivity of the steel.



Never use an acid based cleaning solution! Many food products have an acidic content, which can deteriorate the finish. Be sure to clean the stainless steel surfaces of ALL food products. Common items include, tomatoes, peppers and other vegetables.

Cleaning the Condenser Coil


In order to maintain proper refrigeration performance, the condenser fins must be cleaned of dust, dirt and grease regularly. It is recommended that this be done at least every three months. If conditions are such that the condenser is totally blocked in three months, the frequency of cleaning should be increased. Clean the condenser with a vacuum cleaner or stiff brush. If extremely dirty, a commercially available condenser cleaner may be required.

Failure to maintain a clean condenser coil can initially cause high temperatures and excessive run times. Continuous operation with a dirty or clogged condenser coil can result in compressor failure. Neglecting the condenser coil cleaning procedures will void any warranties associated with the compressor and cost to replace the compressor.




Never use a high-pressure water wash for this cleaning procedure as water can damage the electrical components located near or at the condenser coil.


Unit Assembly N8100-FA




Wiring Diagram N8100-FA




Wiring Diagram N8100B, N8100NB & N8100-BR




Wiring Diagram 8100-EF, 8100-EFN




Wiring Diagram N8200 & N8200G







Wiring Diagram N8643 & N8656




Wiring Diagram N8669 & N8681



Wiring Diagram N8800 208/230V




Wiring Diagram N8700-D, N8700N & N8700-R




AMPERES IN LINE WIRES

# OF WARMERS	120V, 1 PHASE	208V, 1 PHASE	230V, 1 PHASE	208-230V, 3 PHASE		
				L1	L2	L3
1	8.3	4.8	5.3			
2	16.7	9.6	10.6			
3	25	14.4	15.9	14.4/15.9	14.4/15.9	14.4/15.9
4	33.3	19.2	21.3	19.2/21.3	19.2/21.3	14.4/15.9
5		24	26.6	24/26.1	19.2/21.3	19.2/21.3
6		28.8	31.3	28.8/31.3	28.8/31.3	28.8/31.3



HA = HEATER ASSEMBLY


Standard Single Phase



HA = HEATER ASSEMBLY

Optional Three Phase

Drop In Louver Panel



Louver part #359-411-0003

Cutout dimension is 11" x 22" (27.9 cm x 55.9 cm).


Miscellaneous Parts 8000 SERIES

<u>Delfield Part #</u>	<u>Description</u>
265-AXE-0000	Divider bar, 2.00" x 20.93"
243-ALS-0032	Divider bar, 13.00" x .90"
243-AB0-0001	Divider bar, 21.00" x .90"
3234242	Plastic drain
1701273	Trim gasket (sold by foot)

Cap Tube Chart - R134A Refrigerant

<u>Model Number</u>	<u>Cap Tube Size/Length</u>
N8118B	.036ID x 72"
N8130B	.036ID x 72"
N8143B	.036ID x 72"
N8144-BR	.036ID x 72"
N8146NB	.042ID x 120"
N8156B	.042ID x 120"
N8159-BR	.036ID x 72"
N8168NB	.042ID x 120"
N8169B	.042ID x 120"
N8176-BR	.042ID x 120"
N8181B	.054ID x 110"
N8194-BR	.042ID x 120"

Replacement Parts N8100-FA



Key Description

	N8131-FA 2-PAN	N8144-FA 3-PAN	N8157-FA 4-PAN	N8169-FA 5-PAN	N8182-FA 6-PAN
1 Upright diffuser	226-0V3-0030	226-0V3-0031	226-0V3-0032	226-0V3-0033	226-0V3-0034
2 Air deflector	226-A9L-0030	226-A9L-0031	226-A9L-0032	226-A9L-0033	226-A9L-0034
3 Coil	3510086	3510086	3510086	3510086	3510086
4 Expansion valve	3516273	3516273	3516273	3516273	3516273
5 Coil assembly cover	019-0V0-0030	019-0V0-0038	019-0V0-0032	019-0V0-0033	019-0V0-0034
6 Fan assembly cover	226-0V1-0030	226-0V1-0031	226-0V1-0032	226-0V1-0033	226-0V1-0034
7 Adapter bar	243-AB0-0001	243-AB0-0001	243-AB0-0001	243-AB0-0001	243-AB0-0001
8 Perforated pan clip	270-0V5-0030	270-0V5-0031	270-0V5-0032	270-0V5-0033	270-0V5-0034
9 Black airflow extrusion	316-991-0030	316-991-0031	316-991-0032	316-991-0033	316-991-0034
10 Cover support bracket	226-0V2-0030	226-0V2-0030	226-0V2-0030	226-0V2-0030	226-0V2-0030
11 Fan guard	3516173	3516173	3516173	3516173	3516173
12 Fan blade	3516172	3516172	3516172	3516172	3516172
13 Fan motor	2162691	2162691	2162691	2162691	2162691
14 Fan bracket	031-264-0000	031-264-0000	031-264-0000	031-264-0000	031-264-0000
15 Plexiglas end cap	091-OXL-0030	091-OXL-0030	091-OXL-0030	091-OXL-0030	091-OXL-0030
16 S/S thumb screw	9321541	9321541	9321541	9321541	9321541
17 Cond. Unit	000-BN5-0030	000-BN5-0035	000-BN5-0035	000-BN5-0036	000-BN5-0036
— Timer	2194345	2194345	2194345	2194345	2194345
— Pressure Control	2193927	2193927	2193927	2193927	2193927
— Rocker switch	2190154	2190154	2190154	2190154	2190154


Condensing Unit 1/4 H.P. R404a Low

8100-EF Series, 8100-EFN Series, N8131-FA, N8231, N8231G, N8245, N8245G, N8259, N8273, N8630, N8643, N8656, N8669

Key	Delfield Part #	Description
-	000-BN5-0030	Condensing Unit Assembly, 115V
-	000-BN5-003J	Condensing Unit Assembly, 220V/50Hz
1	026-C58-0030	Shroud, Condenser Coil
2	3516457	Blade, Fan, 7.25"
3	2162717	Motor, fan, 9W, 115V
3	2162720	Motor, fan, 9W, 230V
4	2160020	Guard, Fan, 7.25"
5	3526999	Compressor, NF5.5CLX, 115V/60Hz, Danfoss
5	3527013	Compressor 220/50Hz, Danfoss
6	2194787	Capacitor, Start 280MFD
7	3516444	Compressor relay and overload, NF5.5CLX
8	3516322	Filter-dryer, (2) inlet .25"
9	075-231-0030	Pan, condensate
10	3516454	Condenser Coil

Miscellaneous Parts Not Included in Condensing Unit


-	2194099	15 Amp switch, 120V
-	2194400	15 Amp switch, 220V
-	2183348	Cord/plug assembly
-	3516225	Expansion valve

**Condensing Unit Assembly 1/3 H.P. R404a, Low, N8259G, N8287, N8681**

Key	Delfield Part #	Description
-	000-BN5-003G	Condensing Unit Assembly, 115V
-	000-BN5-003M	Condensing Unit Assembly, 220V/50Hz
1	026-C58-0030	Shroud, Condenser Coil
2	3516457	Blade, Fan, 7.25"
3	2162717	Motor, fan, 9W, 115V
3	2162720	Motor, fan, 9W, 230V
4	2160020	Guard, Fan, 7.25"
5	3527000	Compressor, NF7.0. 115V/60Hz, Danfoss
5	3527012	Compressor, 220V/50Hz Danfoss
6	3516324	High pressure switch
7	2194788	Capacitor, Start 320MFD
8	3516438	Compressor relay and overload, NF7CLX
9	3516322	Filter-dryer, (2) inlet .25"
10	3516458	Receiver tank
11	075-231-0030	Pan, condensate
12	3516454	Condenser Coil

Miscellaneous Parts Not Included in Condensing Unit

-	3516225	Expansion valve
-	2194099	15 Amp switch, 120V
-	2194400	15 Amp switch, 220V
-	2183348	Cord/plug assembly




Condensing Unit Assembly 1/2 H.P. R404a, Low, N8273G

Key	Delfield Part #	Description
-	000-BN5-0033	Condensing Unit Assembly, 115V
-	000-BN5-003N	Condensing Unit Assembly, 220V/50Hz
1	026-C58-0031	Shroud, 1/2 HP Condenser Coil
2	3516554	Blade, Fan, 9.00", 5-pedal
3	2160019	Guard, Fan, Condenser, Upright
4	2162716	Motor, Fan, 16W, 115V
4	2162721	Motor, Fan 16W, 230V
5	3516324	High Pressure Switch
6	3527001	Compressor, SC12CLX.2, 115V/60Hz, Danfoss
6	3527011	Compressor, 220V/50Hz, Danfoss
7	3516322	Filter-dryer, (2) inlet .25"
8	2194789	Capacitor, Start 240MFD
9	3516441	Compressor relay, SC12CLX.2
10	3516459	Receiver
11	3516455	Condenser Coil


Miscellaneous Parts Not Included in Condensing Unit

-	3516225	Expansion valve
-	2194099	15 Amp switch, 120V
-	2194400	15 Amp switch, 220V
-	2183348	Cord/plug assembly




Narrow Base Condensing Unit Assembly 1/5 H.P. R134A, Low**N8118B, N8130B, N8143B, N8144-BR, N8146NB, N8159-BR, N8168NB**

Key	Delfield Part #	Description
1	2183300	Harness, wire, power cord, 8100
2	3526694	Compressor, 1/5 h.p., 115v/60hz
2	3526718	Compressor, 1/5 h.p., 220v/50hz
3	3516047	Cold Control
4	024-ADB-0040	Compressor stand
5	031-264-0000	Bracket, fan motor, blower coil
6	3516172	Blade, fan, 5.56, CCW, Lexan, clear
7	2162691	Motor, fan, 115v, 50/60, UPPCO/bay
7	2162692	Motor, fan, 230V, 50/60, UPPCO/bay
8	026-ANM-0030	Fan baffle
9	3516067	Coil, condenser, 9 x 10, R-134a, 8100
-	3516191	Filter dryer
-	2194400	15 Amp switch, 220V


**Narrow Base Condensing Unit Assembly N8156B, N8169B, N8176-BR, N8181B, N8194-BR**

Key	Delfield Part #	Description
1	2183300	Harness, wire, power cord
2	3526703	Compressor, 1/3HP, 115/60, R134A, N8181B
2	3526695	Compressor, 1/4 h.p., 115v/60hz, N8156B, N8169B, N8176-BR, N8194-BR
2	3526719	Compressor, 1/4 h.p., 220v/50hz
3	3516047	Cold control
4	024-ADB-0041	Stand, compressor
5	2194013	Fan assembly, condenser, 8" blade, 115V
5	2162689	Fan assembly, condenser, 8" blade, 220V
6	026-ANM-0033	Baffle, fan
7	3516067	Coil, condenser, 9x10, R134A
-	3516191	Filter dryer
-	2194400	15 Amp switch, 220V




Condensing Unit Assembly 1/2 H.P. N8144-FA, N8157-FA


Key	Delfield Part #	Description
-	000-BN5-0035	Condensing Unit Assembly
1	026-C58-0031	Shroud, 1/2 HP condenser coil
2	3516554	Blade, fan 9.00", 5 pedal
3	2160019	Guard, fan, condenser, upright
4	2162716	Motor, fan, 16W, 115V
5	3516462	Capacitor, start, assembly
6	3527026	Compressor, SC12MLX, 115V/60Hz, Danfoss
7	3516331	High pressure switch
8	3516322	Filter dryer, (2) inlet, .25"
9	3516459	Receiver
10	075-231-0031	Pan, condensate
11	3516455	Coil, 1/2 HP condensing



Condensing Unit Assembly 3/4 H.P. N8169-FA, N8182-FA

Key	Delfield Part #	Description
-	000-BN5-0036	Condensing Unit Assembly
1	026-C58-0032	Shroud, 3/4 HP condenser coil
2	2160019	Guard, fan, condenser, upright
3	3516442	Capacitor, start, run, assembly
4	3527021	Compressor, SC18MLX, 115V/60Hz, Danfoss
5	3516322	Filter dryer, (2) inlet, .25"
6	3516360	Tank, receiver
7	3516456	Coil, condenser, 3/4 HP
-	075-231-0031	Pan, condensate
-	3516433	Blade, fan 25°, 10", CW, upright
-	2162716	Motor, fan, 16W, 115V




Food Well Assembly With Thermostat control N8600**For models N8600**

Key	Delfield Part #	Description
1	2194940	Immersion heater 120V, 1Ph 3KW
1	2194942	Immersion heater 240V 1Ph 5KW
2	026-AO6-0041	Box, control, galv, 8600 series
3	372-ANQ-003D	Front, collar, mounting, 8600
4	2193979	Switch, 3 position, 30Amp
5	372-ANS-0001	Cover, control box, 8700 series
6	2194190	Light, pilot, 125V, red
7	2194202	Thermostat, electric (heated)
8	3234556	Knob, thermostat control (heated)
9	2194185	Contactor, relay 30 Amp 120V
10	3516047	Temperature control (cold)

Food Well Assembly With Infinite Control N8700

For models N8700D, N8700N, N8700ND, N8700R


Key	Delfield Part #	Description
1	3434703	Insulation, fiberglass, 9" x 48"
2	2194335	Thermostat, non-adjustable, 480°F
3	026-103-0002	Bottom cover
4	3434663	Insulation, blanket, 24" wide
5	026-061-0001	Plate, deflector, DFW, with or without drain
6	2194007	Element, heating, 208/230v, 1000/1222w
6	2194006	Element, heating, 120v
7	000-BQ9-Z0000	Well, hot food, with drain
7	000-BQ9-Z0001	Well, hot food, without drain
-	3234557	Knob, infinite control
-	2194110	Control, infinite, 240v, 14a
-	2194107	Control, infinite, 120v



Food Well Assembly With Thermostat Control N8800

For models N8831, N8859, N8873, N8887

Key	Delfield Part #	Description
1	3234556	Knob, thermostat control
2	2193984	Thermostat 30A, N8873, N8887
2	2194012	Thermostat, 25A, N8831, N8845, N8859
3	2194007	Element, heating, 208/230v, 1000/1222w
3	2194006	Element, heating, 120v, 1000w
4	026-061-0001	Plate, deflector, DFW, with drain
-	3434704	Insulation, fiberglass, 1" thick
-	3434664	Insulation, fiberfrax, 1" thick



Standard Labor Guidelines To Repair Or Replace Parts On Delfield Equipment

Advice and recommendations given by Delfield Service Technicians do not constitute or guarantee any special coverage.

- A maximum of 1-hour is allowed to **diagnose a defective component**.
- A maximum of 1-hour is allowed for **retrieval of parts** not in stock.
- A maximum **travel distance** of 100 miles round trip and 2-hours will be reimbursed.
- Overtime, installation/start-up, normal control adjustments, general maintenance, glass breakage, freight damage, and/or correcting and end-user installation error will not be reimbursed under warranty unless pre-approved with a **Service Work Authorization** from Delfield. You must submit the number with the service claim.

Labor Of 1-Hour Is Allowed To Replace:

- Compressor Start Components and Overload Protector
- Condenser Fan Motor and Blade
- Hi-limit/Thermal Protector Switch
- Solenoid Coil
- Condensate Element
- Contactor/Relay
- Infinite Switch
- Thermostat

Labor Of 2 Hours To Replace:

- Heating Element
- Solenoid Valve
- Locate/Repair Leak

Labor Of 3 Hours To Replace:

- Capillary Tubing
- Expansion Valve
- Condenser

Labor Of 4 Hours To Replace:

- Compressor

This includes recovery of refrigerant and leak check.

\$55.00 maximum reimbursement for refrigerant recovery (includes recovery machine, pump, torch, oil, flux, minor fittings, solder, brazing rod, nitrogen, or similar fees.)

Refrigerants:

- R134A A maximum of \$5.00/lb. or 31¢/oz. will be reimbursed.
- R404A A maximum of \$15.00/lb. or \$1.00/oz. will be reimbursed.



Standard One Year Limited Warranty (One year parts, 90 days labor)

The Delfield Company ("Delfield") warrants to the Original Purchaser of the Delfield product (herein called the "Unit") that such Unit, and all parts thereof, will be free from defects in material and workmanship under normal use and service for a period of one (1) year from the date of shipment of the Unit to the Original Purchaser **or, if the Original Purchaser returns the warranty card completely filled out including the date of installation within thirty (30) days of receipt of the Unit, one (1) year from the date of installation.** During this one year warranty period, Delfield will repair or replace any defective part or portion thereof returned to Delfield by the Original Purchaser which Delfield determines was defective due to faulty material or workmanship. The Original purchaser will pay all labor, crating, freight and related costs incurred in the removal of the Unit of defective component and shipment to Delfield, except that during a period of either ninety (90) days from the date of shipment of the Unit to the Original Purchaser or, if the Original Purchaser returns the warranty card completely filled out including the date of installation within thirty (30) days of receipt of the Unit, ninety (90) days from the date of installation Delfield will pay all related labor costs. Delfield will pay the return costs if the Unit or part thereof was defective.

The term "Original Purchaser" as used herein means that person, firm, association, or corporation for whom the Unit was originally installed.

This warranty does not apply to any Unit or part thereof that has been subjected to misuse, neglect, alteration, or accident, such as accidental damage to the exterior finish, operated contrary to the recommendations specified by Delfield; or repaired or altered by anyone other than Delfield in any way so as to, in Delfield's sole judgement, affect its quality or efficiency. This warranty does not apply to any Unit that has been moved from the location where it was originally installed. This warranty also does not cover the refrigerator drier or the light bulbs used in the Unit. **The warranty is subject to the user's normal maintenance and care responsibility as set forth in the Service and Installation Manual, such as cleaning the condenser coil, and is in lieu of all other obligations of Delfield. Delfield neither assumes, nor authorizes any other person to assume for Delfield, any other liability in connection with Delfield's products.**

Removal or defacement of the original Serial Number or Model Number from any Unit shall be deemed to release Delfield from all obligations hereunder or any other obligations, express or implied.

Parts furnished by suppliers to Delfield are guaranteed by Delfield only to the extent of the original manufacturer's express warranty to Delfield. Failure of the Original Purchaser to receive such manufacturer's warranty shall in no way create any warranty, expressed or implied, or any other obligation or liability on Delfield's part in respect thereof.

If shipment of a replacement part is requested prior to the arrival in the Delfield factory of the part claimed to be defective, the Original Purchaser must accept delivery of the replacement part on a C.O.D. basis, with credit being issued after the part has been received and inspected at Delfield's plant and determined by Delfield to be within this warranty.

Under no condition does this warranty give the Original Purchaser the right to replace the defective Unit with a complete Unit of the same manufacturer or of another make. Unless authorized by Delfield in writing, this warranty does not permit the replacement of any part, including the motor-compressor, to be made with the part of another make or manufacturer.

No claims can be made under this warranty for spoilage of any products for any reason, including system failure.

The installation contractor shall be responsible for building access, entrance and field conditions to insure sufficient clearance to allow any hood(s), vent(s), or Unit(s) if necessary, to be brought into the building. Delfield will not be responsible for structural changes or damages incurred during installation of the Unit or any exhaust system.

Delfield shall not be liable in any manner for any default or delay in performance hereunder caused by or resulting from any contingency beyond Delfield's control, including, but not limited to, war, governmental restrictions or restraints, strike, lockouts, injunctions, fire, flood, acts of nature, short or reduced supply of raw materials, or discontinuance of the parts by the original part manufacturer.

Except as provided in any Additional Four Year Protection Plan, if applicable, and the Service Labor Contract, if applicable, the foregoing is exclusive and in lieu of all other warranties, whether written or oral, express or implied. This warranty supersedes and excludes any prior oral or written representations or warranties. Delfield expressly disclaims any implied warranties of merchantability, fitness for a particular purpose or compliance with any law, treaty, rule or regulation relating to the discharge of substances into the environment. The sole and exclusive remedies of any person relating to the Unit, and the full liability of Delfield for any breach of this warranty, will be as provided in this warranty.

Other than this Delfield Standard One Year Limited Warranty, any applicable Delfield Additional Four Year Protection Plan or applicable Delfield Service Labor Contract, the Original Purchaser agrees and acknowledges that no other warranties are offered or provided in connection with or for the Unit or any other part thereof.

In no event will Delfield be liable for special, incidental or consequential damages, or for damages in the nature of penalties.

Additional Four Year Protection Plan (for Motor-Compressor only)

Delfield Model#	Serial #	Installation Date
<input type="text"/>	<input type="text"/>	<input type="text"/>

In addition to the Standard One Year Warranty on the Motor-Compressor contained in the above listed Delfield product (the "Unit"), The Delfield Company ("Delfield") also agrees to repair, or exchange with similar or interchangeable parts in design and capacity at Delfield's option, the defective Motor-Compressor contained in the Unit (the "Motor-Compressor"), or any part thereof, for the Original Purchaser only, at any time during the four (4) years following the initial one (1) year period commencing on the date of installation for the Original Purchaser. **Failure of the Original Purchaser to register the registration card containing the Original Purchaser's name, address, date of installation, model number and serial number of the Unit containing the Motor-Compressor within 30 days from the date of installation shall void this warranty.** This additional warranty is only available if the Motor-Compressor is inoperative due to defects in material or factory workmanship, as determined by Delfield in its sole judgement and discretion. The Original Purchaser shall be responsible for returning the defective Motor-Compressor to Delfield prepaid, F.O.B. at the address shown on the back cover of this manual.

The term "Original Purchaser" as used herein means that person, firm, association, or corporation for whom the Unit was originally installed.

The term "Motor-Compressor" as used herein does not include unit base, air or water cooled condenser, receiver, electrical accessories such as relay, capacitors, refrigerant controls, or condenser fan/motor assembly. This warranty does not cover labor charges incidental to the replacement of parts. This warranty further does not include any equipment to which said condensing unit is connected, such as cooling coils, temperature controls or refrigerant metering devices. This warranty shall be void if the Motor-Compressor, in Delfield's sole judgement, has been subjected to misuse, neglect, alteration or accident, operated contrary to the recommendations specified by the Unit manufacturer, repaired or altered by anyone other than Delfield in any way so as, in Delfield's sole judgment, to affect its quality or efficiency or if the serial number has been altered, defaced or removed. This Warranty does not apply to a Motor-Compressor in any Unit that has been moved from the location where it was originally installed. The addition of methyl chloride to the condensing unit or refrigeration system shall void this warranty.

General Conditions

Delfield shall not be liable in any manner for any default or delay in performance hereunder caused by or resulting from any contingency beyond Delfield's control, including, but not limited to, war, governmental restrictions or restraints, strike, lockouts, injunctions, fire, flood, acts of nature, short or reduced supply of raw materials, or discontinuance of any part or the Motor-Compressor by the unit manufacturer.

Replacement of a defective Motor-Compressor is limited to one (1) Motor-Compressor by us during the four (4) year period. Delfield shall replace the Motor-Compressor at no charge.

This warranty does not give the Original Purchaser of the Motor-Compressor the right to purchase a complete replacement Motor-Compressor of the same make or of another make. It further does not permit the replacement to be made with a Motor-Compressor of another kind unless authorized by Delfield. In the event Delfield authorizes the Original Purchaser to purchase a replacement Motor-Compressor locally, only the wholesale cost of the Motor-Compressor is refundable.

Expressly excluded from this warranty are damages resulting from spoilage of goods.

Except as provided in any applicable Standard One Year Limited Warranty or applicable Service Labor Contract, the foregoing is exclusive and in lieu of all other warranties, whether written or oral, express or implied. This Warranty supersedes and excludes any prior oral or written representations or warranties. Delfield expressly disclaims any implied warranties of merchantability, fitness for a particular purpose or compliance with any law, treaty, rule or regulation relating to the Motor-Compressor, and the full liability of Delfield for any breach of this warranty, will be as provided in this warranty.

Other than any applicable Delfield Standard One year Limited Warranty, this Delfield Additional Four Year Protection Plan and any applicable Delfield Service Labor Contract, the Original Purchaser agrees and acknowledges that no other warranties are offered or provided in connection with or for the Motor-Compressor or any part thereof.

In no event will Delfield be liable for special, incidental or consequential damages, or for damages in the nature of penalties.





Mt. Pleasant, MI



Covington, TN

Thank you for choosing Delfield!

Help is a phone call away. Help our team of professional, courteous customer service reps by having your model number and serial number available at the time of your call (800) 733-8829.

Model: _____ S/N: _____

Installation Date: _____



**For a list of Delfield's authorized parts depots,
visit our website at www.delfield.com.**

